

turbo RS 3-38

Operating instructions



Operating instructions

turbo RS 3-38, series 1

Confirmation number from: 1906087

Editorial deadline: 14.07.2022

FMB Maschinenbau
Paul-Hohe-Straße 1
97906 Faulbach
+49 9392 801 0

info@fmb-machinery.de
www.fmb-machinery.de

Operating instructions

1, 3, en_US

Table of contents

1	General	5
1.1	Operating instructions	5
1.2	Information about the product	8
1.3	Technical data	12
2	Safety	16
2.1	Safety measures	16
2.2	Safety equipment	16
3	Transport	18
3.1	Prepare for transportation	18
3.2	Transporting the product	23
4	Assembly and start-up	27
4.1	Prepare for assembly	27
4.2	Aligning	28
4.3	Electrical connection	29
4.4	Assembly	30
4.5	Adjustments	36
4.6	Settings	37
4.7	Pre-set parameters	39
5	Control panel	44
5.1	Control panel, general	44
6	Operation	46
6.1	Basic functions	46
6.2	Overview of selections	47
6.3	Edit and manage programs	51
6.4	Processing settings	56
6.5	Clamp material bars	59
6.6	Feed material bars	62
6.7	Processing phase	66
7	Converting	76
7.1	General conversion	76
7.2	Guide channel	76
7.3	Reduction	89
7.4	Steady	89
7.5	Separating device	102
8	Maintenance	107
8.1	Maintenance actions	107
8.2	Auxiliary equipment	112

9 **Faults**..... 114

 9.1 Fault messages..... 114

 9.2 Fault table..... 115

 9.3 Service..... 119

 9.4 Technical problems..... 119

10 **Index**..... 121

1 General

1.1 Operating instructions

Product versions and special equipment

The operating instructions cover several versions of the described product. You can see which version of the product you have in the field "Type" on the name plate. ➔ *"Name plate" on page 8.*

The product versions differ with regards to the length of the loading magazine and therefore also with regards to the number of supports. In the chapters "Transport" and "Assembly" the respective product version is to be observed. Product versions over a certain length can be delivered in two pieces. Please find more precise information about the individual product versions from the respective dimension sheet. ➔ *"Other applicable documents" on page 5.*

The diagrams may vary from the actual product. The principle described does, however, apply to all versions.

The operating instructions also describe special equipment, which may not be installed on your product. The descriptions of special equipment state that they are optionally installed.

Special equipment with a greater scope is described in corresponding supplemental instructions, which can also be found in the technical documentation folder. The supplemental instructions are a supplement to the operating instructions, and are to be observed in connection with it. First familiarize yourself with the operating instructions, before you use the supplemental instructions.

Other applicable documents

The operating instructions are supplemented by the following documents, which are also kept in the technical documentation folder:

- Circuit diagram
- Pneumatics plan
- Dimension sheet (specific to the product version)
- Adapter set/attachment diagram (optional)
- Supplemental instructions (optional)

Explanation of symbols

 **DANGER**

Warning Hazard

Warns of a hazard with a high risk level which, if not avoided, will cause death or severe injury.

Type and source of hazard

Consequences if the note is disregarded.

- Actions necessary to avert the hazard.

Warning Hazard

Warns of a hazard with a medium risk level which, if not avoided, could cause death or severe injury.

 **WARNING**

Type and source of hazard

Consequences if the note is disregarded.

- Actions necessary to avert the hazard.

⚠ CAUTION

Warning Caution

Warns of a hazard with a low risk level which, if not avoided, could cause minor or moderate injury.

Type and source of hazard

Consequences if the note is disregarded.

- Actions necessary to avert the hazard.

Note (material damage)

A note that misuse could cause material damage.

NOTICE

Type and source of hazard

Consequences if the note is disregarded.

- Actions necessary to avert the hazard.

Useful information

Notes or additional information.



Useful information.

Instructions on use

→ These instructions require the user to take action.

Display text

Display text comprises terms or text which appear on the control panel of the product.

Example: **Display text**.

Menu pathway

The menu pathway shows the path for actions, where you have to navigate through more than one menu level.

Example: **Start → Sub menu → Destination**

Cross-reference

Cross-references refer to further information about a topic.

Example: ➔ *“Explanation of symbols” on page 5.*

Intended use

The loading magazine is intended for attachment to machine tools, and is only allowed to be operated if it has been installed on a machine tool in accordance with the specifications of these operating instructions. The loading magazine is exclusively intended for the supply of material bars to machine tools. These materials are round or have multiple edges. In individual cases, special profiles are allowed to be supplied, which have been agreed with FMB in advance.

Furthermore, the intended use of the loading magazine can be seen by observing the Technical Data chapter of these operating instructions ➔ *Chapter 1.3 “Technical data” on page 12.*

The applicable accident prevention guidelines and other generally-recognized technical safety regulations are to be observed.

Reasonably foreseeable misuse

- Non-observance of the requirements on the material bars.
➔ *“Requirements on the material bars” on page 59.*
- Operation with asymmetric profile bars without consultation with FMB.

- Operation with special profiles without consultation with FMB.
- Operation with non-homogenous material bars (imbalance).
- Processing outside of the permitted area (diameter, length).
➔ *“Technical data of the loading magazine” on page 12.*
- Use of unintended fuel. ➔ *“Lubricant” on page 14.*
- Operation without lubrication.
- Operation without a capacity adjustment set or with the wrong set.
Operation without a clamping device or with the wrong clamping device.
- Transportation not done in accordance with the operating instructions. ➔ *Chapter 3.2 “Transporting the product” on page 23.*
- Operation outdoors.
- Manipulation of safety equipment.
- Performance of work without sufficient qualifications. ➔ *“Qualifications of the personnel” on page 7.*

Unauthorized alterations to the product are not permitted and exclude the liability of the manufacturer for any damage incurred as a result.

Qualifications of the personnel

The work described in these operating instructions is only allowed to be performed by personnel who have been qualified according to the table specified below.

Area of responsibility	Training by the manufacturer concerning assembly and start-up*	Product training**	Specific technical training***
Transport			X
Assembly / Start-up	X		
Operation		X	
Maintenance		X	X
Disposal			X

*Extensive qualification in the assembly and start up of FMB products. Qualification is done by FMB.



**Personnel who have received training for the product, are familiar with the functions and have been made aware of the risks. The training can be done by FMB or by a person who has already received training.

***Personnel who have received training in the respective area of responsibility, and have qualifications allowing them to perform the work correctly, to properly estimate risks and avoid hazards.

1.2 Information about the product

Name plate


The name plate is attached to the loading magazine in position **1**.




2	Types and lengths	3	Machine number
4	Year of construction		

The declaration of conformity (CE or UKCA) shall be added, if issued, to the name plate of the loading magazine.

Overview



1	Control cabinet	2	Cover
3	Support	4	Oil tank
5	Remnant bin	6	Control panel
7	Steady		



8	Drive	9	Lateral material storage with separation device
10	Guide channel, rear	11	Material gripper
12	Guide channel, front		

Functional description

The loading magazine supplies material bars and pushes them through the spindle into the processing area of the machine tool. The loading magazine works at the speed of the machine tool and thereby allows the automatic loading of the machine tool.

The collet of the machine tool closes and processing begins. The guide channel filled with oil and the steady placed between the machine tool and the guide channel ensure the exact bar guide required for processing. After a workpiece has been completed, the collet of the machine tool opens. The pusher of the loading magazine moves the material bar into the cut-off position, the collet of the machine tool closes and the next workpiece is processed.

If the material bar has been used up and the last possible part has been made, the working process of the machine tool is stopped. The collet of the machine tool opens and the pusher is moved back. The material gripper closes and holds the remnant of the material bar in position. The remnant is taken out of the clamping sleeve and is ejected into the remnant bin. The working process begins again.

Drive

The pusher is driven by a servomotor with a toothed belt. A sensor on the servomotor detects the exact position of the pusher.

Material gripper

The material gripper is equipped with blades, allowing it to grab the material bar. The newly-inserted material bars are held by the material gripper and pressed into the clamping device using the

force of the pusher. Remnants of processed material bars are held by the material gripper and removed from the clamping device using the force of the pusher.

Synchronizing unit


The synchronizing unit is only installed in loading magazines, which are intended for attaching to lathes with a moving headstock. The synchronizing unit ensures that the pusher of the loading magazine and the material bar also complete the traverse paths of the lathe headstock.

This is made possible by the synchronization bar, which is connected to the lathe headstock and transfers any movement of the lathe headstock to the pusher via the synchronization clutch.

During the processing by the lathe, the drive of the loading magazine is switched off and the synchronization clutch is closed. The movements of the lathe spindle are transferred to the pusher. The pusher and the material bar move at the speed of the lathe headstock.


During the bar feed the drive of the loading magazine is switched on and the synchronization clutch is opened. The pusher is moved by the drive of the loading magazine. The material bar is pushed on.

Layout of the components



1	End stop	2	Pusher with short pusher flag
3	Material gripper	4	Pusher
5	Clamping sleeve	6	Starting switch
7	Guide module	8	Lathe spindle
9	Lathe collet		

Positions and traverse paths



1	Pusher length	The dimension for the parameter Pusher length is measured from the rear edge of the pusher to the front edge of the bearing insert.
2	Traverse path First insert travel	The first insert is performed after the material bar is changed. The traverse path First insert travel is the path from the starting switch in the loading magazine to the cut-off position in the working area of the lathe.
3	Traverse path Travel interval on	With interval insert active, an intermittent feed takes place in the area of Travel interval on .
4	Position draw off	At the position Position draw off the material gripper grips the material bar.
5	Position rear limit	The maximum rear position the pusher is able to reach. The position Position rear limit is reached when the remnant is removed or the pusher swings out.
6	Position storage	The position at which the short pusher picks up a new material bar. The pusher travels at high speed, just before the position Position storage it brakes, picks up the material bar and accelerates again.
7	Position Limit pos. short pusher front	The position to which the pusher moves the material bar, enabling the material gripper to grab the material bar.
8	Position open steady	During operation, the clamping sleeve must pass the steady. When the clamping sleeve is at the position Position open steady the steady opens to prevent damage.
9	Position close steady	During operation, the clamping sleeve must pass the steady. When the pusher passes the open steady and has reached the position Position close steady the steady closes.

10	Pos. reverse rotation return	When returning from the spindle of the lathe, the pusher moves from the position Pos. reverse rotation return at high speed.
11	Position front limit	The maximum front position the pusher is able to reach. The clamping sleeve is just before the collet of the lathe. The value Position front limit and the value Part length 1 are used to calculate when the last part will be fed in.
12		The clamping sleeve is pressed on to the material bar up to this position.
13	Length of guide module	The dimension for the parameter Length of guide module is measured from the rear edge to the front edge of the guide tube and depends on the stroke of the guide module.

1.3 Technical data

Technical data of the loading magazine

Characteristic	Unit	Value
Material flow in the guide channel	mm	3 - 38
Bar length	mm	3200 / 3800 / 4200 / 4775 / 5300 / 6200 / 7400
Maximum feed force	N	550
Insert speed	mm/s	520
Feed speed	mm/s	1000
Return speed	mm/s	2000
Maximum remnant length	mm	450
Weight ³ Length version 3200	kg	750
Weight ³ Length version 3800	kg	900
Weight ³ Length version 4200	kg	1000
Weight ³ Length version 4775	kg	1100
Weight ³ Length version 5300	kg	1250

Characteristic	Unit	Value
Weight ³ Length version 6200	kg	1500
Weight ³ Length version 7400	kg	1850
Weight of transport pallet	kg	Depending on length variant approx. 250 - 500
Oil tank level	l	80
Supply of compressed air	bar	6 - 10
Compressed air consumed per loading process	l	approx. 10
Compressed air consumed per double stroke of the steady	l	approx. 0.5
Noise emission during the bar change	dB(A)	48 +/- 5
Operating voltage ^{1, 4}	V	200 / 400 / other types
Power requirement	KW	2
Nominal frequency ^{2, 5}	Hz	50 / 60
Control voltage	V	24

1) According to DIN EN 60204 (VDE 0113), the continuous operating voltage must be within 100% ± 10% of the line voltage.

2) According to DIN EN 60204 (VDE 0113), the frequency must be between 0.99 and 1.01 of the nominal frequency.

3) Empty, without equipment and without transport pallets.

4) The operating voltage applicable for your product can be seen on the circuit diagram. ➔ *"Other applicable documents" on page 5.*

5) The product is rated for a nominal frequency of 50 Hz and 60 Hz.

Operating conditions

Characteristic	Unit	Value
Surrounding temperature	°C	+ 15 - + 40
Air humidity, non-condensing	%	30 - 75
Altitude about sea level	m	up to 1000

Storage conditions

Characteristic	Unit	Value
Surrounding temperature	°C	- 20 - + 65

The loading magazine is only allowed to be stored in dry rooms.

Lubricant

The lubricant used must comply with one of the following standards.


- DIN 51 517-2 CL 68,
- DIN 51 506 VBL 68,
- DIN ISO 3448 ISO VG 68.

The following lubricants are recommended for use in the loading magazine:

Manufacturer	Type
Aral	Motanol HE 68
Mobil / Esso	Vacuoline 1409
Shell	Morlina 68

Dimensions of the loading magazine

*Dimension A: Material bar length; **Dimensions B and C: Depending on the pusher



Stroke	400	400	600	600
Pusher length	1466	1666	1666	1866
	B1	B2	B2	B3
	C1	C2	C2	C3

Table of dimensions

Loading magazine length	Dimensions in mm								
	A	B1	B2	B3	D	C1	C2	C3	G***
2200	2200	3295	3495	3695	690	1365	1565	1765	740 - 1440
3200	3200	4295	4495	4695					
3800	3800	4895	5095	5295					
4200	4200	5295	5495	5695					
4775	4775	5870	6070	6270					
5300	5300	6395	6595	6795					
6200	6200	7295	7495	7695					

*** Set to the spindle height. On loading magazines with a shifting device, this value increases by 30 mm.

2 Safety

2.1 Safety measures

Personal safety equipment

The operator of the product must provide the following safety equipment and ensure they are used.

- Safety shoes
- Ear protection
- Safety gloves
- Eye protection
- Skin protection

2.2 Safety equipment

Emergency stop device

The loading magazine has an emergency stop device which complies with DIN EN 60204 (VDE 0113). The emergency stop button is mounted on the control panel ➔ *"Press the emergency stop button" on page 46.*

When the emergency stop button is pressed, the power is shut off for the safety-relevant PLC outputs. In addition, the power supply for the drive motor is shut off. The drive motor and hence the pusher cannot perform any more movements. The pressurization of the pneumatic valves remains for the function "Open / close guide channel", so that the guide channel remains shut. The pressurization of the rest of the pneumatic valves is interrupted. They go to their original position. An error message appears on the control panel of the loading magazine.

The emergency stop signal is transmitted to the machine tool and has to be processed there in accordance with DIN EN 23125.

If the emergency stop button of the machine tool is pressed, the emergency stop signal is forwarded to the loading magazine and also triggers an emergency stop there.

Lock

The cover of the loading magazine and the lid of the steady are monitored by the lock. In open position, the lock prevents the loading magazine operating. If the lock reports an "open" position, there is no power at certain PLC outputs and the drive is shut down. The lock helps ensure the loading magazine operates safely.

Safety door of the machine tool

If the safety door of the machine tool is opened during operation, the drive of the loading magazine is shut down. It is not possible to move the pusher of the loading magazine if the safety door of the machine tool is open. A risk to people due to the pusher of the loading magazine being in the working area of the machine tool is therefore excluded.



Working on the guide channel

The guide channel is divided into the front guide channel and the rear guide channel. Both parts can be opened either separately or together. Safety bolts are attached to the bearing brackets. They

must be used when working on an open guide channel to secure the guide channel. ➔ *“Securing the guide channel with safety bolts” on page 76.*

Valve block

The valve block is located in position **1** on the loading magazine.



On the valve block, all valves are centrally supplied with compressed air. The compressed air for all valves can be shut off centrally at the stop valve **2**.

After shutting off the compressed air, compressed air can be stored in the individual pneumatic cylinders. This can cause unforeseen movements of individual components of the loading magazine. The pneumatic cylinders can be vented separately via the valves **3** after shutting off the supply of compressed air.

This is the case in the event of certain repair work and with troubleshooting. The valve block is only allowed to be operated by personnel qualified to use it. In the event of questions please contact FMB. ➔ *“Service contact details” on page 119.*

3 Transport

3.1 Prepare for transportation

Preparing the loading magazine for transportation

DANGER

Movable guide channel/guide module can unexpectedly move forward out of the loading magazine

During transport, the movable guide channel/guide module can move forward out of the loading magazine due to its inertia caused by jerky movements. Personal injury from impact can result.

- Do not loiter in the danger area.
- Install the transport lock for the guide channel/guide module before transport as described in the operating instructions.

WARNING

Falling attachments/components

Loose attachments or components being transported by the loading magazine can fall and cause personal injury due to crushing and impact.

- Secure loose attachments or components against slipping and falling before transport.



Once the loading magazine has been raised, the pins extending out of the floor must be detached at ground level or removed from the floor using suitable means.


1. ➤ Completely remove any material bars. ➤ *"Removing the material bar from the loading magazine" on page 69 or ➤ "Draw off and eject the remnant" on page 69.*
2. ➤ Press the  button.
3. ➤ **SETUP** Opening.
4. ➤ Move the pusher all the way to the back using the  button.
5. ➤ Leave the loading magazine at a standstill for at least 8 hours to allow the oil to drain out.
6. ➤ Turn off the main switch of the lathe.
7. ➤ Disconnect the power supply to the lathe (remove the connector).
8. ➤ Remove all the electrical connections from the loading magazine to the control cabinet.
9. ➤ Dispose of the oil / cooling lubricant in accordance with the legal provisions.
10. ➤ Depressurize the compressed air line to the loading magazine.
11. ➤ Switch off the compressed air supply. ➤ *"Switch the supply of compressed air on/off" on page 112*
➤ The loading magazine is vented.
12. ➤ Fasten the control cabinet to the beam ➤ *"Removing the control cabinet from / attaching the control cabinet to the loading magazine" on page 34.*

- 13.** ▶ Install the transport lock for the guide channel/guide module.
- “Assembly/disassembly of guide module transport lock (steady with material passage 26 mm)” on page 20,
 - “Assembly/disassembly of guide module transport lock (steady with material passage 38 mm)” on page 21.

- 14.** ▶ Loosen the anchors on the floor.

➔ The loading magazine is ready for transportation.

Transport beams



Two transport beams **1** have to be attached to the loading magazine. The attachment points for the transport beams **1** are on the underside of the loading magazine.

Assembling the transport beams

⚠ DANGER

Falling loading magazine

Personal injury due to squashing and impact by the falling loading magazine.

If the transport beams are attached improperly to the loading magazine, they might come loose or the screw connections might break.

- Observe the description about the assembly of transport beams in the operating instructions.

⚠ DANGER

Falling transport beams

Personal injury due to squashing and impact by the falling transport beams.

If the raising of the loading magazine is not done by the transport beam, there is a danger that it might fall down if mounted improperly and hit people.


- Do not stay in the danger area.
- Only install transport beams for the purpose of crane transportation and then remove them directly.

⚠ CAUTION


Protruding transport beams

Personal injury because of impact due to protruding transport beams.

- Remove the transport beams after the loading magazine has been transported.



1. ➤ Place the transport beam **1** on the threaded bolt.
2. ➤ Insert and tighten the nuts **2**.




3. ➤ From length version 6200: Insert and tighten the screws **3** additionally.


Information about the length versions: ➤ *"Name plate"* on page 8.

4. ➤ Assemble the second transport beam in the same way.

Removing the transport beams



1. ➤ Loosen and remove the nuts **2**.




2. ➤ From length version 6200: Loosen and remove the screws **3**.
3. ➤ Remove the transport beam **1**.
4. ➤ Remove the second transport beam in the same way.

Assembly/disassembly of guide module transport lock (steady with material passage 26 mm)



The described procedure refers to the steady with a material passage of up to 26 mm.

Assembly:



1. ➤ Loosen the lock nuts **2**.
2. ➤ Insert the transport lock **1** in the direction of the arrow.
3. ➤ Tighten the lock nuts **2**.
4. ➤ Insert and tighten the screws **4**.

Disassembly:


➤ Disassemble in reverse order.

Assembly/disassembly of guide module transport lock (steady with material passage 38 mm)




The described procedure refers to the steady with a material passage of up to 38 mm.

Assembly:



1. ➤ Loosen and remove the screws **1**.
2. ➤ Remove the lid **2**.



3. ➤ Position the transport lock **3**.
4. ➤ Insert and tighten the screws **4**.

Disassembly:

➤ Disassemble in reverse order.

Angle of inclination of the load attachment gear

⚠ DANGER


Falling loading magazine

Personal injury due to crushing and impact by the falling loading magazine.



When lifting the loading magazine with the multi-chain load attachment gear, the specified maximum angle of the load attachment gear has to be observed. If this angle is exceeded, the attachments of the transport beams may break and the loading magazine could fall down.

- Observe the specified maximum angle of inclination of the load attachment gear.

When using the multi-chain load attachment gear, the load attachment gear chosen must not exceed the angle of inclination of **A** 40°. Greater angles of inclination generate transverse forces that are beyond the rating of the attachment of the transport beams.



Detaching the loading magazine from the transport pallet



1. Secure the loading magazine to prevent tipping over.
2. Loosen and remove the screws in the attachment holes **3** of the support **4**.
3. Loosen the rest of the supports from the transport pallet in the same way.
4. Using a crane, raise the loading magazine **1** from the transport pallet **2** and set down safely ➔ *“Transporting the loading magazine using the crane” on page 23.*

1. Detach the oil tank from the transport pallet.
2. Lift the oil tank off the transport pallet using a suitable hoist.

Fastening the loading magazine to the transport pallet

i Fastening the loading magazine to the transport pallet serves only to prevent it from slipping or to raise the loading magazine and transport pallet over the transport beams of the loading magazine. For transportation, the loading magazine has to be additionally secured. Fastening it to the transport pallet is not sufficient.

i The loading magazine must be fastened to the transport pallet using adequately dimensioned fasteners.



➔ Pay attention to the weight of the transport pallet in the technical data. ➔ “Technical data of the loading magazine” on page 12.

1. ➔ Place the oil tank on the transport pallet using a suitable hoist.

2. ➔ Secure the oil tank to prevent it from slipping.

1. ➔ Raise the loading magazine **1** onto the transport pallet **2** using a crane. ➔ “Transporting the loading magazine using the crane” on page 23.

2. ➔ Secure the loading magazine to prevent tipping over.



3. ➔ Drill through the attachment holes **3** in the transport pallet.

4. ➔ Insert the screws and washers through the attachment holes **3** of the support **4**.

5. ➔ Attach and tighten the washers and nuts from the other side.

6. ➔ Fasten the rest of the supports to the transport pallet in the same way.

3.2 Transporting the product

Transporting the loading magazine using the crane

If the loading magazine is hoisted with the transport pallet, it must be ensured that the attachment screws of the pallet are adequately dimensioned to prevent the pallet coming loose from the loading magazine.

⚠ DANGER

Falling loading magazine

Personal injury due to squashing and impact by the falling loading magazine.

- Do not stay in the danger area.
- Use hoisting equipment suitable for the weight of the loading magazine.
- Observe the weight of the loading magazine and, where applicable, the transport pallet in the technical data.
- Only hoist the loading magazine using a crane via the transport beams.
- Observe the description on hoisting the loading magazine in the operating instructions.

⚠ DANGER

Falling transport pallets / Loose loading magazine

Personal injury due to squashing and impact as a result of a falling transport pallet.

If the loading magazine is secured insufficiently or incorrectly to the transport palette, this may come loose. The transport pallet may fall down. The loading magazine may be knocked over and fall down.

- Do not stay in the danger area.
- Observe the description about the correct attachment of the loading magazine to the transport pallet in the operating instructions.

⚠ DANGER

Falling control cabinet

Personal injury due to squashing and impact by the falling control cabinet.

- Do not stay in the danger area.
- Observe the description on securing the control cabinet in the operating instructions.

⚠ DANGER

Falling oil tank

Personal injury due to squashing and impact by the falling oil tank.

- Do not stay in the danger area.
- Secure the oil tank on the transport pallet against slipping.



1. ➤ Assembling the transport beams ➔ *“Assembling the transport beams” on page 19.*
2. ➤ Fasten suitable hoists to all four eyebolts **1** of the transport beam.
3. ➤ Hoist the loading magazine and set it down securely.
4. ➤ Remove the hoists from the eyebolts **1** of the transport beams.
5. ➤ Remove the transport beams again after the loading magazine has been set down ➔ *“Removing the transport beams” on page 20.*

Transporting the loading magazine using the fork-lift truck

DANGER

Falling loading magazine

Personal injury due to squashing and impact by the falling loading magazine.

- Do not stay in the danger area.
- Only hoist the loading magazine on a transport pallet using a fork-lift truck.
- Observe the description on the correct attachment of the loading magazine to the transport pallet in the operating instructions.
- Pay attention to the centre of gravity when hoisting with the fork-lift truck.
- Observe the weight of the loading magazine and, where applicable, the transport pallet in the technical data.

DANGER

Falling transport pallets / Loose loading magazine

Personal injury due to squashing and impact as a result of a falling transport pallet.

If the loading magazine is secured insufficiently or incorrectly to the transport pallet, this may come loose. The transport pallet may fall down. The loading magazine may be knocked over and fall down.

- Do not stay in the danger area.
- Observe the description about the correct attachment of the loading magazine to the transport pallet in the operating instructions.

DANGER

Falling control cabinet

Personal injury due to squashing and impact by the falling control cabinet.

- Do not stay in the danger area.
- Observe the description on securing the control cabinet in the operating instructions.

DANGER

Falling oil tank

Personal injury due to squashing and impact by the falling oil tank.



- Do not stay in the danger area.
 - Secure the oil tank on the transport pallet against slipping.
1.  Fasten the loading magazine to a transport pallet ➔ *“Fastening the loading magazine to the transport pallet” on page 23.*
 2.  Calculate the center of gravity of the load.
 3.  Place the forks of the fork-lift truck beneath the center of gravity of the load.
 4.  Hoist the transport pallet with the loading magazine and set it down securely.
 5.  Detach the loading magazine from the transport pallet ➔ *“Detaching the loading magazine from the transport pallet” on page 22.*

Transport the loading magazine with means of transportation



When transporting the loading magazine with means of transportation such as a truck, it is necessary to attach the loading magazine to a transport pallet ➔ *“Fastening the loading magazine to the transport pallet” on page 23*. The unit consisting of the transport pallet and the loading magazine must also be secured via the transport beams of the loading magazine to the floor of the means of transport, strapped diagonally. ➔ *“Attach the loading magazine to the means of transport” on page 26*.

Attach the loading magazine to the means of transport



1. ➔ Attach the loading magazine to a transport pallet ➔ *“Fastening the loading magazine to the transport pallet” on page 23*.
2. ➔ Attach suitable fasteners [1] to the end stop of the transport beams [2].
3. ➔ Raise the loading magazine and the transport pallet with a crane or fork-lift truck onto the means of transport ➔ *“Transporting the loading magazine using the crane” on page 23* or ➔ *“Transporting the loading magazine using the fork-lift truck” on page 25*.
4. ➔ Strap the loading magazine diagonally using suitable fasteners [1] to the floor of the means of transport [3].
5. ➔ Attach the opposite side of the loading magazine in the same way.

4 Assembly and start-up

4.1 Prepare for assembly

Assembly requirements

NOTICE

Damage to the floor

The floor on which the product is placed, must be designed to bear the loads. Non observance can lead to material damage.

- Have the suitability of the floor checked by an expert.

NOTICE

Damage to wires in the floor

When selecting the place to set the product down, you must make sure that there are no wires in the floor in the area under the product. They could be damaged when securing the product.

- Have the suitability of the installation location checked by an expert.

Delivery state

The loading magazine and all add-on parts and equipment are delivered together on a transport pallet. The entire consignment is covered with a protective film to prevent coarse contamination.

- The loading magazine is screwed to the transport pallet.
- The add-on set for fastening the loading magazine to the floor is packed and stored in the remnant bin.
- The adapter set is packed and stored in the remnant bin.
- Depending on the equipment, further equipment parts such as the telescopic tube set, steady, lathe, capacity adjustment set or lacquered parts are also supplied. They are all packed on the carton and secured to prevent them from slipping on the transport pallet.

Unpacking the product

Check the delivery:

1. ➤ Remove the protective film.
2. ➤ Remove the add-on parts and equipment from the transport pallet.
3. ➤ Take the add-on parts and equipment out of the remnant bin.
4. ➤ Unpack the add-on parts and equipment.
5. ➤ Check the delivery to make sure it is complete.

Detach the consignment from the transport pallet:

5. ➤ Detach the loading magazine from the transport pallet.
➤ *“Detaching the loading magazine from the transport pallet” on page 22.*

4.2 Aligning

Calculate the distance of the loading magazine from the machine tool

Attachment to machine tools with moving headstock:

1. ➤ Set up the loading magazine on the machine tool. ➔ *"Setting up the loading magazine" on page 28.*
2. ➤ Calculate the distance from the loading magazine to the machine tool using the order-specific adapter diagram.
3. ➤ Adjust the distance.

Setting up the loading magazine

⚠ DANGER

Falling loading magazine

Personal injury due to squashing and impact by the falling loading magazine.

The loading magazine has a high centre of gravity. When aligning the loading magazine there is a danger of it tipping over.

- Do not stay in the danger area.
- Observe the description on aligning and setting up the loading magazine in the operating instructions.

⚠ DANGER

Moving the whole loading magazine during set-up

Personal injury due to squashing or impact due to moving the whole loading magazine.


When setting up and aligning the loading magazine, the whole loading magazine has to be moved. People may be struck by the loading magazine or become stuck between the loading magazine and the lathe.

- Do not stay in the danger area.

For alignment, the loading magazine with the supports is placed on round material bars (diameter 18 mm - 22 mm).



1. ➤ Position the round material bars **1** so that the loading magazine is as close as possible to the lathe.
2. ➤ Hoist the loading magazine using suitable equipment and together with the supports **2** place it on the round material bars **1**.
3. ➤ Align the middle of the loading magazine roughly so that the side faces the lathe spindle.
4. ➤ Calculate the distance between the loading magazine and the lathe. ➔ *"Calculate the distance of the loading magazine from the machine tool" on page 28.*
5. ➤ Move the loading magazine along the round material bars and create the calculated distance to the lathe.



6. ➔ Position the foot plates **3** beneath the threaded pins **4**.
7. ➔ Turn the threaded pins **4** to the right until the round material bars **5** are free.
8. ➔ Tighten the **6** nuts.
9. ➔ Remove the **5** round material bars.

4.3 Electrical connection

Electrical connection of the loading magazine and lathe

The electrical connection between the loading magazine and the lathe is shown in the order-specific electrical documents. The order-specific electrical documents are contained in the technical documentation of the product. The configuration of the plug and the operating voltage of the loading magazine are determined by the lathe. The configuration of the plug is done by FMB at the factory and is completed upon delivery. The contacts are configured according to the table below and have to be checked when starting up the loading magazine. If the contacts are not configured as described in the tables, please contact FMB.

- Contacts from the loading magazine to the lathe: ➔ *“Contacts from the loading magazine to the machine tool” on page 29*
- Contacts from the lathe to the loading magazine: ➔ *“Contacts from the machine tool to the loading magazine” on page 30*

Contacts from the loading magazine to the machine tool

Name	Explanation
-K30	Contact closed >> No fault reported by the loading magazine Contact open >> The loading magazine reports a fault In the event of a fault, the spindle of the tool machine can no longer turn
-K1	The material bar is pushed into the machine tool or Input release, Program - Start This signal is emitted, depending on the machine tool control system, as an impulse or permanent contact.
-K9	This signal indicates to the machine tool that the material bar has been processed. This signal is emitted, depending on the machine tool control system, as a normally closed or normally open contact.
-K91 (optional)	When working with two different part lengths, this signal is emitted when the bar end of the longer part Part length 1 is reached.
-K90	Contact closed >> The loading magazine is in automatic mode
-K44	This signal is emitted after the execution of the part length feed and continues until the moving signal (collet open) is removed. The signal is only emitted in the following cases: Operating mode Part length internal , Part length external and Collet open, fixed speed .

Name	Explanation
Loading magazine emergency stop	Potential-free contact of the loading magazine. This contact is to be included in the emergency-stop circuit of the machine tool.

Contacts from the machine tool to the loading magazine

Signal from the machine tool	Loading magazine action
Collet open	The feed equipment of the loading magazine is switched on.
End of cycle, start bar change	On machine tools with a program skip in the bar starting program, the contact must be queued in front of "collet open". Contact triggers a bar change on the loading magazine.
Machine tool ready for operation, enable automatic mode	The loading magazine can be switched to automatic mode (for this to happen, this contact must be active).
Loading magazine on (option)	Contact starts automatic mode of the loading magazine.
Safety door closed	The feed movement through the loading magazine is executed only if this contact is active.
Follow-up with sub-spindle (optional)	M-command from the machine tool. If this signal is emitted before the collet is opened (push command), the next follow-up is converted from Part length internal , Part length external , to Part follow-up with sub-spindle .
Emergency stop of the machine tool	Potential-free contact of the lathe. This contact is included in the emergency-stop circuit of the loading magazine.

4.4 Assembly

Establish the power supply to the loading magazine

 **DANGER**

Live components of the control cabinet

Personal injury by electrical shock due to contact with live components of the control cabinet.

This work is only allowed to be performed by a qualified electrician.

- Turn off the machine tool before starting work on the main switch.

 **DANGER**


Damaged wires or plugs

Personal injury by electric shock due to damaged wires or plug-in connections.

- Perform a visual check of wires and plug-in connections for damage before inserting them into the control cabinet.

The main power supply of the loading magazine is connected to the loading magazine and attached to the front of the loading magazine.


1. ➤ Turn off the machine tool before starting work on the main switch.
2. ➤ Check the electrical connection of the loading magazine and lathe. ➤ *“Electrical connection of the loading magazine and lathe” on page 29*
3. ➤ Insert the main power supply cable of the loading magazine into the control cabinet of the lathe.
4. ➤ Check the input voltage of the loading magazine.
5. ➤ Insert the connecting pipe for the compressed air supply to the loading magazine into the maintenance unit **1**.



Setting the supply of compressed air



Values for the supply of compressed air: ➤ “Technical data of the loading magazine” on page 12.



1. ➤ Switch off the supply of compressed air on/off at the knob **1**.
2. ➤ Set the supply of compressed air at the control unit **2**.
3. ➤ Check the compressed air supply on the display **3**.

Aligning the loading magazine

⚠ DANGER

Falling loading magazine

Personal injury due to squashing and impact by the falling loading magazine.

The loading magazine has a high centre of gravity. When aligning the loading magazine there is a danger of it tipping over.

- Do not stay in the danger area.
- Observe the description on aligning and setting up the loading magazine in the operating instructions.

⚠ DANGER

Moving pusher without protective equipment

Personal injury due to squashing and impact because of work on an unsecured pusher.

When aligning the loading magazine, it is necessary for technical reasons to move the pusher without the intended protective equipment. The danger area is not covered during this process. The moving pusher may catch extremities or people.

- Do not stay in the danger area.

⚠ CAUTION

Sharp knives of the material gripper


Cuts due to the sharp knives of the material gripper.

When working in the vicinity of the material gripper, there is a risk of cuts in the event of inattentiveness.


- Wear safety gloves.

➔ The centering hole on the pusher of the loading magazine must align with the lathe spindle. Set and verify the alignment with an optical alignment aid. In the event of questions about this please contact FMB. ➔ *"Service contact details" on page 119.*

Correcting the height (roughly):



- ➔ Loosen the clamping screws [4].




- ➔ Loosen the lock nuts [5] of the threaded spindles [6].
- ➔ Correct the height of the loading magazine with the threaded spindles [6].
- ➔ Tighten the lock nuts [5] of the threaded spindles [6].
- ➔ Tighten the clamping screws [4].



Correcting the position:

- ➔ Loosen the lock nuts [7] of the threaded pins [8].
- ➔ Correct the position of the loading magazine by adjusting the threaded pins [8].
- ➔ Tighten the lock nuts [7] of the threaded pins [8].

Correcting the lateral position:



1. ➤ Apply the lever (e.g. crowbar) at the lifting points **9** and correct the side position.
2. ➤ Remove the optical alignment aids again.


Attaching the loading magazine to the floor

i

The number of attachment points to be used depends on the condition of the floor and the equipment of the loading magazine. In the event of uncertainty, please consult FMB.

i

To attach the loading magazine to the floor, appropriately designed drop-in anchors or adhesive anchors must be used. In the event of uncertainty, please consult FMB.



1. ➤ Aligning the loading magazine ➤ "Aligning the loading magazine" on page 31.
2. ➤ Drill the floor holes through the attachment points **1**.
3. ➤ Fix attachment aids to the floor hole.
4. ➤ Screw the nuts to the attachment aid and tighten.

Attachment to machine tool

⚠ DANGER

Moving components of the loading magazine and the machine tool

Personal injury due to crushing, impact or entanglement by movements of the loading magazine and the machine tool.

When working on the unsecured interface (connection between loading magazine and machine tool released), the extremities may become trapped or entangled by the moving components of the loading magazine or machine tool.

- Turn off the machine tool before starting work on the main switch.

⚠ WARNING

Movement of the guide channel during assembly

Personal injury from crushing of upper limbs due to loose guide channel.

During commissioning, the movable guide channel is detached from the headstock of the lathe. This allows the movable guide channel to move freely. The high dead weight of the movable guide channel can present hazards for the operator.

- Be aware that the guide channel is detached during assembly.

⚠ CAUTION

Falling add-on parts

Personal injury due to squashing and impact by the falling add-on parts.

When setting up the loading magazine, various add-on parts have to be mounted at the interface between the loading magazine and the machine tool. They might fall down and hit body extremities.

- Raise and secure add-on parts with suitable hoisting equipment.

The attachment of the loading magazine to the machine tool is order-specific and dependent on the individual design of the interface between the loading magazine and the machine tool. Refer to the adapter set/attachment diagram for the precise procedure.

➔ "Other applicable documents" on page 5.

If you have any questions about how the loading magazine is attached to the machine tool, please contact FMB. ➔ "Service contact details" on page 119.


Removing the control cabinet from /
attaching the control cabinet to the
loading magazine

⚠ CAUTION


Falling control cabinet

Personal injury due to squashing and impact by the falling control cabinet.


- Observe the description on removing and fastening the control cabinet from the loading magazine in the operating instructions.



1. ➔ Support the control cabinet [1] using suitable hoisting equipment [2].



2. ➔ Loosen the screws [3].



3. ➤ Shift the control cabinet in the direction indicated by the arrow and unhinge.
4. ➤ Lower the control cabinet and place it on the floor.
5. ➤ Attach the control cabinet to the loading magazine in reverse order.

Setting up and connecting the oil tank

⚠ DANGER


Damaged wires or plugs

Personal injury by electric shock due to damaged wires or plug-in connections.

- Perform a visual check of wires and plug-in connections for damage before inserting them into the control cabinet.


1. ➤ Turn off the machine tool before starting work on the main switch.

2. ➤ Place the oil tank **1** below the oil return pipe **2** using suitable hoisting equipment.



3. ➤ Connect the pump outlet **3** and the oil feed **4** to the oil feed line.

4. ➤ Secure the oil feed line outlet **3** and the oil feed **4** with tube clips.



5. ➤ Guide the oil return line into the oil return hole **5**.

6. ➤ Insert the remaining end of the oil return line into the oil return outlet **2**.

7. ➤ Secure the oil return line onto the oil return outlet **2** using a tube clip.

8. ➤ Insert the plug of the oil pump into the control cabinet (the socket is located outside the control cabinet) of the loading magazine.

9. ➤ Fill the oil tank. ➔ "Filling the oil tank of the loading magazine" on page 110.



4.5 Adjustments

Positional values to be set

During start-up, positional values have to be set once for the parameter settings. This concerns certain positions, which can only be calculated from the perspective of the whole system (the loading magazine installed on a lathe).

The following positional values have to be set:

- First insert travel
- Position front limit

Determining value for First insert travel



If the loading magazine is attached to the machine tool, which can be operated in the fixed headstock turning mode and sliding headstock turning mode, a separate value must be determined for each mode. In Settings, there is then a field for each mode (sliding headstock turning, fixed headstock turning).

1. Load a short material bar (approx. 1 m) ➔ "Draw off remnant, eject it and draw on the new material bar" on page 70.
2. Press the button.
3. **SETUP** Open .
4. Move the end of the material bar on the lathe side to the starting switch using the button.
5. Check and note the current position on the control panel.
6. **On lathes with a moving headstock:** Move the end of the material bar on the lathe side through the collet of the lathe until just before the guide sleeve of the lathe using the button.

i The position "just before the guide sleeve" has to be clarified, if necessary with FMB or with the lathe manufacturer.
7. **On lathes with a fixed headstock:** Move the end of the material bar on the lathe side through the collet of the lathe up to the cut-off position using the button.
8. Check and note the current position on the control panel.
9. Deduct the first position from the second position.
10. *i The result is the value for the **First insert travel**.*
11. Press the button.
12. **'SETTINGS' → Service settings → Position'**
13. Tap the **First insert travel** field.
➔ An input window opens.
14. Enter value for **First insert travel** .
➔ The value for **First insert travel** is determined.

Determining value for Position front limit



If the loading magazine is attached to the machine tool, which can be operated in the fixed headstock turning mode and sliding headstock turning mode, a separate value must be determined for each mode. In Settings, there is then a field for each mode (sliding headstock turning, fixed headstock turning).

1. ➤ **Only for lathes with a moving headstock:** Move the headstock of the spindle towards the guide sleeve to the end position.
2. ➤ Close the collet of the lathe.
3. ➤ Press the button.
4. ➤ **SETUP** Open .
5. ➤ Move the pusher with the clamping sleeve towards the lathe using the button until the clamping sleeve of the loading magazine is queued on the collet of the lathe.
6. ➤ Press the button.
7. ➤ **'SETTINGS → Service settings → Position'**
8. ➤ Tap the **Position front limit** field.
 - ➔ An input window opens.
9. ➤ Enter the recorded value, minus the safety distance of 5 mm for **Position front limit** .
 - ➔ The value for **Position front limit** is determined.

4.6 Settings

Distanceview

Distanceview is a display on the control panel, which is active after a pre-set time and is ended by pressing the touchscreen. On the Distanceview display, only the information relevant for production is shown on an enlarged display. This makes it possible to see the current statuses of the loading magazine, even from a distance.

Set the Distanceview



The display Distanceview is active, if the touchscreen is not pressed within the pre-set time. The time is set in seconds. If the time has been set to "0", the function is deactivated.

1. ➤ Press the button.
2. ➤ **'SETTINGS → System settings'**
3. ➤ Click on the field **TIME DISTANCEVIEW**.
 - ➔ An input field opens.
4. ➤ Enter the value for the activation of the display.
 - ➔ Distanceview has been set and is active after the expiry of the entered time.

Set the date and time

1. ➤ Press the button.

2. 'SETTINGS → System settings'
3. Click on the field SET DATE.
➔ An input field opens.
4. Enter the current date.
5. Click on the field SET TIME.
➔ An input field opens.
6. Enter the current time.

Changing language settings

1. Press the button.
2. 'SETTINGS → System settings'
3. Click on the respective language.

Set the unit of measure

1. Press the button.
2. 'SETTINGS → System settings'
3. Click on the respective unit of measure in the field UNIT OF MEASURE.
➔ The status display on the button turns green. The unit of measure has been set.

Setting the oil feed



The setting of the oil feed must be done during operation for rotating material bars.

1. Set the ball value on the oil pump to "off".
2. Open the ball valve slowly, until the material bar runs slowly.
➔ The oil feed has been set.

Position oilpump on / Position oilpump off Setting



The oil pump keeps the oil flowing in the guide channel. The flow of oil is necessary to guide the material bar optimally in the guide channel of the loading magazine. If the end of the material bar is in the transition section from the guide channel to the spindle of the lathe, the oil pump can be switched off. This prevents oil getting into the working area of the lathe.



On loading magazines with an active synchronization clutch, the "Position oilpump off" position is controlled automatically.

1. Press the button.
2. 'SETTINGS → Basic settings → Parameter'
3. Tap the Position oilpump on field.
➔ An input field opens.

4. ➤ Enter value for Position oilpump on .
5. ➤ Tap the **Position oilpump off** field.
 - ➡ An input field opens.
6. ➤ Enter value for Position oilpump off .

4.7 Pre-set parameters

Pusher length Entering



Information about **Pusher length**: ➡ “Positions and traverse paths” on page 11.



This value is pre-set by the FMB. If necessary, the value can be adjusted.

1. ➤ Press the button.
2. ➤ ‘**SETTINGS** → **Service settings** → **Position**’
3. ➤ Tap the **Pusher length** field.
 - ➡ An input field opens.
4. ➤ Enter the value for Pusher length .

Position storage Entering



Information about **Position storage**: ➡ “Positions and traverse paths” on page 11.



This value is pre-set by the FMB. If necessary, the value can be adjusted.

1. ➤ Press the button.
2. ➤ ‘**SETTINGS** → **Service settings** → **Position**’
3. ➤ Tap the **Position storage** field.
 - ➡ An input field opens.
4. ➤ Enter the value for Position storage .

Speed Acceleration Short pusher forward Entering



The value **Speed Acceleration Short pusher forward** describes the speed at which the pusher moves to the **Position storage** value to pick up the material bar and push it into the area of the material gripper.

1. ➤ Press the button.
2. ➤ ‘**SETTINGS** → **Service settings** → **Speed**’
3. ➤ Scroll to the next page using the button.
4. ➤ Tap the **Speed Acceleration Short pusher forward** field.
 - ➡ An input field opens.
5. ➤ Enter the value for Speed Acceleration Short pusher forward .

Limit pos. short pusher front Entering



Information about **Limit pos. short pusher front** see: ➔ "Positions and traverse paths" on page 11.

1. ➔ Press the button.
2. ➔ '**SETTINGS** → **Service settings** → **Position**'
3. ➔ Tap the **Limit pos. short pusher front** field.
➔ An input field opens.
4. ➔ Enter the value for Limit pos. short pusher front .

Enter Speed First insert low



The value **Speed First insert low** describes the speed at which the pusher moves to the **Position front limit** position.



This value is pre-set by the FMB. If necessary, the value can be adjusted.

1. ➔ Press the button.
2. ➔ '**SETTINGS** → **Service settings** → **Speed**'
3. ➔ Click on the field **Speed First insert low**.
➔ An input field opens.
4. ➔ Enter the value for Speed First insert low.

Enter Position open steady



Information about **Position open steady**: ➔ "Positions and traverse paths" on page 11.



This value is pre-set by the FMB. If necessary, the value can be adjusted.

1. ➔ Press the button.
2. ➔ '**SETTINGS** → **Service settings** → **Position**'
3. ➔ Click on the field **Position open steady**.
➔ An input field opens.
4. ➔ Enter the value for Position open steady.

Enter Position close steady



Information about **Position close steady**: ➔ "Positions and traverse paths" on page 11.



This value is pre-set by the FMB. If necessary, the value can be adjusted.

1. ➔ Press the button.
2. ➔ '**SETTINGS** → **Service settings** → **Position**'

3. ➤ Click on the field **Position close steady**.
➡ An input field opens.
4. ➤ Enter the value for Position close steady.

Enter the Speed Return from spindle



The value **Speed Return from spindle** describes the slower of the two speeds of the pusher when retracting. This is used if the pusher is in the area of the machine tool spindle.



This value is pre-set by the FMB. If necessary, the value can be adjusted.

1. ➤ Press the button.
2. ➤ **'SETTINGS → Service settings → Speed'**
3. ➤ Click on the field **Speed Return from spindle**.
➡ An input field opens.
4. ➤ Enter the value for Speed Return from spindle.

Enter the Pos. reverse rotation return



At the **Pos. reverse rotation return** position the speed of the pusher when returning out of the machine tool spindle is switched from **Speed Return from spindle** to the higher **Speed Return high**.



This value is pre-set by the FMB. If necessary, the value can be adjusted.

1. ➤ Press the button.
2. ➤ **'SETTINGS → Basic settings → Parameter'**
3. ➤ Click on the field **Pos. reverse rotation return**.
➡ An input field opens.
4. ➤ Enter the value for Pos. reverse rotation return.

Enter the Speed Return high



The value **Speed Return high** describes the faster of the two speeds of the pusher when retracting. This is used if the pusher is no longer in the area of the machine tool spindle.



This value is pre-set by the FMB. If necessary, the value can be adjusted.

1. ➤ Press the button.
2. ➤ **'SETTINGS → Service settings → Speed'**
3. ➤ Click on the field **Speed Return high**.
➡ An input field opens.
4. ➤ Enter the value for Speed Return high.

Enter the Position draw off



Information about **Position draw off**: ➔ “Positions and traverse paths” on page 11.



This value is pre-set by the FMB. If necessary, the value can be adjusted.

1. ➔ Press the button.
2. ➔ ‘**SETTINGS** → **Service settings** → **Position**’
3. ➔ Click on the field **Position draw off**.
 - ➔ An input field opens.
4. ➔ Enter the value for Position draw off.

Set the Collet Signal



This function is available as an option.



This value is pre-set by the FMB. If necessary, the value can be adjusted.

1. ➔ Press the button.
2. ➔ ‘**SETTINGS** → **Service settings** → **Mode**’
3. ➔ Click on the field **Collet Signal**.
 - ➔ A selection window opens.
4. ➔ Click on the respective selection.
 - ➔ The chosen selection is shown in the field.

Set the Feed Stop Signal



This function is available as an option.



This value is pre-set by the FMB. If necessary, the value can be adjusted.

1. ➔ Press the button.
2. ➔ ‘**SETTINGS** → **Service settings** → **Mode**’
3. ➔ Click on the field **Feed Stop Signal**.
 - ➔ A selection window opens.
4. ➔ Click on the respective selection.
 - ➔ The chosen selection is shown in the field.

Length of guide module Entering



This value is pre-set by the FMB.

1. ➔ Press the button.
2. ➔ ‘**SETTINGS** → **Basic settings** → **Parameter**’

3. ➤ Tap the **Length of guide module** field.
 - ➡ An input field opens.
4. ➤ Enter the value for Length of guide module .


5 Control panel

5.1 Control panel, general

Layout

The control panel has a touchscreen, which is operated by touching it with a finger.

The upper, darker area of the screen provides information about the current statuses of the loading magazine and is visible in every menu. On the lower part of the screen the different menus are shown.



1	Display of the current material bar length
2	Number of possible parts
3	Display of the current position
4	Fault message display
5	Visualization of the current material bar length
6	Visualization of the current material bar length (enlarged image)
7	Display of the current status
8	Display of the loaded program
9	Product status (automatic mode)

Navigation

The contents of the control panel are split into several main menus. In the main menus you can reach the corresponding content page directly or via the sub-menus.

The way to reach the respective action in the control panel is described via a menu pathway in the guidelines of these operating instructions. The menu pathway shows the way via the menus to the content page which the action is on.

Example: *Main menu* → *Sub menu 1* → *Sub menu 2*

If you selected the last menu, you are directly on the content page on which the action occurs. The guidelines then indicate the field which should be worked on, or the button which should be pressed.

Example: Field *Click on the example* field.

Some pages contain more content that can be shown on one page of the control panel. In this case the described field or button may be on one of the following pages. To reach any following pages, you have to scroll through the content page. The fact that content may be located on following pages is not considered in the operating instructions.

Scroll through content pages: ➔ *“Scroll through content page” on page 45.*

Scroll through content page

Access the following page

➔ Access the following pages with .

Access the previous page

➔ Access the previous page with .

Explanation of symbols



*In the main menus **PRODUCTION** and **SETUP** there is a help page, which provides explanations of the symbols used.*

Explanation of symbols Main menu PRODUCTION

1. ➔ Press the  button.
2. ➔ Press **PRODUCTION**.
3. ➔ Press the  button.

Explanation of symbols Main menu SETUP

1. ➔ Press the  button.
2. ➔ Press **SETUP**.
3. ➔ Press the  button.

6 Operation

6.1 Basic functions

Press the emergency stop button



The emergency stop button is located on the control panel. Pressing the emergency-stop button switches the outputs of the PLC output card off. The drive of the loading magazine is shut down. An error message appears on the display of the control panel.



- ➔ Press the emergency stop button **1**.
- ➔ The loading magazine stops.

Make the loading magazine ready for operation after the emergency stop



1. ➔ Unlock the emergency stop button **1**.
2. ➔ Where necessary, cancel the emergency stop on the machine tool.
 - ➔ The loading magazine is ready for operation

Switch on the loading magazine

- ➔ Turn on the main switch of the machine tool.
 - ➔ The loading magazine is ready for operation.

Switch off the loading magazine



During active production, the production can be stopped after the end of the machine tool's cycle, and the whole system can be switched off. When the system is switched on again, the processing is continued from the same place.

- ➔ Turn off the main switch of the machine tool.
 - ➔ The loading magazine is switched off.

Parts counter

The parts counter counts the number of parts produced. If a target value is reached, the parts counter stops the production. Product can only be restarted if the actual value has been reset. The target value of the parts counter can be adjusted ➔ *"Set the parts counter" on page 47.*

Set the parts counter

i Once the target value has been reached, the parts counter stops production.

i Production can only be restarted, if the actual value of the parts counter has been reset ➔ *"Reset the actual value of the parts counter" on page 47.*

i Entering **Parts counter Desired** = "0" deactivates the parts counter.

1. ➔ Press the  button.
2. ➔ **'SETTINGS** ➔ **Basic settings** ➔ **Parts counter**
3. ➔ Click on the field **Parts counter Desired**.
 - ➔ An input field opens.
4. ➔ Enter the value for the target number of units.
 - ➔ The parts counter is activated with the entered target quantity.

Reset the actual value of the parts counter

1. ➔ Press the  button.
2. ➔ **'SETTINGS** ➔ **Basic settings** ➔ **Parts counter**
3. ➔ Click on the field **Reset parts counter**.
 - ➔ The parts counter is reset.

6.2 Overview of selections

Selections

Selections are available for the functions and components of the loading magazine with several respective selection options. They can be selected if required to adjust the operation of the loading magazine.

Part follow-up

Selection	Selection option	Description
Part follow-up		
	Collet open, fixed speed	Push to the stop.
	Part length internal	Push without stop to the specified position.

Selection	Selection option	Description
	Part length external (optional)	As Part length internal. Feed values are, however, provided by the lathe.
	Part length internal+w/o tension	Push without stop to the specified position. Once the push command has been removed, the system is depressurized.
	Part length external+w/o tension (optional)	As Part length internal. Feed values are, however, provided by the lathe. Once the push command has been removed, the system is depressurized.

Remnant gripper

Selection	Selection option	Description
Remnant gripper		
	Standard	The remnant is removed and falls into the remnant bin.
	Push forward	The remnant is removed and pushed forward by the pusher onto the remnant flap. Caution: In this operating mode the max. remnant length is 480 mm.

With / without gripper

i The selection *With / without gripper* allows the remnant to be removed from the working area of the lathe. For this purpose there are several operating modes available.

Selection	Selection option	Description
With / without gripper	with gripper	The material bar is clamped in a clamping sleeve on the loading magazine side. The remnant must be removed from the lathe side.
	without gripper	The material bar is moved by a centering sleeve on the loading magazine side. The material bar sits loosely in the centering sleeve. The remnant is pushed by the lathe spindle and removed from the working area of the lathe.
	without gripper with press upon	The material bar is clamped in a clamping sleeve on the loading magazine side. The remnant must be removed from the lathe side.

Selection	Selection option	Description
	with gripper with press upon + bar change	The material bar is clamped in a clamping sleeve on the loading magazine side. The remnant must be removed from the lathe side. During the processing of the last part a new material bar is loaded.

Interval insert



The interval insert improves the insertion of multi-sided material in the collet.

Selection	Selection option	Description
Interval insert	without return	Intermittent feed of short strokes.
	with return	Intermittent feed of short forward and backward strokes (recommended setting).

Steady

Selection	Selection option	Description
Steady		
	Steady roll. op. as push.pass.	During processing, the roller steady closes. When the pusher moves, the roller steady opens. As soon as the pusher is in the area of the roller steady, the roller steady remains open.
	Steady jaws op. as push.pass.	During processing, the jaw steady closes. When the pusher moves, the steady remains closed. As soon as the pusher is in the area of the jaw steady, the jaw steady remains open.
	Jaw steady closed when pushing	During processing, the jaw steady opens. When the pusher moves the jaw steady closes. As soon as the pusher is in the area of the jaw steady, the jaw steady remains open.
	R. steady on as pusher passes	During processing, the roller steady closes. When the pusher moves, the roller steady opens. As soon as the clamping sleeve of the pusher is in the area of the roller steady, the roller steady opens and remains open until the clamping sleeve is through the steady. After that, the roller steady closes during processing. When the pusher moves, the roller steady opens.

Selection	Selection option	Description
	J. steady on as pusher passes	During processing, the jaw steady closes. When the pusher moves, the jaw steady remains closed. As soon as the clamping sleeve of the pusher is in the area of the jaw steady, the jaw steady opens and remains open until the clamping sleeve is through the steady. The jaw steady then closes during processing. When the pusher moves, the jaw steady opens.

Mode sliding-fixed headstock



This selection is available only if the machine tool can be operated in both modes (Long turn and Short turn).

Selection	Selection option	Description
Mode sliding-fixed headstock		
	Long turn	The parameters "First insert sliding headstock turning" and "Position front end position sliding headstock turning" are used.
	Short turn	The parameters "First insert fixed headstock turning" and "Position front end position fixed headstock turning" are used.

First insert

Selection	Selection option	Description
First insert	Standard	The pusher moves to the First insert travel position.
	To stop	The pusher moves to the First insert travel position and then goes on to a stop in the lathe.

Draw on bar

Selection	Selection option	Description
Draw on bar	without first insert	The material bar is loaded and pressed.
	with first insert	The material bar is loaded and pressed. Then the pusher moves to the position end First insert.

Separation

Selection	Selection option	Description
Separation		
	with channel opened (standard)	The material bar is separated if the guide channel is open and rolls directly into the guide channel.
	with channel closed (special)	The material bar is separated if the guide channel is closed and is queued in the guide channel until it opens and then rolls inside.

Loading magazine



This function is available as an option.

Selection	Selection option	Description
Loading magazine	On	Normal work flow with the loading magazine.
	Off (chucker mode)	The loading magazine is switched off (collet mode).

6.3 Edit and manage programs

Program

Processing parameters are saved in the programs, which are valid for particular processing. During production, the program parameters of the loaded program are consulted.

For the creation of programs, a particular selection of program parameters is available, which can be set in the program editor. They are described under "Edit and manage programs".

➔ Chapter 6.3 "Edit and manage programs" on page 51.

In addition to the program parameters, general processing settings can be made which are not, however, saved in the programs. They are described under "Processing settings".

➔ Chapter 6.4 "Processing settings" on page 56.

Creating a new program

1. ➤ Press the button.
2. ➤ 'PROGRAM → NEW'
 - ➔ PROGRAM EDITOR opens.
3. ➤ Enter the program parameters.
4. ➤ Scroll to page 2 using the button.
5. ➤ Press the button.
6. ➤ Give the program a name.
7. ➤ Press the **NEW** button.
 - ➔ A new program is created.

Editing a program

1. ➤ Press the  button.
2. ➤ Select **PROGRAM**.
3. ➤ Click on the program to be edited in the list.
 - ➔ The selected program is marked blue.
4. ➤ Press **Edit**.
5. ➤ Enter the program parameters.
6. ➤ Press the  button.
7. ➤ Press the **Overwrite** button.
 - ➔ The changes are saved.

Load program



To use a program in automatic mode, it must be loaded.

1. ➤ Press the  button.
2. ➤ Select **PROGRAM**.
3. ➤ Click on the corresponding program in the list.
 - ➔ The selected program is marked blue.
4. ➤ Press **Open and load**.
 - ➔ The selected program is loaded and is used in automatic mode.

Enter the profile of the material bar

1. ➤ Open the program in the program editor. ➔ *“Creating a new program” on page 51 or ➔ “Editing a program” on page 52.*
2. ➤ Click on the field **Profile**.
 - ➔ A list of profiles opens.
3. ➤ Click on the profile to be processed.
4. ➤ Save changes with the  button.

Entering the material to be processed

1. ➤ Open the program in the program editor. ➔ *“Creating a new program” on page 51 or ➔ “Editing a program” on page 52.*
2. ➤ Click on the field **Material**.
 - ➔ An input field opens.
3. ➤ Enter the material to be processed.
4. ➤ Save changes with the  button.

Enter the diameter of the material bar to be processed

1. ➤ Open the program in the program editor. ➤ “Creating a new program” on page 51 or ➤ “Editing a program” on page 52.
2. ➤ Click on the field **Diameter**.
➤ An input field opens.
3. ➤ Enter the diameter to be processed.
4. ➤ Save changes with the  button.

Enter the Part length



*The length dimension of the part to be produced is recorded under **Part length**. This is used by the control unit to automatically calculate the possible number of parts to be manufactured.*

The length dimension of the part to be produced currently has to be adjusted.

1. ➤ Open the program in the program editor. ➤ “Creating a new program” on page 51 or ➤ “Editing a program” on page 52.
2. ➤ Click on the field **Part length 1**.
➤ An input field opens.
3. ➤ Enter the part length.
4. ➤ Save changes with the  button.

Enter the Feed force for part follow-up



*The **Feed force for part follow-up** is the force with which the pusher moves the material bar.*

This setting is also editable during production.

1. ➤ Open the program in the program editor. ➤ “Creating a new program” on page 51 or ➤ “Editing a program” on page 52.
2. ➤ Click on the field **Feed force**.
➤ An input field opens.
3. ➤ Enter the feed force.
4. ➤ Save changes with the  button.

Enter the Speed for part follow-up



*The **Speed for part follow-up** is the speed with which the pusher moves the material bar.*

1. ➤ Open the program in the program editor. ➤ “Creating a new program” on page 51 or ➤ “Editing a program” on page 52.
2. ➤ Click on the field **Speed**.
➤ An input field opens.
3. ➤ Enter the speed.

4. ➤ Save changes with the  button.

Enter the feed of the material bar



The pusher moves the material bar once per turned part by the set value in the working area of the lathe. The material bar is moved directly to the cut-off position.

1. ➤ Open the program in the program editor. ➤ “Creating a new program” on page 51 or ➤ “Editing a program” on page 52.
2. ➤ Click on the field **Feed 1**.
 - An input field opens.
3. ➤ Enter the feed of the material bar.
4. ➤ Save changes with the  button.

Set the Selection option Part follow-up

1. ➤ Open the program in the program editor. ➤ “Creating a new program” on page 51 or ➤ “Editing a program” on page 52.
2. ➤ Click on the field **Part follow-up**.
 - A selection window opens.
3. ➤ Click on the selection option.
 - The chosen selection option is shown in the field.
4. ➤ Save changes with the  button.

Set the Selection option First insert

1. ➤ Open the program in the program editor. ➤ “Creating a new program” on page 51 or ➤ “Editing a program” on page 52.
2. ➤ Click on the field **First insert**.
 - A selection window opens.
3. ➤ Click on the selection option.
 - The chosen selection option is shown in the field.
4. ➤ Save changes with the  button.

Enter Feed force for first insert



***Feed force for first insert** is the force with which the pusher moves a new material bar into the working area of the lathe.*



This value is pre-set by the FMB. If necessary, the value can be adjusted.

1. ➤ Open the program in the program editor. ➤ “Creating a new program” on page 51 or ➤ “Editing a program” on page 52.
2. ➤ Click on the field **Feed force for first insert**.
 - An input field opens.

3. ➤ Enter Feed force for first insert.
4. ➤ Save changes with the  button.

Enter Feed force for press upon



*The **Feed force for press upon** is the force with which the pusher presses the material bar against the clamping device.*



This value is pre-set by the FMB. If necessary, the value can be adjusted.

1. ➤ Open the program in the program editor. ➤ “Creating a new program” on page 51 or ➤ “Editing a program” on page 52.
2. ➤ Click on the field **Feed force for press upon**.
➤ An input field opens.
3. ➤ Enter Feed force for press upon.
4. ➤ Save changes with the  button.

Enter Extension first insert



*This function allows the extension of the **First insert travel**. The entered value is added to the **First insert travel** path.*



This value is set to "0" (off) by FMB. If necessary, the value can be adjusted.

1. ➤ Open the program in the program editor. ➤ “Creating a new program” on page 51 or ➤ “Editing a program” on page 52.
2. ➤ Click on the field **Extension first insert**.
➤ An input field opens.
3. ➤ Enter Extension first insert.
4. ➤ Save changes with the  button.

Enter Speed sub-spindle

1. ➤ Open the program in the program editor. ➤ “Creating a new program” on page 51 or ➤ “Editing a program” on page 52.
2. ➤ Click on the field **Speed sub-spindle**.
➤ An input field opens.
3. ➤ Enter Speed sub-spindle.
4. ➤ Save changes with the  button.

Enter Feed force for sub-spindle

1. ➤ Open the program in the program editor. ➤ “Creating a new program” on page 51 or ➤ “Editing a program” on page 52.
2. ➤ Click on the field **Feed force for sub-spindle**.
➤ An input field opens.

3. ➤ Enter Feed force for sub-spindle.
4. ➤ Save changes with the  button.

6.4 Processing settings

Enter the selection option

1. ➤ Press the  button.
2. ➤ 'SETTINGS → Basic settings → Selection option'
3. ➤ Click on the field with the corresponding selection.
 - ➔ A selection window opens.
4. ➤ Click on the selection option.
 - ➔ The chosen selection option is shown in the field.

Enter Speed First insert

i *Speed First insert is the speed with which the pusher moves a new material bar into the working area of the lathe.*

i *This value is pre-set by the FMB. If necessary, the value can be adjusted.*

1. ➤ Press the  button.
2. ➤ 'SETTINGS → Service settings → SPEED'
3. ➤ Click on the field **Speed First insert**.
 - ➔ An input field opens.
4. ➤ Enter the value for Speed First insert.

Correct. value after auto / door start enter

i *This function balances out minor position changes to the pusher, which may occur if the system is depressurized.*

When the material bar is clamped by the lathe collet, there may be a slight distortion, which is caused by the feed force of the pusher. If the system is switched from automatic to manual operation, or the working area of the lathe is opened, the drive of the loading magazine switches off. The pressure on the pusher reduces and the distortion disappears. This causes a slight change in position of the pusher, which can then be corrected by the entered value.

i *This value is set to "0" (off) by FMB. If necessary, the value can be adjusted.*

1. ➤ Press the  button.
2. ➤ 'SETTINGS → Basic settings → Parameter'
3. ➤ Tap the **Correct. value after auto / door start** field.
 - ➔ An input field opens.
4. ➤ Enter value for Correct. value after auto / door start .

Enter the Max. bar return

i *If the material bar is clamped by the lathe collet, the pusher may be pressed back. This function reports a fault if the pusher is pressed back by more than the set value.*

i *This value is set to "0" (off) by FMB. If necessary, the value can be adjusted.*

1. ➤ Press the  button.
2. ➤ 'SETTINGS → Basic settings → Parameter'
3. ➤ Click on the field Max. bar return.
➔ An input field opens.
4. ➤ Enter the value for Max. bar return.

Enter the Max. part length follow-up

i *This function monitors the insert travel when pushing the material bar. If the set value is exceeded when pushing the part length, the loading magazine reports a fault.*

i *This value is set to "0" (off) by FMB. If necessary, the value can be adjusted.*

1. ➤ Press the  button.
2. ➤ 'SETTINGS → Basic settings → Parameter'
3. ➤ Click on the field Max. part length follow-up.
➔ An input field opens.
4. ➤ Enter the value for Max. part length follow-up.

Enter the Min. part length follow-up

i *This function monitors the insert travel when pushing the material bar. If the set value is not reached when moving the part length, the loading magazine reports a fault.*

i *This value is set to "0" (off) by FMB. If necessary, the value can be adjusted.*

1. ➤ Press the  button.
2. ➤ 'SETTINGS → Basic settings → Parameter'
3. ➤ Click on the field Min. part length follow-up.
➔ An input field opens.
4. ➤ Enter the value for Min. part length follow-up.

Max. remnant length Entering

i *This function limits the length of the remnant to the entered value. If this value is exceeded, an error message is output.*



This value is set to "0" (off) by FMB. If necessary, the value can be adjusted.

1. ➤ Press the button.
2. ➤ 'SETTINGS' → Service settings → Position"
3. ➤ Tap the Max. remnant length field.
➔ An input field opens.
4. ➤ Determining the value for "Max. remnant length".

Enter the Collet open delay



This function delays the pushing of the material bar by the set value.



This value is set to "0" (off) by FMB. If necessary, the value can be adjusted.

1. ➤ Press the button.
2. ➤ 'SETTINGS' → Basic settings → Parameter"
3. ➤ Click on the field Collet open delay .
➔ An input field opens.
4. ➤ Enter the value for Collet open delay .

Enter the Collet close delay



This function delays the return of the material bar after being pushed by the set value. The pressure on the material bar is therefore maintained for longer.



This value is set to "0" (off) by FMB. If necessary, the value can be adjusted.

1. ➤ Press the button.
2. ➤ 'SETTINGS' → Basic settings → Parameter"
3. ➤ Click on the field Collet close delay .
➔ An input field opens.
4. ➤ Enter the value for Collet close delay.

Enter the Feed force for part follow-up with sub-spindle

1. ➤ Press the button.
2. ➤ 'SETTINGS' → Service settings → Feed"
3. ➤ Click on the field Feed force for part follow-up with sub-spindle.
➔ An input field opens.
4. ➤ Enter the value for Feed force for part follow-up with sub-spindle.

Enter the Speed for part follow-up sub-spindle

1. ➤ Press the  button.
2. ➤ 'SETTINGS → Service settings → Speed'
3. ➤ Click on the field Speed for part follow-up sub-spindle.
➔ An input field opens.
4. ➤ Enter the value for Speed for part follow-up sub-spindle.

Switching on/off the headstock position determination




This function is optional and is only available if the shaft encoder - B4 is installed.

1. ➤ Press the  button.
2. ➤ 'SETTINGS → Service settings → Mode'
3. ➤ Tap the Rotary encoder -B4 field.
➔ A selection window opens.
4. ➤ Tap on the selection option.
➔ The chosen selection option is shown in the field.

6.5 Clamp material bars

Requirements on the material bars




The smooth running of the material bar depends on the material and the precise geometric shape. Straightness, roundness and imbalance are key for the possible speed. The importance of the straightness increases as the diameter gets bigger. In general, a deviation in the straightness of more than 0.5 mm / m has a negative effect on the smooth running.

When measuring the straightness of the material bar proceed as shown in the following diagram. For the measurement, the material bar is rotated four times by 90°.

Requirements:

- The start of the material bar (on the lathe side) must be burr-free.
- The end of the material bar (on the loading magazine side) must not be bent or deformed.
- The material bar must be free of dirt.
- Bars with multiple sides must not have any circumferential chamfers on the lathe side.
- Material bars with a circular cross-section, whose diameter is closer to the pusher diameter, must be chamfered so that they can be inserted easier into the clamping sleeve.

Clamping device



A clamping device is attached to the pusher to guide the end of the material bar. Depending on the application, either a clamping sleeve, a centering sleeve or a clamping mandrel is necessary. The size of the clamping device depends on the diameter of the material bar to be processed.

Clamping sleeve: Material bars are pushed into the clamping sleeve and clamped by a frictional connection to the external diameter.

Clamping mandrel: Raw material is pushed to the clamping mandrel and clamped on the inner diameter by a frictional connection.

Centering sleeve: Material bars are pushed onto the disc of the centering sleeve and moved without voltage. The end of the material bar on the side of the loading magazine must have a centric chamfer. The chamfer must have minimum dimensions of 20% of the material bar diameter x 45° and a run-out accuracy of < 0.1 mm.

Changing the clamping device

⚠ WARNING

Falling material bar

Personal injury due to squashing and impact as a result of a falling material bar.

Material bars which are located on the lateral material storage, may fall down during conversion work.

- Before conversion work, remove the material bars from the lateral material storage.

⚠ CAUTION

Sharp knives of the material gripper

Cuts due to the sharp knives of the material gripper.

When working in the vicinity of the material gripper, there is a risk of cuts in the event of inattentiveness.

- Wear safety gloves.

⚠ CAUTION

Driven guide channel cover

Personal injury due to squashing and impact by the closing of the guide channel cover.

When working on the opened guide channel, the driven guide channel cover may squash extremities.

- Insert the safety bolts when working on the open guide channel. Observe the description in the operating instructions.



Clamping devices with a diameter < 25 mm are attached to the bearing insert with a cross pin.

Clamping devices with a diameter of 25 mm and above are attached to the bearing insert with three setscrews.

Clamping device with a diameter < 25 mm:

1. ➡ Press the  button.


2. ➤ **SETUP** Opening.
3. ➤ Move the pusher right to the back using the  button.
4. ➤ Swing out the pusher with the  button.
5. ➤ Press the emergency stop button. ➤ *“Press the emergency stop button” on page 46.*
6. ➤ Switch off the compressed air supply. ➤ *“Switch the supply of compressed air on/off” on page 112*
7. ➤ Where necessary, obtain release from the lathe to open the cover.
8. ➤ Open the cover.
9. ➤ Secure the guide channel with safety bolts. ➤ *“Securing the guide channel with safety bolts” on page 76*
10. ➤ Push the cross pin  out of the hole  in the direction indicated by the arrow.



11. ➤ Pull the clamping device  in the direction indicated by the arrow and take it out.
12. ➤ Mount and attach the clamping device in reverse order.
13. ➤ Remove the safety bolts in the guide channel.
14. ➤ Close the cover.
15. ➤ Switch on the compressed air supply. ➤ *“Switch the supply of compressed air on/off” on page 112*
16. ➤ Unlock the emergency stop button. ➤ *“Make the loading magazine ready for operation after the emergency stop” on page 46*
17. ➤ Swing in the pusher using the  button.
18. ➤ Acknowledge the error message using the  button.

Clamping device with a diameter of 25 mm and greater:

1. ➤ Press the  button.
2. ➤ **SETUP** Opening.
3. ➤ Move the pusher all the way to the back using the  button.
4. ➤ Swing out the pusher with the  button.
5. ➤ Press the emergency stop button. ➤ *“Press the emergency stop button” on page 46.*
6. ➤ Switch off the compressed air supply. ➤ *“Switch the supply of compressed air on/off” on page 112*
7. ➤ Where necessary, obtain release from the lathe to open the cover.



8. ➤ Open the cover.
9. ➤ Secure the rear guide channel with safety bolts. ➤ *“Securing the guide channel with safety bolts” on page 76*
10. ➤ Loosen the threaded pins **1** (3 pieces).
11. ➤ Pull the clamping device **2** in the direction indicated by the arrow and take it out.
12. ➤ Mount and attach the clamping device in reverse order.
13. ➤ Remove the safety bolts in the guide channel.
14. ➤ Close the cover.
15. ➤ Switch on the compressed air supply. ➤ *“Switch the supply of compressed air on/off” on page 112*
16. ➤ Unlock the emergency stop button. ➤ *“Make the loading magazine ready for operation after the emergency stop” on page 46*
17. ➤ Swing in the pusher using the  button.
18. ➤ Acknowledge the error message using the  button.

The material bar diameter is greater than the inner diameter of the clamping sleeve

To clamp material bars with a diameter which is greater than the inner diameter of the clamping sleeve, the end of the material bar has to be rotated. This is necessary, for example, to make full use of the nominal diameter of the capacity adjustment set.

Here the following applies:

- The diameter of the chamfer must be adjusted to the inner diameter of the clamping sleeve.
- The length of the chamfer must be adjusted to the clamping width of the clamping sleeves (the material bar must be moved up to the stop in the clamping sleeve).
- The chamfer must have a concentricity of < 0.1 mm.

6.6 Feed material bars

Push the part several times

The functions push part once, push part twice, and push part three times, allow the material bar to be pushed repeatedly within one machining cycle of the lathe. Entering the corresponding feed values allows the material bar to be pushed into different positions three times.

- Push part once: ➤ *“Set push part once:” on page 62*
- Push part twice: ➤ *“Set push part twice” on page 63*
- Push part three times: ➤ *“Set push part three times” on page 63*

Set push part once:



The pusher moves the material bar once per turned part in the working area of the lathe. The material bar is moved directly to the cut-off position.

1. ➤ Open the program in the program editor. ➤ “Creating a new program” on page 51 or ➤ “Editing a program” on page 52.
2. ➤ Set the option **Part follow-up** to selection option **Part length internal**. ➤ “Set the Selection option Part follow-up” on page 54 or ➤ “Enter the selection option” on page 56.
3. ➤ Click on the field **Feed 1**.
 - An input field opens.
4. ➤ Enter the length of the first processing.
5. ➤ Scroll to the next page using the  button.
6. ➤ Save changes.

Set push part twice



*The pusher moves the material bar twice per turned part in the working area of the lathe. The material bar is moved to for the first **Feed 1** machining operation. Then the material bar is moved to for the second **Feed 2** machining operation. At **Feed 2** the material bar is cut off.*

1. ➤ Open the program in the program editor. ➤ “Creating a new program” on page 51 or ➤ “Editing a program” on page 52.
2. ➤ Set selection **Part follow-up** to selection option **Part length internal** set. ➤ “Set the Selection option Part follow-up” on page 54 or ➤ “Enter the selection option” on page 56.
3. ➤ Tap the **Feed 1** field.
 - An input field opens.
4. ➤ Enter the length of the first machining operation.
5. ➤ Scroll to the next page using the  button.
6. ➤ Tap the **Feed 2** field.
 - An input field opens.
7. ➤ Enter the length of the second machining operation.
8. ➤ Save changes.

Set push part three times



*The pusher moves the material bar into the work area of the lathe three times per turned part. The material bar is moved to for the first **Feed 1** machining operation. Then the material bar is moved to for the second **Feed 2** machining operation. The material bar is now moved to for the third **Feed 3** machining operation. At **Feed 3** the material bar is cut off.*

1. ➤ Open the program in the program editor. ➤ “Creating a new program” on page 51 or ➤ “Editing a program” on page 52.
2. ➤ Set selection **Part follow-up** to selection option **Part length internal** set. ➤ “Set the Selection option Part follow-up” on page 54 or ➤ “Enter the selection option” on page 56.

3. Tap the **Feed 1** field.
➔ An input field opens.
4. Enter the length of the first machining operation.
5. Scroll to the next page using the  button.
6. Tap the **Feed 2** field.
➔ An input field opens.
7. Enter the length of the second machining operation.
8. Tap the **Feed 3** field.
➔ An input field opens.
9. Enter the length of the third machining operation.
10. Save changes.

Pushing the material bar with the sub-spindle of the machine tool



If the lathe sends a signal for the sub-spindle to the loading magazine, the saved values for speed and feeding force are automatically used when pushing with the sub-spindle.

If the lathe sends no signal for the sub-spindle to the loading magazine, the saved values are automatically used when pushing with the sub-spindle for speed and feeding force, which are also used for standard pushing. It may be necessary to adjust these values when working with the sub-spindle.

The values of loading magazine and machine tool should generally be set so that the loading magazine can follow the machine tool. The technical data for the loading magazine must be taken into account.



All the settings for working with the sub-spindle have to be set in a program.

1. Enter values for **Feed force for sub-spindle** and **Speed sub-spindle**. ➔ “Enter Feed force for sub-spindle” on page 55 and ➔ “Enter Speed sub-spindle” on page 55.
2. Set selection **Part follow-up** to selection option **Collet open, fixed speed**.

Process two different part lengths



This function is available as an option.

This function means it is possible to process two different long parts. The second part length can be used to process shorter parts from the remnant. Once the remnant is too short for the first part length, the second part length is pushed.

1. Open the program in the program editor. ➔ “Creating a new program” on page 51 or ➔ “Editing a program” on page 52.
2. Scroll to the next page using the  button.

3. ➤ Click on the field **Feed 1 part 2**.
➔ An input field opens.
4. ➤ Enter the value for the shorter part.
5. ➤ Save changes.

Interval insert

The interval insert improves the insertion of multi-sided material into the lathe collet. During the first insert, the pusher performed intervals of short forward and backward strokes. The interval insert can be adjusted ➔ “Set the Interval insert” on page 65.

Set the Interval insert



*The value **Travel interval on** determines the length of the intermittent movement.*



The intermittent movement is set for the time of the forward and backward stroke.

Length of the intermittent movement:

1. ➤ Press the button.
2. ➤ ‘**SETTINGS** → **Service settings** → **Position**’
3. ➤ Click on the field **Travel interval on**.
➔ An input field opens.
4. ➤ Enter the value for **Travel interval on**.

Set the speed:

1. ➤ Press the button.
2. ➤ ‘**SETTINGS** → **Basic settings** → **Selection option**’
3. ➤ Click on the field **Time on**.
➔ A selection window opens.
4. ➤ Enter the value for **Time on**.
5. ➤ Click on the field **Time off**.
➔ A selection window opens.
6. ➤ Enter the value for **Time off**.

Set the interval insert selection:

1. ➤ Press the button.
2. ➤ ‘**SETTINGS** → **Basic settings** → **Selection option**’
3. ➤ Click on the field **Interval insert**.
➔ A selection window opens.
4. ➤ Click on the selection option.
➔ The chosen selection option is shown in the field.

Switching Interval insert on/off

1. ➤ Open the program in Programeditor. ➤ “Creating a new program” on page 51 or ➤ “Editing a program” on page 52.
2. ➤ Click on the field **Interval insert**.
➤ A selection window opens.
3. ➤ Select a corresponding value.
➤ The selection is shown in the field.
4. ➤ Scroll to the next page using the  button.
5. ➤ Save changes.

6.7 Processing phase

Loading the lateral material storage

 **WARNING**

High weight of the material bar

Physical overloading when raising the material bar by a high weight.


- Observe the weight of the material bar.
- Use suitable hoisting equipment.

 **WARNING**

High weight of the material bar

Danger of squashing limbs when putting down the material bar.

- Observe the weight of the material bar.
- Use suitable hoisting equipment.



1. ➤ Store the material bar on the lateral material storage **1**.
2. ➤ Move the material bar to the material stop **2**.

Report of the last material bar



This function is available as an option.

If a signal light is built into the loading magazine, the yellow light flashes as soon as the report is displayed on the control panel.

If the last material bar has been loaded from the lateral material storage into the guide channel during production (automatic mode), a yellow light flashes on the control panel, with the text **Last bar**. This notifies the operator that the lateral material storage is empty.

Production



During production the automatic mode is active. The loading magazine works at the same speed as the lathe. The program flow is completed taking into account the set values.

Automatic mode can be started in two stages of the program flow. This requires the following conditions:

- Step 1: A remnant is in the clamping sleeve.
- Step 17: A material bar is drawn onto the clamping device and is located in the lathe, at the cut-off position.

If the requirements for automatic mode have not been met, they can be established by the following procedure:

- Remove remnant, eject it and draw on the new material bar
➔ "Draw off remnant, eject it and draw on the new material bar" on page 70.

Start/stop production

1. ➔ Observe the prerequisites for automatic mode ➔ "Production" on page 67.
2. ➔ Press the button.
3. ➔ Access **PRODUCTION**.
4. ➔ If there is a remnant in the clamping sleeve: press the **S1** button.

If a material bar is drawn onto the clamping device and is located in the cut-off position in the lathe, press the **S17** button.
5. ➔ Start/stop production with the button.

Work flow for production (automatic mode)

Step	Description	Position
Step 1 Return	The pusher moves with the remnant from the lathe spindle into the area of the material gripper.	From the position: Pos. reverse rotation return at high speed End: Position draw off
Step 2 Close gripper blades	The material gripper closes and grabs the remnant.	-
Step 3 Draw off remnant	The pusher moves back again. The remnant is removed from the pusher.	End: Position rear limit
Step 4 Open gripper blades / guide channel	The guide channel opens. The material gripper opens. The remnant falls on the remnant flap.	-
Step 5 Open remnant flap	The remnant flap opens. The remnant falls into the remnant bin.	-

Step	Description	Position
Step 6 Close gripper blades / remnant flap	The remnant flap closes. The material gripper closes.	-
Step 7 Swing pusher out	The pusher swings out of the guide channel. The separation device moves down. A material bar rolls from the lateral material storage onto the separation device.	-
Step 8 Separate material	The separation device moves up. The material bar falls into the open guide channel.	-
Step 9 Close guide channel, short pusher forward	The guide channel closes. The short pusher moves the material bars forward.	End: Limit pos. short pusher front
Step 10 Short pusher return	The material bar remains in position. The short pusher moves back.	End: Position rear limit
Step 11 Swing pusher in	The pusher swings into the guide channel. The material gripper closes and grabs the material bar.	-
Step 12 Press upon	The pusher moves forward. The material bar is pressed onto the pusher.	End: Position draw off
Step 13 Open gripper blades	The material gripper opens.	-
Step 14 First insert	The pusher moves the material bar into the working area of the lathe.	End: First insert travel
Step 15 Start lathe	The loading magazine reports "End of bar change – program start" on the lathe. The collet of the lathe closes. The processing begins.	-
Step 16 Material cut-off	The processed part is cut off. The collet of the lathe opens.	-
Step 17 Part production	The pusher moves the material bar until the end of the material bar is reached.	End: Position front limit - Part length 1
Step 18 Insert last part	The pusher moves the material bar for the last time.	-
Step 19 Machine last part	The lathe operates the last part.	-
Step 20 Stop lathe / start bar change	A transfer time switch into step 1 is activated	-

Approaching Position rear limit



The "Position rear limit" position is reached when the pusher stops by itself while moving back and a value in the region of "0.00" (tolerance - 2.00 mm to + 1.50 mm) is displayed in the **FEED POSITION** field on the control panel.

1. ➤ Press the  button.
2. ➤ Access **SETUP**.
3. ➤ Move the pusher back using the  or  button until the pusher stops.

Draw off and eject the remnant



The remnant is removed from the clamping sleeve and is ejected into the remnant bin.

1. ➤ Press the  button.
2. ➤ Access **SETUP**.
3. ➤ Press the  button.

- ➔ The status display on the button turns green during the action. Once the action has been completed, the status display on the button is switched off. The remnant lies in the remnant bin.

Removing the material bar from the loading magazine



This action is suitable for material bars, which cannot be removed from the remnant bin due to their length. When the action is performed, the material bar is removed from the clamping sleeve and placed in the guide channel. The material bar can then be removed from the guide channel.

WARNING

High weight of the material bar

Physical overloading when raising the material bar by a high weight.

- Observe the weight of the material bar.
- Use suitable hoisting equipment.

CAUTION

Driven guide channel cover

Personal injury due to squashing and impact by the closing of the guide channel cover.

When working on the opened guide channel, the driven guide channel cover may squash extremities.

- Insert the safety bolts when working on the open guide channel. Observe the description in the operating instructions.

CAUTION

Sharp knives of the material gripper

Cuts due to the sharp knives of the material gripper.

When working in the vicinity of the material gripper, there is a risk of cuts in the event of inattentiveness.

- Wear safety gloves.

1. ➤ Press the  button.
2. ➤ Access **SETUP**.

3. ➤ Press the  button.
 - The status display on the button turns green during the action. Once the action has been completed, the status display on the button is switched off. The material bar is removed from the clamping device and lies in the guide channel.
4. ➤ Push the material out of the range of the material gripper with the  button.
5. ➤ Move the pusher by pressing the button  to **Position rear limit**.
6. ➤ Open the guide channel with the  button.
7. ➤ Press the emergency stop button. ➤ *“Press the emergency stop button” on page 46.*
8. ➤ Switch off the supply of compressed air. ➤ *“Switch the supply of compressed air on/off” on page 112*
9. ➤ Where necessary, obtain release from the lathe to open the cover.
10. ➤ Open the cover.
11. ➤ Secure the guide channel with safety bolts. ➤ *“Securing the guide channel with safety bolts” on page 76*
12. ➤ If the material bar reaches into the working area of the lathe: pull the material bar by hand towards the loading magazine, until the material bar is fully on the loading magazine.
13. ➤ Remove the material bar from the loading magazine via the lateral material storage.
14. ➤ Remove the safety bolts in the guide channel.
15. ➤ Close the cover.
16. ➤ Switch on the compressed air supply. ➤ *“Switch the supply of compressed air on/off” on page 112*
17. ➤ Unlock the emergency stop button. ➤ *“Make the loading magazine ready for operation after the emergency stop” on page 46*
18. ➤ Close the guide channel with the  button.
19. ➤ Acknowledge the error message by pressing the  button.

Draw off remnant, eject it and draw on the new material bar



When executing the action, the remnant is removed from the clamping sleeve, ejected into the remnant bin and then a new material bar is loaded from the lateral material storage and drawn onto the clamping device.



With this action, a first insert can be performed after the new bar has been drawn in. For this purpose, select the desired operating mode.

There must be a material bar in the lateral material storage.

1. ➤ Press the  button.

2. Access **SETUP**.


3. Press the  button.

- ➔ The status display on the button turns green during the action. Once the action has been completed, the status display on the button is switched off.

Without first insert: The remnant is located in the remnant bin. The new material bar is drawn in and is in the working room of the lathe.

With first insert: The remnant is located in the remnant bin. The new material bar is drawn in and is in the working room of the lathe.

Remnant bin



The remnant bin **1** is located below the loading magazine and is accessible from the front. When the remnant flap **2** opens, the remnant lying on it falls down into the remnant bin and can be removed by the operator.

Removing the remnant

WARNING

Driven remnant flap

Personal injury due to squashing, impact or striking by the driven remnant flap.

When removing the remnant, the operator has to reach down into the remnant bin. If the operator reaches up, his/her hand would be in the area of the driven remnant flap.

- When removing the remnants in the remnant bin, do not reach upwards.


CAUTION

Further ejection of remnants into the remnant bin

Personal injury due to squashing and impact as a result of addition residual ejection.

When removing a remnant from the remnant bin, there may be a further ejection of remnants. The remnant may hit extremities in the remnant bin.

- Do not reach into the remnant bin during the bar change.
- When removing a remnant, observe the current operating conditions of the loading magazine.



➞ Remove the remnant from the remnant bin **1**.

Switching Steady on/off

1. ➞ Press the  button.
2. ➞ Access **PRODUCTION** or **SETUP**.

Switch on:

1. ➞ Press the  button.
 - ➞ The status display on the button turns green. The steady is switched on.

Switch off:

1. ➞ Press the  button.
 - ➞ The status display on the button is off. The steady is switched off.

Switch the steady on/off as a insertion aid

1. ➞ Press the  button.
2. ➞ Access **PRODUCTION**.

Switch on:

- ➞ Press the  button.
 - ➞ The status display on the button turns green. The steady function as an insertion aid is switched on.

Switch off:

- ➞ Press the  button.
 - ➞ The status display on the button is off. The steady function as an insertion aid is switched off.

Switching Interval insert on/off

1. ➞ Press the  button.
2. ➞ Access **PRODUCTION**.

Switch on:

1. ➞ Press the  button.
 - ➞ The status display on the button turns green. The interval insert is switched on.

Switch off:

1. ➤ Press the  button.
 - The status display on the button is off. The interval insert is switched off.

Switching the brake function on/off



The brake function holds the pusher in position during the processing of the machine tool and prevents the pusher being pressed back.

1. ➤ Press the  button.
2. ➤ Access **PRODUCTION**.

Switch on:

1. ➤ Press the  button.
 - The status display on the button turns green. The brake function is switched on.

Switch off:

1. ➤ Press the  button.
 - The status display on the button is off. The brake function is switched off.

Switching Oil pump on/off

1. ➤ Press the  button.
2. ➤ Access **SETUP**.

Switch on:

1. ➤ Press the  button.
 - The status display on the button turns green. The oil pump is switched on.

Switch off:

1. ➤ Press the  button.
 - The status display on the button is off. The oil pump is switched off.

Eject the remnant

1. ➤ Press the  button.
2. ➤ **SETUP** Opening.
1. ➤ Press and hold the  button.
 - The status display on the button turns green. The remnant flap is opened. The remnant falls down into the remnant bin.

2. ➤ Release the  button.

- ➔ The status display on the button is off. The remnant flap is closed.

Close/open the material gripper

1. ➤ Press the  button.

2. ➤ Access **SETUP**.

Close:

1. ➤ Press the  button.

- ➔ The status display on the button turns green. The material gripper is closed.

Open:

1. ➤ Press the  button.

- ➔ The status display on the button is off. The material gripper is opened.

Open/close the guide channel

1. ➤ Press the  button.

2. ➤ Access **SETUP**.

Open:

1. ➤ Press the  button.

- ➔ The status display on the button turns green. The front guide channel is opened.

Close:

1. ➤ Press the  button.

- ➔ The status display on the button is off. The guide channel is closed.

Swing the pusher out/in

1. ➤ Press the  button.

2. ➤ **SETUP** Opening.

Swing out:

➤ Press the  button.

- ➔ The status display on the button turns green. The pusher has been swung out.

Swing in:

➤ Press the  button.

- ➔ The status display on the button is off. The pusher has been swung in.

Switch discharge material bar oil on / off



This function is available as an option.

1. ➤ Press the  button.

2. ➤ Access **SETUP**.

Switch on:

➤ Press the  button.

- ➡ The status display on the button turns green. The function discharging oil from the material bar is switched on.

Switch off:

➤ Press the  button.

- ➡ The status display on the button is off. The function discharging oil from the material bar is switched off.

7 Converting

7.1 General conversion

Capacity adjustment set

The loading magazine can process material bars of different diameters. Certain components of the loading magazine can be adjusted to the material bar diameter to be processed, to improve the guide of the material bar. These components are consolidated in a capacity adjustment set and can be exchanged if needed.

In the event of questions about the choice of the right capacity adjustment set, please contact FMB. ➔ *“Service contact details” on page 119.*

The capacity adjustment set includes:

- A pusher with a short pusher and flag
- Inserts of the guide channel
- Lifting plates

The guide jaws of the steady and the telescopic tube/guide tube/guide module can also be adapted to the material diameter to be processed. However, these are not part of the capacity adjustment set.

Depending on the extension version and the type of lathe, further adjustments may be necessary during conversion to other diameters. For information about this, see the extension-specific adapter set/attachment diagram. ➔ *“Other applicable documents” on page 5.*

Move to the conversion position

1. ➤ Press the  button.

2. ➤ Access **SETUP**.

➤ Press the  button.

- ➔ The status display on the button turns green. The conversion position is moved to (duration approx. 10s).

7.2 Guide channel

Securing the guide channel with safety bolts

 **WARNING**

Falling material bar

Personal injury due to squashing and impact as a result of a falling material bar.

Material bars which are located on the lateral material storage, may fall down during conversion work.

- Before conversion work, remove the material bars from the lateral material storage.

⚠ CAUTION
Sharp knives of the material gripper

Cuts due to the sharp knives of the material gripper.

When working in the vicinity of the material gripper, there is a risk of cuts in the event of inattentiveness.


- Wear safety gloves.

⚠ CAUTION
Driven guide channel cover

Personal injury due to squashing and impact by the closing of the guide channel cover.

When working on the opened guide channel, the driven guide channel cover may squash extremities.


- Insert the safety bolts when working on the open guide channel. Observe the description in the operating instructions.




The safety bolts **1** are attached to a chain on the loading magazine and are in the position **2**. The guide channel can open at the front, at the back or at the front and back. The safety bolts must secure the respective open position when working on the open guide channel (front only, rear only or front and rear).

Guide channel, front:

1. Press the button.
2. **SETUP** Press .
3. Open the front guide channel using the button.
4. Press the emergency stop button. ➔ *“Press the emergency stop button” on page 46.*
5. Switch off the compressed air supply. ➔ *“Switch the supply of compressed air on/off” on page 112*
6. Where necessary, obtain release from the lathe to open the cover.
7. Open the cover.
8. Insert the safety bolt **3** into the hole **4**.
➔ The front guide channel is secured by a safety bolt.
9. After finishing work on the guide channel, remove the safety bolt **3** from the hole **4**.
10. Close the cover.
11. Switch on the compressed air supply. ➔ *“Switch the supply of compressed air on/off” on page 112*
12. Unlock the emergency stop button. ➔ *“Make the loading magazine ready for operation after the emergency stop” on page 46*
13. Close the front guide channel using the button.
14. Acknowledge the error message by pressing the button.


Guide channel, rear:

1. Press the button.
2. **SETUP** Press .



3. ➤ Open the rear guide channel using the  button (swing out the pusher).
4. ➤ Press the emergency stop button. ➔ *“Press the emergency stop button” on page 46.*
5. ➤ Switch off the compressed air supply. ➔ *“Switch the supply of compressed air on/off” on page 112*
6. ➤ Where necessary, obtain release from the lathe to open the cover.
7. ➤ Open the cover.
8. ➤ Insert the safety bolt  into the hole .
 - ➔ The rear guide channel is secured by a safety bolt.
9. ➤ After finishing work on the guide channel, remove the safety bolt  from the hole .
10. ➤ Close the cover.
11. ➤ Close the rear guide channel using the  button (swing in the pusher).
12. ➤ Acknowledge the error message by pressing the .

Pusher

The pusher is driven by the drive motor and moves the material bar into the working area of the lathe. The diameter of the pusher depends on the diameter of the material to be processed and must be changed when processing different material thicknesses.

Depending on the spindle diameter of the lathe, it may be necessary for the spindle diameter to also be adjusted. In the event of questions about this please contact FMB. ➔ *“Service contact details” on page 119*

Changing the pusher and lifting plates

WARNING

Falling material bar

Personal injury due to squashing and impact as a result of a falling material bar.

Material bars which are located on the lateral material storage, may fall down during conversion work.

- Before conversion work, remove the material bars from the lateral material storage.

CAUTION

Sharp knives of the material gripper

Cuts due to the sharp knives of the material gripper.

When working in the vicinity of the material gripper, there is a risk of cuts in the event of inattentiveness.

- Wear safety gloves.

⚠ CAUTION
Driven guide channel cover

Personal injury due to squashing and impact by the closing of the guide channel cover.

When working on the opened guide channel, the driven guide channel cover may squash extremities.



- Insert the safety bolts when working on the open guide channel. Observe the description in the operating instructions.




A second person is required to change the pusher, to support the work.

Removal:


1. ➤ Press the  button.
2. ➤ **SETUP** .
3. ➤ Approach the conversion position by pressing the  button.
➤ *“Move to the conversion position” on page 76.*
4. ➤ Press the emergency stop button. ➤ *“Press the emergency stop button” on page 46.*
5. ➤ Switch off the compressed air supply. ➤ *“Switch the supply of compressed air on/off” on page 112*
6. ➤ Where necessary, obtain release from the lathe to open the cover.
7. ➤ Open the cover.
8. ➤ Secure the front and rear guide channel with safety bolts.
➤ *“Securing the guide channel with safety bolts” on page 76.*
9. ➤ Set the holding-down device **1** in the area of the pusher to the highest position. ➤ *“Setting the height of the holding-down device” on page 104.*
10. ➤ Hold the pusher **2** (second person).
11. ➤ Remove the safety device **3**.
12. ➤ Remove the lifting plate (front) **4** in the direction indicated by the arrow.






13. ➤ Remove the safety device [5].
14. ➤ Remove the lifting plate (rear) [6] in the direction indicated by the arrow.
15. ➤ Remove the pusher (second person).


Installation:



1. ➤ Insert the lifting plate (front) [7].
2. ➤ Insert the safety device [8].
3. ➤ Insert the pusher [9] with the front end going into the lifting plate (front) [7] (second person).



4. ➤ Insert the rear end of the pusher with the short pusher flag [10] into the guide [11] and hold it (second person).



5. ➤ Insert the lifting plate (rear) [12].
6. ➤ Insert the safety device [13].
 - ➔ The pusher is now installed.
7. ➤ Remove the safety bolts in the guide channel.
8. ➤ Close the cover.
9. ➤ Switch on the compressed air supply. ➔ "Switch the supply of compressed air on/off" on page 112
10. ➤ Unlock the emergency stop button. ➔ "Make the loading magazine ready for operation after the emergency stop" on page 46
11. ➤ Swing in the pusher using the  button.
12. ➤ Close the guide channel using the  button.
13. ➤ Acknowledge the error message using the  button.

Changing the short pusher flag



When changing the pusher, the flag from the old pusher is mounted onto the new pusher.



1. ➤ Detach the pusher. ➔ *“Changing the pusher and lifting plates” on page 78.*
2. ➤ Loosen and remove the screws 1 in the short pusher flag.
3. ➤ Remove the flag.
4. ➤ Attach the flag in reverse order.
5. ➤ Insert the pusher. ➔ *“Changing the pusher and lifting plates” on page 78.*

Changing the insert of the top rear guide channel

⚠ WARNING

Falling material bar

Personal injury due to squashing and impact as a result of a falling material bar.

Material bars which are located on the lateral material storage, may fall down during conversion work.

- Before conversion work, remove the material bars from the lateral material storage.

⚠ CAUTION

Sharp knives of the material gripper

Cuts due to the sharp knives of the material gripper.

When working in the vicinity of the material gripper, there is a risk of cuts in the event of inattentiveness.

- Wear safety gloves.


⚠ CAUTION

Driven guide channel cover

Personal injury due to squashing and impact by the closing of the guide channel cover.

When working on the opened guide channel, the driven guide channel cover may squash extremities.


- Insert the safety bolts when working on the open guide channel. Observe the description in the operating instructions.



The top rear guide channel insert 1 is located in the area between the drive motor 2 and the material gripper 3

To change the top rear guide channel insert, the pusher must be removed. ➔ *“Changing the pusher and lifting plates” on page 78.*

1. ➤ Press the  button.
2. ➤ **SETUP** Press .
3. ➤ Move to the conversion position by pressing the  button. ➔ *“Move to the conversion position” on page 76.*
4. ➤ Press the emergency stop button. ➔ *“Press the emergency stop button” on page 46.*



5. ➤ Switch off the compressed air supply. ➔ *"Switch the supply of compressed air on/off" on page 112*
6. ➤ Where necessary, obtain release from the lathe to open the cover.
7. ➤ Open the cover.
8. ➤ Secure the front and rear guide channel with safety bolts.
➔ *"Securing the guide channel with safety bolts" on page 76*
9. ➤ Place the insertion tool [4] with the short bend into the recess [5] in the upper guide channel.
10. ➤ Press and hold the insert safeguard [6] and move the insert tool [4] in the direction indicated by the arrow.
➔ The insert is now detached.
11. ➤ Remove the insert tool.
12. ➤ Remove the insert.
13. ➤ Place the new insert into the upper rear guide channel and press in firmly by hand.
14. ➤ Remove the safety bolts in the guide channel.
15. ➤ Close the cover.
16. ➤ Switch on the compressed air supply. ➔ *"Switch the supply of compressed air on/off" on page 112*
17. ➤ Unlock the emergency stop button. ➔ *"Make the loading magazine ready for operation after the emergency stop" on page 46*
18. ➤ Swing in the pusher using the  button.
19. ➤ Close the guide channel with the  button.
20. ➤ Acknowledge the error message by pressing the  button.

Changing the insert of the bottom rear guide channel

WARNING

Falling material bar

Personal injury due to squashing and impact as a result of a falling material bar.

Material bars which are located on the lateral material storage, may fall down during conversion work.

- Before conversion work, remove the material bars from the lateral material storage.

CAUTION

Sharp knives of the material gripper

Cuts due to the sharp knives of the material gripper.

When working in the vicinity of the material gripper, there is a risk of cuts in the event of inattentiveness.


- Wear safety gloves.

⚠ CAUTION
Driven guide channel cover

Personal injury due to squashing and impact by the closing of the guide channel cover.


When working on the opened guide channel, the driven guide channel cover may squash extremities.

- Insert the safety bolts when working on the open guide channel. Observe the description in the operating instructions.



The bottom rear guide channel insert [1] is located in the area between the drive motor [2] and the remnant bin [3]. The insert consists of several parts. The change is described using the example of one part of the insert, but has to be done for all the parts.

1. Press the button.
2. **SETUP** Press .
3. Move to the conversion position by pressing the button. ➔ *"Move to the conversion position" on page 76.*
4. Press the emergency stop button. ➔ *"Press the emergency stop button" on page 46.*
5. Switch off the compressed air supply. ➔ *"Switch the supply of compressed air on/off" on page 112*
6. Where necessary, obtain release from the lathe to open the cover.
7. Open the cover.
8. Secure the front and rear guide channel with safety bolts. ➔ *"Securing the guide channel with safety bolts" on page 76*
9. Place the insertion tool [4] with the long bend into the recess [5] in the lower guide channel.
10. Move the insert tool [4] in the direction indicated by the arrow. ➔ The insert is now detached.
11. Remove the insert.
12. Remove the insert tool.
13. Place the new insert into the bottom rear guide channel and press in firmly by hand.
14. Remove the safety bolts in the guide channel.
15. Close the cover.
16. Switch on the compressed air supply. ➔ *"Switch the supply of compressed air on/off" on page 112*
17. Unlock the emergency stop button. ➔ *"Make the loading magazine ready for operation after the emergency stop" on page 46*
18. Swing in the pusher using the button.
19. Close the guide channel with the button.



20. Acknowledge the error message by pressing the  button.

Changing the insert of the top front guide channel

WARNING

Falling material bar

Personal injury due to squashing and impact as a result of a falling material bar.

Material bars which are located on the lateral material storage, may fall down during conversion work.

- Before conversion work, remove the material bars from the lateral material storage.

CAUTION

Sharp knives of the material gripper

Cuts due to the sharp knives of the material gripper.

When working in the vicinity of the material gripper, there is a risk of cuts in the event of inattentiveness.

- Wear safety gloves.


CAUTION

Driven guide channel cover

Personal injury due to squashing and impact by the closing of the guide channel cover.


When working on the opened guide channel, the driven guide channel cover may squash extremities.

- Insert the safety bolts when working on the open guide channel. Observe the description in the operating instructions.



The top front guide channel insert  is located in the area between the material gripper  and the steady . The insert consists of several parts. The change is described using the example of one part of the insert, but has to be done for all the parts.

1. Press the  button.
2. **SETUP** Press .
3. Move to the conversion position by pressing the  button.
➔ "Move to the conversion position" on page 76.
4. Press the emergency stop button. ➔ "Press the emergency stop button" on page 46.
5. Switch off the compressed air supply. ➔ "Switch the supply of compressed air on/off" on page 112
6. Where necessary, obtain release from the lathe to open the cover.
7. Open the cover.
8. Secure the front and rear guide channel with safety bolts.
➔ "Securing the guide channel with safety bolts" on page 76



9. ➤ Place the insertion tool **4** with the short bend into the recess **5** in the upper guide channel.
10. ➤ Press and hold the insert safeguard **6** and move the insert tool **4** in the direction indicated by the arrow.
➔ The insert is now detached.
11. ➤ Remove the insert tool.
12. ➤ Remove the insert.
13. ➤ Place the new insert into the top front guide channel and press in firmly by hand.
14. ➤ Remove the safety bolts in the guide channel.
15. ➤ Close the cover.
16. ➤ Switch on the compressed air supply. ➔ *“Switch the supply of compressed air on/off” on page 112*
17. ➤ Unlock the emergency stop button. ➔ *“Make the loading magazine ready for operation after the emergency stop” on page 46*
18. ➤ Swing in the pusher using the  button.
19. ➤ Close the guide channel with the  button.
20. ➤ Acknowledge the error message by pressing the  button.

Changing the remnant flap insert

WARNING

Falling material bar

Personal injury due to squashing and impact as a result of a falling material bar.

Material bars which are located on the lateral material storage, may fall down during conversion work.

- Before conversion work, remove the material bars from the lateral material storage.

CAUTION

Sharp knives of the material gripper

Cuts due to the sharp knives of the material gripper.

When working in the vicinity of the material gripper, there is a risk of cuts in the event of inattentiveness.

- Wear safety gloves.


CAUTION

Driven guide channel cover

Personal injury due to squashing and impact by the closing of the guide channel cover.



When working on the opened guide channel, the driven guide channel cover may squash extremities.

- Insert the safety bolts when working on the open guide channel. Observe the description in the operating instructions.



The remnant flap insert **1** is located in the guide channel at the height of the remnant bin **2**.

1. Press the button.
2. **SETUP** Press .
3. Move to the conversion position by pressing the button.
➔ "Move to the conversion position" on page 76.
4. Press the emergency stop button. ➔ "Press the emergency stop button" on page 46.
5. Switch off the compressed air supply. ➔ "Switch the supply of compressed air on/off" on page 112
6. Where necessary, obtain release from the lathe to open the cover.
7. Open the cover.
8. Secure the front and rear guide channel with safety bolts.
➔ "Securing the guide channel with safety bolts" on page 76
9. Pull and hold the insert safeguard **3** in the direction indicated by the arrow.
10. Push the remnant flap insert **4** towards the insert safeguard and remove it from above.



11. Place the new remnant flap insert with the holes **5** on the insert pegs in the guide channel.
12. Push the remnant flap insert towards the material gripper until the insert safeguard **3** locks into place.
13. Remove the safety bolts in the guide channel.
14. Close the cover.
15. Switch on the compressed air supply. ➔ "Switch the supply of compressed air on/off" on page 112
16. Unlock the emergency stop button. ➔ "Make the loading magazine ready for operation after the emergency stop" on page 46
17. Swing in the pusher using the button.
18. Close the guide channel with the button.
19. Acknowledge the error message by pressing the button.

Changing the insert of the bottom front guide channel

WARNING

Falling material bar

Personal injury due to squashing and impact as a result of a falling material bar.

Material bars which are located on the lateral material storage, may fall down during conversion work.

- Before conversion work, remove the material bars from the lateral material storage.

CAUTION

Sharp knives of the material gripper

Cuts due to the sharp knives of the material gripper.

When working in the vicinity of the material gripper, there is a risk of cuts in the event of inattentiveness.

- Wear safety gloves.


CAUTION

Driven guide channel cover

Personal injury due to squashing and impact by the closing of the guide channel cover.


When working on the opened guide channel, the driven guide channel cover may squash extremities.

- Insert the safety bolts when working on the open guide channel. Observe the description in the operating instructions.




The bottom front guide channel insert **1** is located in the area between the remnant bin **2** and the steady **3**. The insert consists of several parts. The change is described using the example of one part of the insert, but has to be done for all the parts.

1. Press the  button.
2. **SETUP** Press .
3. Move to the conversion position by pressing the  button.
➔ “Move to the conversion position” on page 76.
4. Press the emergency stop button. ➔ “Press the emergency stop button” on page 46.
5. Switch off the compressed air supply. ➔ “Switch the supply of compressed air on/off” on page 112
6. Where necessary, obtain release from the lathe to open the cover.
7. Open the cover.
8. Secure the front and rear guide channel with safety bolts.
➔ “Securing the guide channel with safety bolts” on page 76





9. Place the insertion tool **4** with the long bend into the recess **5** in the lower guide channel.
10. Move the insert tool **4** in the direction indicated by the arrow.
➔ The insert is now detached.
11. Remove the insert.
12. Remove the insert tool.
13. Place the new insert into the bottom front guide channel and press in firmly by hand.
14. Remove the safety bolts in the guide channel.
15. Close the cover.
16. Switch on the compressed air supply. ➔ *"Switch the supply of compressed air on/off" on page 112*
17. Unlock the emergency stop button. ➔ *"Make the loading magazine ready for operation after the emergency stop" on page 46*
18. Swing in the pusher using the button.
19. Close the guide channel with the button.
20. Acknowledge the error message by pressing the button.

Changing the guide module



1. Press the button.
2. **SETUP**.
3. Approach the conversion position by pressing the button.
➔ *"Move to the conversion position" on page 76.*
4. Press the emergency stop button. ➔ *"Press the emergency stop button" on page 46.*
5. Switch off the compressed air supply. ➔ *"Switch the supply of compressed air on/off" on page 112*
6. Where necessary, obtain release from the lathe to open the cover.
7. Open the cover.
8. Secure the front and rear guide channel with safety bolts.
➔ *"Securing the guide channel with safety bolts" on page 76*
9. Pull the index pin **1** and rotate through 30°.
➔ The index pin is in the open position
10. Pull the guide module **2** out of the adapter set **3** in the direction of the arrow.



11. Pull the index pin **4** and rotate through 30°.
 - ➔ The index pin is in the open position
12. Remove the guide sleeve **5** in the direction of the arrow.
13. Remove the guide module **6** in the direction of the arrow.
14. Attach the guide module in reverse order. It must be ensured that the locking points for the index pins are in the correct position to ensure that the index pins lock.
15. Remove the safety bolts in the guide channel.
16. Close the cover.
17. Switch on the compressed air supply. ➔ *"Switch the supply of compressed air on/off" on page 112*
18. Unlock the emergency stop button. ➔ *"Make the loading magazine ready for operation after the emergency stop" on page 46*
19. Swing in the pusher using the  button.
20. Close the guide channel using the  button.
21. Acknowledge the error message using the  button.

7.3 Reduction

Reduction, general

The transition area between the loading magazine and the machine tool and the machine tool spindle can be reduced. The procedure is order-specific. The information on "Attachment to the machine tool" must be observed here. ➔ *"Attachment to machine tool" on page 33.*


7.4 Steady

Steady


The design of the steady is dependent on the spindle diameter of the machine tool. The steady is supplied in the following versions:

- Material passage up to 26 mm
- Material passage up to 38 mm

The procedure for working on the steady is dependent on the design.



Steady with a material passage of up to diameter 26 mm



Steady with a material passage of up to diameter 38 mm

The steady moves the material bar during processing. For this purpose, the material guide of the steady can be equipped with jaws (jaw steady) or rollers (roller steady). To guide the material bar, the steady is closed. In open condition, the material bar and pusher can pass.

The open and closed position can be adjusted via the end stops. When closing, the steady moves to the desired material bar diameter and guides the material bar. When opening, the steady moves

the material guide apart so that the pusher can pass. The stop screw [1] limits the material guide [3] on closing. The stop screw [2] limits the material guide [3] on opening ➔ *“Setting the steady (material passage 26 mm) to the material bar diameter” on page 91, ➔ “Setting the steady (material passage 38 mm) to the material bar diameter” on page 92.*

The steady can also be set so that the material guide can be adjusted to the current material thickness when closed. For this purpose, the pressure is reduced at the pressure control valve of the steady. With the right setting, the material guide can adjust itself automatically. In this case the steady opens and closes to the maximum. When closing, the steady stops as soon as the material guide [3] reaches the surface of the material bar. The material bar is then guided without excessive wear. The stop screws [1] and [2] have no function and are set so that the material guide can close or open to the maximum..

Setting the steady (material passage 26 mm) to the material bar diameter




The described procedure refers to the steady with a material passage of up to 26 mm.



The steady can be used as a roller steady or a jaw steady. Depending on the application, rollers or jaws have to be installed to guide the material.



*To be able to manually open and close the steady, the following setting must be made for the duration of the set-up process, regardless of the later use: **selection Steady**, Selection option **Jaw steady**.*



The path of the rollers when the steady is closed is set using the stop screw [2].

The path of the rollers when the steady is opened is set using the stop screw [4]. This is only necessary in case of pusher vibrations ➔ *“Guide the pusher with the steady (material passage 26)” on page 94, ➔ “Guiding the pusher with the steady (material passage 38 mm)” on page 95.* In all other cases, the stop screw [4] is completely unscrewed, so that the steady opens fully in the open position.

1. ➔ Draw the material bar with the respective diameter onto the clamping sleeve. ➔ *“Draw off remnant, eject it and draw on the new material bar” on page 70.*
2. ➔ **selection Steady**, Selection option **Jaw steady** set. ➔ *“Enter the selection option” on page 56.*
3. ➔ Press the button.
4. ➔ **SETUP** .
5. ➔ Close the steady by pressing the button.
 - ➔ The status display on the button turns green. The steady is closed.

6. ➤ Loosen the lock nut .
7. ➤ Turn the stop screw  to the left until the stop screw  is completely unscrewed.
8. ➤ Open the steady using the  button.
 - ➔ The status display on the button is off. The steady is open.
9. ➤ Turn the stop screw  to the right until you feel resistance.
10. ➤ Tighten the lock nut 
 - ➔ The end stop for the open position is set
11. ➤ Loosen the lock nut .
12. ➤ Turn the stop screw  to the left until the stop screw  is completely unscrewed.
13. ➤ Move the material bar into the lathe using the  button.
14. ➤ Clamp the material bar in the lathe.
15. ➤ Close the steady by pressing the  button.
 - ➔ The status display on the button turns green. The steady is closed.
16. ➤ Turn the stop screw  to the right until you feel resistance.
 - ➔ The stop screw  is touching the end stop.
17. ➤ Open the steady using the  button.
 - ➔ The status display on the button is off. The steady is open.
18. ➤ Turn the stop screw  approx. half a turn clockwise.
19. ➤ Tighten the lock nut 
 - ➔ The end stop for the closed position is set.
20. ➤ **When used as a roller steady:** selection **Steady**, Selection option **Roller steady** set. ➔ "Enter the selection option" on page 56.
21. ➤ **When used as a jaw steady:** selection **Steady**, Selection option **Jaw steady** set. ➔ "Enter the selection option" on page 56.

Setting the steady (material passage 38 mm) to the material bar diameter




The described procedure refers to the steady with a material passage of up to 38 mm.



The steady can be used as a roller steady or a jaw steady. Depending on the application, rollers or jaws may need to be installed to guide the material.



To be able to manually open and close the steady, the following setting must be made for the duration of the set-up process, regardless of the later use: selection **Steady**, Selection option **Jaw steady**.



The path of the rollers when the steady is closed is set with the stop screw [2].

The path of the rollers when the steady is opened is set with the stop screw [4]. This is only necessary in case of pusher vibrations ➔ *“Guide the pusher with the steady (material passage 26)” on page 94*, ➔ *“Guiding the pusher with the steady (material passage 38 mm)” on page 95*. In all other cases, the stop screw [4] is completely unscrewed, so that the steady opens fully in open position.

1. ➤ Pull the material bar with the relevant diameter onto the clamping sleeve. ➔ *“Draw off remnant, eject it and draw on the new material bar” on page 70.*
2. ➤ selection **Steady**, Selection option **Jaw steady** set. ➔ *“Enter the selection option” on page 56.*
3. ➤ Press the  button.
4. ➤ **SETUP** press.
5. ➤ Close the steady by pressing the  button.
 - ➔ The status display on the button turns green. The steady is closed.
6. ➤ Loosen the lock nut [3].
7. ➤ Turn the stop screw [4] to the left until the stop screw [4] is completely unscrewed.
8. ➤ Open the steady using the  button.
 - ➔ The status display on the button is off. The steady is open.
9. ➤ Turn the stop screw [4] to the right until you feel resistance.
10. ➤ Tighten the lock nut [3]
 - ➔ The end stop for the open position is set
11. ➤ Loosen the lock nut [1].
12. ➤ Turn the stop screw [2] clockwise as far as it will go.
13. ➤ Move the material bar into the lathe using the  button.
14. ➤ Clamp the material bar in the lathe.
15. ➤ Close the steady by pressing the  button.
 - ➔ The status display on the button turns green. The steady is closed.
16. ➤ Turn the stop screw [2] to the left until you feel resistance.
 - ➔ The stop screw [2] is touching the end stop.
17. ➤ Open the steady using the  button.
 - ➔ The status display on the button is off. The steady is open.
18. ➤ Turn the stop screw [2] approx. half a turn counterclockwise.

19. Tighten the lock nut **1**.
 - ➔ The end stop for the closed position is set.
20. **When used as a roller steady:** selection **Steady**, Selection option **Roller steady** set. ➔ “Enter the selection option” on page 56.
21. **When used as a jaw steady:** selection **Steady**, Selection option **Jaw steady** set. ➔ “Enter the selection option” on page 56.

Guide the pusher with the steady (material passage 26)

i


The described procedure refers to the steady with a material passage of up to 26 mm.

i

If the pusher vibrates, the steady can be set so that it guides the pusher in the open position.

i

To be able to manually open and close the steady, the following setting must be made for the duration of the set-up process, regardless of the later use: selection **Steady**, Selection option **Jaw steady**.



1. selection **Steady**, Selection option **Jaw steady** set. ➔ “Enter the selection option” on page 56.
2. Press the button.
3. **SETUP**.
4. Close the steady by pressing the button.
 - ➔ The status display on the button turns green. The steady is closed.
5. Loosen the lock nut **1**.
6. Turn the stop screw **4** to the left until the stop screw **4** is completely unscrewed.
7. Open the steady using the button.
 - ➔ The status display on the button is off. The steady is open.
8. Move the pusher into the lathe using the button until the pusher is in the steady area.
9. Loosen the lock nut **1**.
10. Turn the stop screw **2** to the left until the stop screw **2** is completely unscrewed.
11. **Condition for closing the steady on the pusher:** selection **Steady**, Selection option **Roller steady** set. ➔ “Enter the selection option” on page 56.
12. **Condition for closing the steady on the pusher:** close the collet of the lathe.
13. Close the steady by pressing the button.
 - ➔ The status display on the button turns green. The steady is closed.


14. Turn the stop screw **4** to the right until you feel resistance.
15. Turn the stop screw **4** approx. half a turn counterclockwise.
16. Tighten the lock nut **3**.
 - ➔ The end stop for the open position is set
17. Open the steady using the  button.
 - ➔ The status display on the button is off. The steady is open.
18. **When used as a roller steady:** selection **Steady**, Selection option **Roller steady** set. ➔ “Enter the selection option” on page 56.
19. **When used as a jaw steady:** selection **Steady**, Selection option **Jaw steady** set. ➔ “Enter the selection option” on page 56.

Guiding the pusher with the steady (material passage 38 mm)

***i** The described procedure refers to the steady with a material passage of up to 38 mm.*

***i** If the pusher vibrates, the steady can be set so that it guides the pusher in open position.*

***i** To be able to manually open and close the steady, the following setting must be made for the duration of the set-up process, regardless of the later use: selection **Steady**, Selection option **Jaw steady**.*



1. selection **Steady**, Selection option **Jaw steady** set. ➔ “Enter the selection option” on page 56.
2. Press the  button.
3. **SETUP** press.
4. Close the steady by pressing the  button.
 - ➔ The status display on the button turns green. The steady is closed.
5. Loosen the lock nut **3**.
6. Turn the stop screw **4** clockwise as far as it will go.
7. Open the steady using the  button.
 - ➔ The status display on the button is off. The steady is open.
8. Move the pusher into the lathe using the  button until the pusher is in the area of the steady.
9. Loosen the lock nut **1**.
10. Turn the stop screw **2** to the left until the stop screw **2** is completely unscrewed.
11. **Condition for closing the steady on the pusher:** selection **Steady**, Selection option **Roller steady** set. ➔ “Enter the selection option” on page 56.
12. **Condition for closing the steady on the pusher:** close the collet of the lathe.


13. ➤ Close the steady by pressing the  button.
 - ➔ The status display on the button turns green. The steady is closed.
14. ➤ Turn the stop screw  to the right until you feel resistance.
15. ➤ Turn the stop screw  approx. half a turn counterclockwise.
16. ➤ Tighten the lock nut .
 - ➔ The end stop for the open position is set
17. ➤ Open the steady using the  button.
 - ➔ The status display on the button is off. The steady is open.
18. ➤ **When used as a roller steady:** selection **Steady**, Selection option **Roller steady** set. ➔ “Enter the selection option” on page 56.
19. ➤ **When used as a jaw steady:** selection **Steady**, Selection option **Jaw steady** set. ➔ “Enter the selection option” on page 56.

Installing/removing rollers with holder (steady with material passage 26 mm)





The described procedure refers to the steady with a material passage of up to 26 mm.

1. ➤ Press the emergency stop button. ➔ “Press the emergency stop button” on page 46.
2. ➤ Switch off the compressed air supply. ➔ “Switch the supply of compressed air on/off” on page 112
3. ➤ Loosen the screws  and remove.
4. ➤ Remove the lid .



5. ➤ Loosen and remove the screw .
6. ➤ Remove top rollers  with holder upwards.
7. ➤ Remove bottom rollers with holder in the same way.
8. ➤ Insert the rollers with holder in reverse order.






9. ➤ Position the cover **2**.
10. ➤ Insert and tighten the screws **1**.
11. ➤ Switch on the compressed air supply. ➔ "Switch the supply of compressed air on/off" on page 112
12. ➤ Unlock the emergency stop button. ➔ "Make the loading magazine ready for operation after the emergency stop" on page 46
13. ➤ Acknowledge the error message by pressing the **CLR** button.


Installing/removing rollers with holder (steady with material passage 38 mm)




The described procedure refers to the steady with a material passage of up to 38 mm.



1. ➤ Press the emergency stop button. ➔ "Press the emergency stop button" on page 46.
2. ➤ Switch off the compressed air supply. ➔ "Switch the supply of compressed air on/off" on page 112
3. ➤ Loosen the screws **1**.
4. ➤ Loosen the screw **2**.
5. ➤ Remove the lid **3**.



6. ➤ Loosen and remove the screw **4**.
7. ➤ Remove top rollers **5** with holder upwards.
8. ➤ Remove bottom rollers with holder in the same way.
9. ➤ Insert the rollers with holder in reverse order.





10. ➤ Position the cover **3**.
11. ➤ Tighten the screws **1**.
12. ➤ Insert and tighten the screw **2**.
13. ➤ Switch on the compressed air supply. ➔ "Switch the supply of compressed air on/off" on page 112
14. ➤ Unlock the emergency stop button. ➔ "Make the loading magazine ready for operation after the emergency stop" on page 46
15. ➤ Acknowledge the error message by pressing the **CLR** button.

Installing/removing guide jaws with holder (steady with material passage 26 mm)




The described procedure refers to the steady with a material passage of up to 26 mm.

1. ➤ Press the emergency stop button. ➔ "Press the emergency stop button" on page 46.
2. ➤ Switch off the compressed air supply. ➔ "Switch the supply of compressed air on/off" on page 112
3. ➤ Loosen the screws **1** and remove.
4. ➤ Remove the lid **2**.



5. ➤ Loosen and remove the screw **3**.
6. ➤ Remove top guide jaws **4** with holder.
7. ➤ Remove bottom guide jaws with holder in the same way.
8. ➤ Insert the guide jaws with holder in reverse order.





9. ➤ Position the cover **2**.
10. ➤ Insert and tighten the screws **1**.
11. ➤ Switch on the compressed air supply. ➤ *“Switch the supply of compressed air on/off” on page 112*
12. ➤ Unlock the emergency stop button. ➤ *“Make the loading magazine ready for operation after the emergency stop” on page 46*
13. ➤ Acknowledge the error message by pressing the **CLR** button.

Installing/removing guide jaws with holder (steady with material passage 38 mm)




The described procedure refers to the steady with a material passage of up to 38 mm.

1. ➤ Press the emergency stop button. ➤ *“Press the emergency stop button” on page 46.*
2. ➤ Switch off the compressed air supply. ➤ *“Switch the supply of compressed air on/off” on page 112*
3. ➤ Loosen the screws **1**.
4. ➤ Loosen the screw **2**.
5. ➤ Remove the lid **3**.



6. ➤ Loosen and remove the screw **4**.
7. ➤ Remove top guide jaws **5** with holder.
8. ➤ Remove bottom guide jaws with holder in the same way.
9. ➤ Insert the guide jaws with holder in reverse order.





10. ➤ Position the cover 3.
11. ➤ Tighten the screws 1.
12. ➤ Insert and tighten the screw 2.
13. ➤ Switch on the compressed air supply. ➤ *“Switch the supply of compressed air on/off” on page 112*
14. ➤ Unlock the emergency stop button. ➤ *“Make the loading magazine ready for operation after the emergency stop” on page 46*
15. ➤ Acknowledge the error message by pressing the CLR button.

Changing the guide jaws (steady with material passage 26 mm)




The described procedure refers to the steady with a material passage of up to 26 mm.

1. ➤ Press the emergency stop button. ➤ *“Press the emergency stop button” on page 46.*
2. ➤ Switch off the compressed air supply. ➤ *“Switch the supply of compressed air on/off” on page 112*
3. ➤ Loosen the screws 1 and remove.
4. ➤ Remove the lid 2.



5. ➤ Loosen and remove the screw 3.
6. ➤ Remove top guide jaw 4.
7. ➤ Remove bottom guide jaw in the same way.
8. ➤ Install the guide jaws in reverse order.





9. ➤ Position the cover **2**.
10. ➤ Insert and tighten the screws **1**.
11. ➤ Switch on the compressed air supply. ➔ "Switch the supply of compressed air on/off" on page 112
12. ➤ Unlock the emergency stop button. ➔ "Make the loading magazine ready for operation after the emergency stop" on page 46
13. ➤ Acknowledge the error message by pressing the **CLR** button.

Changing the guide jaws (steady with material passage 38 mm)




The described procedure refers to the steady with a material passage of up to 38 mm.

1. ➤ Press the emergency stop button. ➔ "Press the emergency stop button" on page 46.
2. ➤ Switch off the compressed air supply. ➔ "Switch the supply of compressed air on/off" on page 112
3. ➤ Loosen the screws **1**.
4. ➤ Loosen and remove the screws **2**.
5. ➤ Remove the lid **3**.




6. ➤ Loosen and remove the screw **4**.
7. ➤ Remove top guide jaw **5**.
8. ➤ Remove bottom guide jaw in the same way.
9. ➤ Install the guide jaws in reverse order.



10. Position the cover **3**.
11. Tighten the screws **1**.
12. Insert and tighten the screws **2**.
13. Switch on the compressed air supply. ➔ *“Switch the supply of compressed air on/off” on page 112*
14. Unlock the emergency stop button. ➔ *“Make the loading magazine ready for operation after the emergency stop” on page 46*
15. Acknowledge the error message by pressing the **CLR** button.

7.5 Separating device

Separation device, general



1	Ejectors	4	Lateral material storage
2	End stop of the ejectors	5	Holding-down device
3	Material bar		

Thanks to the separation device of the loading magazine, the material bars are stocked and separated for the bar change.

The separation device consists of the lateral material storage, the ejectors, the end stop of the ejectors and the holding-down device.


The material bars are kept in the lateral material storage. Thanks to the angle of the lateral material storage, the material bars slide towards the guide channel. The holding-down device limits the height of the lateral material storage, so that the material bars do

not roll over each other. The end stop of the ejectors is set up so that only one material bar lies on the ejectors. The ejectors move up and lift a material bar into the guide channel.

To adjust the separation device to the respective material bar diameter, the following components have to be set.

- The height of the holding-down device
- End stop of the ejectors

Height of the holding-down device



The holding-down devices are set via the dimension **B**. The dimension **B** is measured from the lower edge of the holding-down device **1** to the storage area of the lateral material storage **2**.

For the dimension **B**:

- The diameter of the current material bar to be processed + 1 mm.

Setting the height of the holding-down device

WARNING

Falling material bar

Personal injury due to squashing and impact as a result of a falling material bar.


Material bars which are located on the lateral material storage, may fall down during conversion work.

- Before conversion work, remove the material bars from the lateral material storage.



1. ➤ Press the emergency stop button. ➔ *"Press the emergency stop button" on page 46.*
2. ➤ Switch off the compressed air supply. ➔ *"Switch the supply of compressed air on/off" on page 112*
3. ➤ Where necessary, obtain release from the lathe to open the cover.
4. ➤ Open the cover.
5. ➤ Loosen the clamping lever **1**.
6. ➤ Move the holding-down device **2** to the desired height.
7. ➤ Close the clamping lever **1**.
8. ➤ Set the rest of the holding-down devices in the same way.
9. ➤ Close the cover.
10. ➤ Switch on the compressed air supply. ➔ *"Switch the supply of compressed air on/off" on page 112*
11. ➤ Unlock the emergency stop button. ➔ *"Make the loading magazine ready for operation after the emergency stop" on page 46*
12. ➤ Acknowledge the error message using the **CLR** button.

End stop of the ejectors



The end stop of the ejectors is set by the dimension **A**. The dimension **A** is measured from the front edge of the ejectors **1** to the front edge of the end stop of the ejectors **2**.

For the dimension **A** the following applies:

- The diameter of the current material bar to be processed.

Setting the end stop of the ejectors


WARNING

Falling material bar

Personal injury due to squashing and impact as a result of a falling material bar.

Material bars which are located on the lateral material storage, may fall down during conversion work.

- Before conversion work, remove the material bars from the lateral material storage.



1. ➤ Press the emergency stop button. ➔ *"Press the emergency stop button" on page 46.*
2. ➤ Switch off the compressed air supply. ➔ *"Switch the supply of compressed air on/off" on page 112*
3. ➤ Where necessary, obtain release from the lathe to open the cover.
4. ➤ Open the cover.
5. ➤ Loosen the taper spanner 1.
6. ➤ Move the handle 2 in the direction indicated by the arrow to set the desired distance.
7. ➤ Close the taper spanner 1.
8. ➤ Close the cover.
9. ➤ Switch on the compressed air supply. ➔ *"Switch the supply of compressed air on/off" on page 112*
10. ➤ Unlock the emergency stop button. ➔ *"Make the loading magazine ready for operation after the emergency stop" on page 46*
11. ➤ Acknowledge the error message by pressing the CLR button.

8 Maintenance

8.1 Maintenance actions

Maintenance plan

Chap.	Task to perform	Every 6 months	Every 36 months	If necessary	Page
	Check the drive belt	X			107
	Check the synchronizing unit belt	X			108
	Replace the relay insert in the control cabinet		X		109
	Check the blades of the material gripper	X			109
	Check the lubricant in the oil tank			X	110

Check the drive belt

DANGER

Moving components of the loading magazine and the tool machine with the cover open

Personal injury due to squashing, impact or striking by movements of the loading magazine and the machine tool with the cover open.

During maintenance work on the loading magazine, there may be unexpected movements of the components of the loading magazine and the machine tool.

- Turn off the machine tool at the main switch, before performing maintenance work. Observe the sequence of the working steps according to the descriptions listed below.

CAUTION

Sharp knives of the material gripper

Cuts due to the sharp knives of the material gripper.

When working in the vicinity of the material gripper, there is a risk of cuts in the event of inattentiveness.

- Wear safety gloves.



Condition of the drive belt:

If the drive belt has cracks or is missing teeth, it must be replaced. Contact FMB. ➔ "Service contact details" on page 119.

1. ➔ Press the emergency stop button. ➔ "Press the emergency stop button" on page 46.
2. ➔ Switch off the supply of compressed air. ➔ "Switch the supply of compressed air on/off" on page 112
3. ➔ Where necessary, obtain release from the lathe to open the cover.
4. ➔ Open the cover.

5. ➤ Turn off the machine tool at the main switch.
6. ➤ Check the condition: Check the drive belt visually for missing teeth.
7. ➤ Close the cover.
8. ➤ Turn on the machine tool at the main switch.
9. ➤ Switch on the compressed air supply. ➤ *“Switch the supply of compressed air on/off” on page 112*
10. ➤ Unlock the emergency stop button. ➤ *“Make the loading magazine ready for operation after the emergency stop” on page 46*
11. ➤ Acknowledge the error message by pressing the  button.

Check the synchronizing unit belt

DANGER

Moving components of the loading magazine and the tool machine with the cover open

Personal injury due to squashing, impact or striking by movements of the loading magazine and the machine tool with the cover open.

During maintenance work on the loading magazine, there may be unexpected movements of the components of the loading magazine and the machine tool.

- Turn off the machine tool at the main switch, before performing maintenance work. Observe the sequence of the working steps according to the descriptions listed below.

CAUTION

Sharp knives of the material gripper

Cuts due to the sharp knives of the material gripper.

When working in the vicinity of the material gripper, there is a risk of cuts in the event of inattentiveness.

- Wear safety gloves.



Condition of the synchronizing unit belt:

If the synchronizing unit belt has cracks or is missing teeth, the synchronizing unit belt must be replaced. Contact FMB. ➤ “Service contact details” on page 119.

1. ➤ Press the emergency stop button. ➤ *“Press the emergency stop button” on page 46.*
2. ➤ Switch off the supply of compressed air. ➤ *“Switch the supply of compressed air on/off” on page 112*
3. ➤ Where necessary, obtain release from the lathe to open the cover.
4. ➤ Open the cover.
5. ➤ Turn off the machine tool at the main switch.
6. ➤ Check the condition: Check the synchronizing unit belt visually for cracks and missing teeth.
7. ➤ Close the cover.
8. ➤ Turn on the machine tool at the main switch.

9. ➤ Switch on the compressed air supply. ➔ *"Switch the supply of compressed air on/off" on page 112*
10. ➤ Unlock the emergency stop button. ➔ *"Make the loading magazine ready for operation after the emergency stop" on page 46*
11. ➤ Acknowledge the error message by pressing the  button.

Replace the relay insert in the control cabinet

DANGER

Live components of the control cabinet

Personal injury by electrical shock due to contact with live components of the control cabinet.

This work is only allowed to be performed by a qualified electrician.

- Turn off the machine tool before starting work on the main switch.



The relay insert for changing signals with the lathe must be replaced regularly. In the event of uncertainty, please contact FMB. ➔ "Service contact details" on page 119.

1. ➤ Turn off the machine tool before starting work on the main switch.
2. ➤ Disconnect the relay insert in the control cabinet of the loading magazine.
3. ➤ Insert the new relay insert in the control cabinet of the loading magazine.

Check the blades of the material gripper

DANGER

Moving components of the loading magazine and the tool machine with the cover open

Personal injury due to squashing, impact or striking by movements of the loading magazine and the machine tool with the cover open.

During maintenance work on the loading magazine, there may be unexpected movements of the components of the loading magazine and the machine tool.

- Turn off the machine tool at the main switch, before performing maintenance work. Observe the sequence of the working steps according to the descriptions listed below.

CAUTION

Sharp knives of the material gripper

Cuts due to the sharp knives of the material gripper.

When working in the vicinity of the material gripper, there is a risk of cuts in the event of inattentiveness.

- Wear safety gloves.
1. ➤ Press the emergency stop button. ➔ *"Press the emergency stop button" on page 46.*
 2. ➤ Switch off the supply of compressed air. ➔ *"Switch the supply of compressed air on/off" on page 112*

3. ➤ Where necessary, obtain release from the lathe to open the cover.
4. ➤ Open the cover.
5. ➤ Turn off the machine tool at the main switch.
6. ➤ Check the material gripper visually for breaks.
7. ➤ If the blades of the material gripper break off, the blades of the material gripper must be replaced. .
8. ➤ Close the cover.
9. ➤ Turn on the machine tool at the main switch.
10. ➤ Switch on the compressed air supply. ➤ *“Switch the supply of compressed air on/off” on page 112*
11. ➤ Unlock the emergency stop button. ➤ *“Make the loading magazine ready for operation after the emergency stop” on page 46*
12. ➤ Acknowledge the error message by pressing the  button.

Check the lubricant in the oil tank

WARNING

Leaking fuel

Personal injuries due to slipping on leaking fuel.

Leaking fuel causes a slipping hazard in the working area.

- Remove leaking fuel immediately.
- Observe the description in the operating instructions about filling / emptying the oil tank.
- Only fill fuel in the intended containers.

1. ➤ Check the lubricant in the oil tank for the formation of foam.
2. ➤ Check the lubricant in the oil tank for severe contamination.
3. ➤ If the lubricant forms foam in the oil tank, or is severely contaminated, the lubricant in the oil tank must be replaced.
➤ *“Empty the oil tank of the loading magazine” on page 111.*

Filling the oil tank of the loading magazine

WARNING

Leaking fuel

Personal injuries due to slipping on leaking fuel.

Leaking fuel causes a slipping hazard in the working area.


- Remove leaking fuel immediately.
- Observe the description in the operating instructions about filling / emptying the oil tank.
- Only fill fuel in the intended containers.



Observe the oil tank level.



Observe the stated types of oil.



1. ➤ Press the emergency stop button. ➔ *"Press the emergency stop button" on page 46.*
2. ➤ Switch off the compressed air supply. ➔ *"Switch the supply of compressed air on/off" on page 112*
3. ➤ Turn off the machine tool at the main switch.
4. ➤ Pull the oil return line out of the oil return hole [5].
5. ➤ Fill the stated quantity of oil into the oil return hole [5].
6. ➤ Guide the oil return line to the oil return hole [5].
7. ➤ Turn on the machine tool at the main switch.
8. ➤ Switch on the compressed air supply. ➔ *"Switch the supply of compressed air on/off" on page 112*
9. ➤ Unlock the emergency stop button. ➔ *"Make the loading magazine ready for operation after the emergency stop" on page 46*
10. ➤ Acknowledge the error message by pressing the **CLR** button.

Empty the oil tank of the loading magazine

⚠ DANGER

Moving components of the loading magazine and the tool machine with the cover open

Personal injury due to squashing, impact or striking by movements of the loading magazine and the machine tool with the cover open.

During maintenance work on the loading magazine, there may be unexpected movements of the components of the loading magazine and the machine tool.

- Turn off the machine tool at the main switch, before performing maintenance work. Observe the sequence of the working steps according to the descriptions listed below.

⚠ WARNING

Leaking fuel

Personal injuries due to slipping on leaking fuel.

Leaking fuel causes a slipping hazard in the working area.

- Remove leaking fuel immediately.
- Observe the description in the operating instructions about filling / emptying the oil tank.
- Only fill fuel in the intended containers.

i

Observe the oil tank level. ➔ *"Technical data of the loading magazine" on page 12.*


i

Before the next operation of the loading magazine, the oil tank of the loading magazine must be refilled. ➔ *"Filling the oil tank of the loading magazine" on page 110.*

i

To empty the oil tank, a suitable pump has to be used.

1. ➤ Press the emergency stop button. ➔ *"Press the emergency stop button" on page 46.*



2. ➤ Switch off the compressed air supply. ➡ *"Switch the supply of compressed air on/off" on page 112*
3. ➤ Turn off the machine tool at the main switch.
4. ➤ Prepare a suitable container with sufficient capacity to collect the oil.
5. ➤ Loosen the tube clip on the oil feed 1.
6. ➤ Remove the oil feed line on the oil feed 1.
7. ➤ Guide the end of the removed oil feed line into the container provided.
8. ➤ Pump the whole contents of the oil tank into the container provided, using a suitable pump.
9. ➤ Insert the oil feed line onto the oil feed 1.
10. ➤ Tighten the tube clip on the oil feed 1.
11. ➤ Turn on the machine tool at the main switch.
12. ➤ Switch on the compressed air supply. ➡ *"Switch the supply of compressed air on/off" on page 112*
13. ➤ Unlock the emergency stop button. ➡ *"Make the loading magazine ready for operation after the emergency stop" on page 46*
14. ➤ Acknowledge the error message by pressing the CLR button.

Switch the supply of compressed air on/off



The supply of compressed air is switched on/off at the maintenance unit 1.


- Switch the supply of compressed air on/off at the knob 2.

8.2 Auxiliary equipment

Shifting the loading magazine




This function is available as an option.



The shifting device **1** is located between the support and the beam of the loading magazine. The procedure is described using the example of a support. To shift the loading magazine, the shifting device must be activated on each support.



*The screws **2** must be used in alternating positions depending on the shifting positions. Several drill holes are intended for this.*



1. ➤ Press the emergency stop button. ➔ "Press the emergency stop button" on page 46.
2. ➤ Switch off the compressed air supply. ➔ "Switch the supply of compressed air on/off" on page 112
3. ➤ Loosen the screws **2** and remove.
4. ➤ Pull and hold the locking pin **3**.
5. ➤ Shift the loading magazine up to the stop.
6. ➤ Release the locking pin **3**.
7. ➤ Insert and tighten the screws **2**.
8. ➤ Switch on the compressed air supply. ➔ "Switch the supply of compressed air on/off" on page 112
9. ➤ Unlock the emergency stop button. ➔ "Make the loading magazine ready for operation after the emergency stop" on page 46
10. ➤ Acknowledge the error message using the **CLR** button.

Performing a reference run



If the drive of the loading magazine is moved manually in switched-off condition, it causes the position of the PLC control unit to be lost. In this case, a reference run must be performed.

1. ➤ Press the **Menu** button.
2. ➤ **SETTINGS** → **Service settings** → **Position diagnosis**
3. ➤ Press the **Enter** button.
4. ➤ Press the **Reference run** button.
 - ➔ The status display on the button flashes yellow. The reference run is performed. The status display on the button turns green. The reference run is ended.

9 Faults

9.1 Fault messages

Display the current fault message

The current fault message is shown in the upper area of the control panel.

Delete the current fault message

→ Press the  button.

Display of pending fault messages in the fault list

1. → Press the  button.
2. → *'DIAGNOSIS → Fault list'*

Delete fault messages in the fault list

1. → Press the  button.
2. → *'DIAGNOSIS → Fault list'*

Delete an error message:

1. → Click on error message.
2. → Delete the error message with the  button.

Delete all error message:

1. → Click on error message.
2. → Delete the error message with the  button.

Access the fault history

1. → Press the  button.
2. → *'DIAGNOSIS → Fault list'*
3. → Press the  button.

Display the position of the current fault on the loading magazine

1. → Press the  button.
2. → *'DIAGNOSIS → Fault list'*
3. → Press the  button.

9.2 Fault table

Fault message and possible cause

Fault message of the loading magazine	Possible cause	Switch / position
Axis 1 fault, code: xx	The servo drive issues a fault message.	
Starting switch -B7 not in home position -KK5/B7	The starting switch is not back in its home position. ■ Air flow disrupted ■ Solenoid valve -KK5 not working	Starting switch not in the home position. Switch -B7 not actuated.
Starting switch -B7 not in the home position -KK9/B7	The starting switch is not back in its home position. ■ Air flow disrupted ■ Solenoid valve -KK9 not working	Starting switch not in the home position. Switch -B7 not actuated.
Press upon not correct; Pos. material draw-off not reached	The clamping sleeve was not pressed, or not pressed completely, onto the material bar. ■ Feed force for press upon too low. ■ Incorrect clamping sleeve. ■ New clamping sleeve.	Position Position draw off has been reached.
Storage empty! No new bar reloaded -B80	There is no material bar in the lateral material storage.	Switch -B80 not actuated.
Diameter setting of channel -M3	The monitoring time has expired. The diameter setting was not performed. The desired value of the channel diameter setting does not agree with the actual value.	
Diameter setting of separation M4/B8	The monitoring time has expired. The diameter setting was not performed. The desired value of the separation diameter setting does not agree with the actual value.	
Motor speed controller not ready for operation - TA1/K3	Fault on the drive motor speed controller.	
Guide channel not closed; Check guide channel - KK01/B6/B26/B28	The guide channel is not closed. ■ Solenoid valve -KK01 not working. ■ Air flow disrupted.	Switch -B6 or -B26 not actuated.
Opening – closing of guide channel not correct -KK1/ KK01/B5/B6/B26/B28	Guide channel not opened or closed correctly. ■ Solenoid valve -KK1 or -KK01 not working. ■ Air flow disrupted.	Switch -B5, -B6, or -B26 not actuated.
No stop in the lathe	Caution selection First insert To stop set! The material bar was not stopped by an end stop in the working area of the lathe.	

Fault message of the loading magazine	Possible cause	Switch / position
No return of remnant -B13	Remnant remains in the lathe. The material gripper did not grab any remnant when removing the remnant. ■ The lathe collet does not open correctly. The remnant fell out of the clamping sleeve when returning. The material gripper did not grab any remnant when removing the remnant. ■ Clamping sleeve pressure too low.	Switch -B13 was actuated.
No new bar in guide channel -B13	The material gripper does not grab any material bars when drawing on ■ No material bar was loaded from the lateral material storage.	Switch -B13 was actuated.
No air pressure! -B11 Check air pressure min. 5 bar	The compressed air is too low, or is lacking, on the maintenance unit. ■ Air supply disturbed	Switch -B11 not actuated.
Magazine not in start position; Start position step 1,15,17 or 19	The loading magazine is not in one of the possible starting positions: step 1, step 15, step 17 or step 19.	
Material on the lateral storage -B80	Material bars are located in the lateral material storage.	Switch -B80 actuated.
Material bar loaded in test run	Test mode active. In test mode, there must be no material bars on the lateral material storage.	
Max fill level of the loading magazine lubricant container reached	The maximum fill level of the lubricant container was reached.	
Motor protection -F1 tripped! -M1/F1 Check -M1, switch -F1 on	The drive motor of the loading magazine was overloaded.	Motor protection switch -F1 was triggered.
Motor protection -F2 tripped! -M2/F2 Check -M2, switch -F2 on	The motor of the oil pump was blocked or overloaded.	Motor protection switch - F2 was triggered.
Motor overload switch F3 triggered! check -M3/F3 - M3, activate F3	Drive motor of the pilgrim step separation was overloaded.	Motor protection switch -F3 was triggered.
Neg.software end position was overrun. Release with manual forward function	The negative software stop was overrun.	
Emergency Stop lathe	The emergency stop button of the lathe was actuated.	
Emergency Stop loading magazine -S69	The emergency stop button on the loading magazine was actuated.	

Fault message of the loading magazine	Possible cause	Switch / position
Pilgrim step separation not in position / not empty - B83/B81/B82	The pilgrim step separation is not in position. ■ Pilgrim step separation was lowered without authorization. ■ Pilgrim step separation was raised without authorization. ■ The pilgrim step separation cycle was interrupted.	
Pos.software end position was overrun. Release with manual return function	The positive software stop was overrun.	
Profibus/Profinet - No live signal from the lathe	The connection of Profibus / Profinet to the machine tool is defective.	
Relay tumbler -K225	Malfunction of the channel lock module. Relay -K225 not working.	
Remnant jammed in clamping sleeve -B13	The remnant was not correctly extracted from the clamping sleeve and is still in the gripping area. The material gripper closes to check the remnant ejection and then grabs the available remnant. ■ The clamping sleeve pressure is not right. ■ The blades of the material gripper are worn. ■ The pressure of the material gripper is too low. The remnant did not fall correctly into the remnant bin and is still in the gripping area. The material gripper closes to check the remnant ejection and then grabs the remaining remnant. ■ The remnant flap is oily. The remnant remains stuck on the remnant flap.	Switch -B13 was not actuated.
Remnant flap not closed - KK010/B17	The remnant flap does not close. ■ Solenoid valve -KK010 does not switch. ■ Air flow disrupted.	Switch -B17 not actuated.
Remnant too long	The "Maximum remnant length" function is active. The length of the remnant exceeds the entered value.	
Pushing signal not ok; Check signal from lathe	The signal "collet open" is transferred by the lathe in an unstable way to the loading magazine (the signal bounces). ■ Defective connection ■ Relay worn (on the lathe side)	

Fault message of the loading magazine	Possible cause	Switch / position
Sensor of the pilgrim step separation support contaminated -B83	- The light reflection for the stable detection of a material bar is not sufficient. - Sensor head (light guide) of switch -B83 is damaged or dirty.	
Signal sliding-fixed head-stock lathe mode does not match shifting device - B71/B76	The external signal of the machine tool (long or short turning mode) does not agree with the position of the shifting device.	
Collet in the lathe closed	Caution selectionDraw on bar with first insert set! The collet of the lathe is not open. First insert cannot be performed. The collet position signal is not available in manual mode.	
Collet closed too long	Collet monitoring time expired.	
Collet opened too long	Collet monitoring time expired.	
Bar has been pushed back	Caution Max. bar return active. The material bar was moved back past the set value when closing the collet. Lathe clamping system not OK.	
Part follow-up too short	Caution Min. part length follow-up active. The entered value was not reached when pushing the material bar. - Feed force too low. - The collet signal is unstable.	
Part follow-up too long	Caution Max. part length follow-up active. The entered value was exceeded when pushing the material bar. End stop in the lathe overrun.	
Cover not closed - B76/B77/B78/B79/K20/K21	The cover (guide channel cladding) or the lid of the steady is not closed.	Switch -B71, -B76, -B77, -B78, or -B79 not actuated.
Shifting device -B71/B76	The shifting device is in a non-permitted position.	Switch -B71 and -B76 not actuated.
Pusher not swung in correctly -KK08/B23	Pusher incorrectly swung in. - Solenoid valve -KK08 does not switch. - Air flow disrupted.	Switch -B23 does not switch.

Fault message of the loading magazine	Possible cause	Switch / position
Pusher out of position	Caution Part length internal or Part length external active. The pusher was moved during processing. ■ Vibrations to the material bar. ■ Lathe clamping system not OK. ■ Brake not switched on. ■ Braking force too low.	
Z-axis collision	The entered value for rotary encoder B4 was not met.	
Monitoring time motor expired	The moving signal is constantly on. The motor pushes against resistance. ■ Problem with the lathe work flow.	
The monitoring time of motor -M3 pilgrim step separation has expired -B81	The motor did not end the single cycle after approx. 10 seconds.	Switch -B81 does not switch.
Monitoring time bar change expired; Fault at bar change	The bar change was unable to be performed correctly. Monitoring time expired.	

9.3 Service

Service contact details

Service telephone no.	+49 9392 801 801
Telephone no. of the headquarters	+49 9392 801 0
Fax	+49 9392 801 220
Email	info@fmb-machinery.de

9.4 Technical problems

Behavior of the loading magazine in the event of a power failure

In the event of a power failure, the operation of the loading magazine is interrupted. The pressurisation of the pneumatic valves is interrupted. All parameters are saved and are available again once the power supply is reestablished.

Material bar stuck in the guide channel

It may be the case that the material bar does not lie completely in the guide channel when the guide channel is closed, and becomes stuck. This is caused by the usually bad material quality or an incorrect setting of the separation device. The correct procedure to loosen a stuck material bar depends on different factors. If the material bar is stuck, please contact FMB. ➔ *“Service contact details” on page 119.*

10 Index

B

Bar

Reloading. 66

Brake function

Switching on/off. 73

C

Capacity adjustment set. 76

CE marking. 8

Centering sleeve. 60

Changing. 60

Clamping device. 60

Changing. 60

Clamping mandrel. 60

Changing. 60

Clamping sleeve. 60

Changing. 60

Compressed air supply

Setting. 31

Switching on/off. 112

Connection of the loading magazine and the lathe

Electrical connection. 29

Connection of the loading magazine and the machine tool

Contacts from the loading magazine to the machine tool. 29

Contacts from the machine tool to the loading magazine. 30

Contacts from the loading magazine to the machine tool. 29

Contacts from the machine tool to the loading magazine. 30

Control cabinet

Attaching to the loading magazine. 34

Setting up. 34

Control panel

Explanation of symbols. 45

Layout. 44

Navigation. 44

Conversion

Separation device. 102

Converting

Change the insert of the bottom front guide channel. 87

Changing the insert of the bottom rear guide channel. 82

Changing the insert of the top front guide channel. 84

Changing the short pusher flag. 80

End stop of the ejectors. 105

Height of the holding-down device. 103

Setting the end stop of the ejectors. 106

Setting the height of the holding-down device. 104

Cover

Safety switch. 16

Cover of the loading magazine

Lock. 16

opening. 16

D

Date

Set the. 37

Delivery state. 27

Diameter of the material bar

Entering. 53

Dimensions

Loading magazine. 14

Distanceview. 37

Set the. 37

Drive. 9

Drive belt

Checking. 107

E

Ejectors. 105

Setting the end stop. 105, 106

Electrical connection of the loading magazine and

lathe. 29

Emergency stop

Emergency stop device. 16

Make the loading magazine ready for operation after the emergency stop. 46

Press the emergency stop button. 46

Explanation of symbols. 45

F

fault message

Access the fault history. 114

delete the current fault message. 114

Display of pending fault messages. 114

Display the position of the current fault on the loading magazine. 114

Fault message

show the current fault message. 114

Feed force

Feed force for part follow-up. 53

Feed force for part follow-up with sub-spindle. 58

Feed length

Entering. 54

Feed the material bar

Feed the multiple-sided material. 65

once. 62

Feed the multiple-sided material

bar. 65

Feeding the material bar

feed three times. 63

twice. 63

With the sub-spindle of the lathe. 64

Front end position

Setting the positional value. 37

Functional description. 9

G		Lubricant	14
Gripper.	9	Changing.	111
Guide channel		Checking for contamination.	110
Conversion work.	16	Discharging from the material bar.	75
Securing.	16	M	
Securing the open position.	16, 76	Maintenance plan.	107
Guide channel insert		Material	
Changing the bottom front insert.	87	Entering the material to be processed.	52
Changing the bottom rear insert.	82	Material bar	
Changing the top front insert.	84	Reloading.	66
Changing the top rear insert.	81	Removing from the loading magazine.	69
Guide module		Requirements.	59
Changing.	88	Material gripper.	9
H		Material storage	
Headstock position determination		Loading.	66
switching on/off.	59	Max. bar return	
Holding-down devices.	104	Setting.	57
Setting the height.	103	Max. remnant length	
I		Setting.	57
Interval insert.	65	Menus	
L		Navigation.	44
Language		N	
change.	38	Name plate.	8
Language settings		Navigation	
change.	38	Control panel.	44
Last material bar on the lateral material support		Menus.	44
Report.	66	No material bar in the lateral material storage	
Lateral material storage		Report.	66
Loading.	66	O	
Lathe		Oil.	14
Safety door.	16	Discharging from the material bar.	75
Lifting plates		Oil feed	
Changing.	78	Setting.	38
Load attachment gear		Oil pump	
Angle of inclination.	22	Setting the On position.	38
Loading magazine		Oil tank	
Aligning.	31	Connecting.	35
attach to means of transport.	26	Emptying.	111
Attaching to the floor.	33	Filling.	110
Calculate the distance to the loading magazine.	28	Setting up.	35
Detaching from the transport pallet.	22	Operating conditions.	13
Dimensions.	14	Overview	
Fastening to the transport pallet.	23	Components.	8
Functional description.	9	P	
Overview of components.	8	Packaging.	27
Setting up.	28	Part	
Shifting.	112	Entering the length.	53
switching off.	46	Parts counter.	47
switching on.	46	Personal safety equipment.	16
transport with means of transportation.	26	Pos. reverse rotation return	
Transporting using the crane.	23	Entering.	41
Transporting using the fork-lift truck.	25	Position draw off	
		Enter the	42

Power failure		Separation device.	102
Behavior of the loading magazine.	119	Shifting device.	112
Pressure		Short pusher flag	
Setting.	31	Changing.	80
Switching on/off.	112	Special equipment.	5
Process different part lengths.	64	Speed	
Product versions.	5	Acceleration Short pusher forward.	39
Profile		First insert.	56
Enter the profile of the material bar.	52	First insert low.	40
Program		Return from spindle.	41
Creating a new program.	51	Return high.	41
Editing.	52	Speed for part follow-up.	53
Push part		Speed for part follow-up sub-spindle.	59
select push once'.	62	Steady.	89
Push the part several times.	62	Adjusting to the material bar diameter.	91
Pusher		Changing the guide jaws.	100, 101
Changing.	78	Enter Position close steady.	40
Enter the length.	39	Enter Position open steady.	40
Guiding with the steady.	94, 95	Guiding the pusher.	94, 95
Pusher length		Installing/removing guide jaws with holder.	98, 99
Entering.	39	Installing/removing rollers with holder.	96, 97
Pushing the part		Lid.	16
Set push part twice.	63	Setting to the material bar diameter.	92
Set push three times.	63	Storage conditions.	13
With the sub-spindle of the lathe.	64	Supply pressure	
R		Switching on/off.	112
Reference run		T	
Performing a run.	113	Technical data	
Remnant		Loading magazine.	12
remove, eject and draw in the material bar.	70	Time	
Removing.	71	Set the	37
unload from the working area of the lathe.	48	Transport	
Remnant bin.	71	Angle of inclination of the load attachment gear.	22
Removing the remnant.	71	Transport beams	
Remnant flap		Assembling.	19
Changing the insert.	85	Removing.	20
Remnant flap insert		Transport lock.	20, 21
Changing.	85	Transporting	
Return speed shift.	41	loading magazine by means of transportation.	26
S		Loading magazine using the crane.	23
Safety		Loading magazine using the fork-lift truck.	25
Personal safety equipment.	16	Preparing the loading magazine for transportation	18
Safety bolts of the guide channel			
Inserting.	76	U	
Safety equipment.	16	Unit of measure	
selection		change.	38
Overview.	47	Unload	
Selection option		from the working area of the lathe.	48
Set the First insert.	54	V	
Set the Part follow-up.	54	Vibrations of the pusher.	94, 95
Selection options.	47		
Set the	56		
Selections.	47		
Enter the selection option.	56		



FMB Maschinenbaugesellschaft mbH & Co. KG

Paul-Hohe-Straße 1

97906 Faulbach

Telefon: +49 9392 801 0
Service: +49 9392 801 801
Fax: +49 9392 801 220

Mail: info@fmb-machinery.de
Web: www.fmb-machinery.de

Ersatzteilliste Spare parts list

turbo RS 3-38 Serie 1

Rückmeldenummer ab: 2153428

FMB zeichnet sich durch die Umsetzung kundenspezifischer Wünsche aus. Deshalb sind viele Standard-Baugruppen durch individuelle Anpassungen oder drehmaschinenbezogen modifiziert. Abweichende Ersatzteile für Anbauten oder Umbauten müssen daher über unseren Ersatzteilvertrieb ermittelt werden.

Achtung ! Angaben für Ersatzteilbestellung:

- **Magazintyp**
- **Magazinnummer**
- **Baujahr**
- **Bezeichnung**
- **Ident-Nummer**

FMB is characterized by the implementation of customer-specific requirements. Therefore, many standard modules are modified by individual adjustments or lathes related. Differing parts for attaching or modifications must therefore be determined from our spare parts sales.

Attention ! Data for spare parts orders:

- **Magazine type**
- **Magazine No.**
- **Year of construction**
- **Designation**
- **Ident No.**

Inhaltsverzeichnis

Contents

Grundaufbau / Basic construction	6
Antrieb / Drive	10
Lager vorne / Bearing front.....	12
Anfahrschalter komplett / Starting switch complete	14
Kanalöffner / Channel opener.....	16
Niederhalter / Holding-down device	20
Lünette D26 / Steady rest D26	22
Lünette D38 / Steady rest D38	24
Seitliche Materialauflage / Lateral material storage.....	26
Reststückklappe / Remnant flap.....	28
Reststückklappe 800 / Remnant flap 800.....	30
Greifer / Gripper	32
Reststückbehälter komplett / Remnant bin complete.....	36
Reststückbehälter komplett / Remnant bin complete.....	38
Synchroneinrichtung / Synchronized device	40
Sensor Synchroneinrichtung / Sensor Synchronized device	42
Abstützung Führungsmodul / Support guide module	44

Adapterset / Adapter set	46
Umbausatz – Vorschubstange 1666 Hub 400 / Vorschubstange 1866 Hub 600 Retrofit kit – Pusher 1666 stroke 400 / Pusher 1866 stroke 600	48
Umrüstsätze / Capacity adjustment sets	51
Abbildung / Drawing	51
Umrüstsätze / Capacity adjustment sets	52
Umrüstsätze 1466 Hub 400 / Capacity adjustment sets 1466 stroke 400	53
Umrüstsätze 1666 Hub 400 / Capacity adjustment sets 1666 stroke 400	54
Umrüstsätze 1666 Hub 600 / Capacity adjustment sets 1666 stroke 600	55
Umrüstsätze 1866 Hub 600 / Capacity adjustment sets 1866 stroke 600	56
Materialführungen / Material guide jaws	57
Führungsmodul / Guide module	58
Wartungseinheit / Maintenance unit.....	59
Pneumatikplan / Pneumatic diagram	61
Seite 1 / Page 1	62
Seite 2 / Page 2	63
Pneumatikteile / Pneumatic parts.....	64
Elektroteile / Electrical parts.....	66
Lademagazin / Loading magazine.....	66
Schalttafel / Switch board	69
Bedientableau / Control panel	73


FMB turbo RS 3-38

Abbildung / Drawing Variante A;D



Grundaufbau / Basic construction

Abbildung Variante / Drawing Variant A;D




Grundaufbau / Basic construction

Pos. Item	Ident-Nr. Ident. no.	Bezeichnung	Designation	Kommentar Remarks
1	100044100	Antrieb	Drive	
2	100098427	Zahnriemen 2200 VST 1466	Toothed belt 2200 Pusher 1466	
	100098976	VST 1666	Pusher 1666	
	200011117	VST 1866	Pusher 1866	
	100076623	Zahnriemen 3200 VST 1466	Toothed belt 3200 Pusher 1466	
	100060659	VST 1666	Pusher 1666	
	100078162	VST 1866	Pusher 1866	
	100085366	Zahnriemen 3800 VST 1466	Toothed belt 3800 Pusher 1466	
	200008475	VST 1666	Pusher 1666	
	100075650	VST 1866	Pusher 1866	
	100078650	Zahnriemen 4200 VST 1466	Toothed belt 4200 Pusher 1466	
	200008471	VST 1666	Pusher 1666	
	200008474	VST 1866	Pusher 1866	
	100100904	Zahnriemen 6200 VST 1466	Toothed belt 6200 Pusher 1466	
	100102150	VST 1666	Pusher 1666	
	200011877	VST 1866	Pusher 1866	
3	2051-648	Lager vorne	Bearing front	
4	100059025	Anfahrschalter Variante A;D	Starting switch Variant A;D	
	100075136	Anfahrschalter Variante B;C	Starting switch Variant B;C	
5	längenabhängig dependent on length	Kanalöffner	Channel opener	
6	2055-060	Niederhalter	Holding-down device	
7	100082275	Lünette D26 Variante A;D	Steady D26 Variant A;D	
	100077069	Lünette D26 Variante B;C	Steady D26 Variant B;C	
	100077530	Lünette D38 Variante A;D	Steady D38 Variant A;D	
	100082276	Lünette D38 Variante B;C	Steady D38 Variant B;C	

Grundaufbau / Basic construction

Abbildung Variante / Drawing Variant A;D





Grundaufbau / Basic construction

Pos. Item	Ident-Nr. Ident. no.	Bezeichnung	Designation	Kommentar Remarks
8	längenabhängig dependent on length	Seitliche Auflage A;D Seitliche Auflage B;C	Lateral material storage A;D Lateral material storage B;C	
9	100072011 100082121	Reststückklappe Variante A;D Reststückklappe Variante B;C	Remnant flap Variant A;D Remnant flap Variant B;C	
	100083017 100083049	Reststückklappe 800 Variante A;D Reststückklappe 800 Variante B;C	Remnant flap Variant 800 A;D Remnant flap Variant 800 B;C	Länge / length 6200
10	2074-975 2074-493	Greifer Variante A;D Greifer Variante B;C	Gripper Variant A;D Gripper Variant B;C	
11	100049340	Reststückbehälter kpl.	Remnant bin compl.	
	100049992	Reststückbehälter 800 kpl.	Remnant bin 800 compl.	Länge / length 6200
12	2035-428	Ölbehälter	Oil reservoir	
13	2041-038	Tauchpumpe	Submerged pump	
14	100059040	Synchroneinrichtung	Synchronized device	
	100098408	Synchroneinrichtung	Synchronized device	Länge / length 2200
15	200008719	Sensor Synchroneinrichtung	Sensor, synchronized device	
16	100073316 100075129	Abstützung Führungsmodul Variante A;D Abstützung Führungsmodul Variante B;C	Support, guide module Variant A;D Support, guide module Variant B;C	
17	100075672	Adapterset D26 Variante A;D	Adapter set D26 Variant A;D	
	100076176	Adapterset D26 Variante B;C	Adapter set D26 Variant B;C	
	100061159	Adapterset D38 Variante A;D	Adapter set D38 Variant A;D	
	100075123	Adapterset D38 Variante B;C	Adapter set D38 Variant B;C	

Antrieb / Drive

1000044100




Antrieb / Drive

1000044100

Pos. Item	Ident-Nr. Ident. no.	Bezeichnung	Designation	Kommentar Remarks
1	200004100	Servomotor	Servomotor	
	200006125	Servomotor mit Bremse	Servomotor with brake	-M1 (Option)
2	2034-836	Synchrone Scheibe z=20	Synchronized disk Z=20	
3	2034-844	Zahnscheibe Z 48-8M 20	Synchronized disk Z=48	
4	2047-772	Zahnriemen	Toothed belt	
5	2050-793	Gerätekurbel	Hand crank	
6	1095-641	Rillenkugellager 20x52x15	Grooved ball bearing 20x52x15	DIN 625
7	0469-238	Rillenkugellager 20x42x12	Grooved ball bearing 20x42x12	DIN 625

Lager vorne / Bearing front

2051-648



Lager vorne / Bearing front


2051-648

Pos. Item	Ident-Nr. Ident. no.	Bezeichnung	Designation	Kommentar Remarks
1	2001-188	Vierkantmutter M8 - 16x16x8	Square nut M8 - 16x16x8	
2	2050-925	Zahnscheibe Z44	Toothed disk Z44	
3	2050-926	Welle	Shaft	
4	2051-272	Einsatz für Kugellager	Insert for ball bearing	
5	2051-351	Grundplatte	Base plate	
6	2029-202	Radial-Wellendichtring	Rotary shaft seal	DIN 3760
7	0024-694	Sicherungsring A20x1,2	Retaining ring A20x1,2	DIN 471
8	0469-238	Rillenkugellager 20x42x12	Grooved ball bearing 20x42x12	DIN 625
9	1095-641	Rillenkugellager 20x52x15	Grooved ball bearing 20x52x15	DIN 625
10	0096-245	Passfeder 6x6x36	Feather key 6x6x36	DIN 6885
11	0313-025	Zylinderschraube M6x12	Cheese head screw M6x12	DIN 7984
12	1112-554	Stellring A20,2 +0,1	Adjusting ring A20,2 +0,1	DIN 705
13	2000-387	Federring A8	Spring washer A8	DIN 7980
14	2000-373	Zylinderschraube M8x16	Cheese head screw M8x16	DIN 7984

Anfahrschalter komplett / Starting switch complete

Variante / Variant A;D: 100059025 (Zeichnung/Drawing)

Variante / Variant B;C: 100075136



Anfahrschalter komplett / Starting switch complete


Variante / Variant A;D 100059025

Variante / Variant B;C 100075136

Pos. Item	Ident-Nr. Ident. no.	Bezeichnung	Designation	Kommentar Remarks
1	100059031	Anfahrschalterfahne	Flag for starting switch	
2	2051-671	Federklammer D20	Spring anchor D20	
3	2027-034	Federlasche	Spring shackle	
4	2027-033	Zugfeder 1,6x12x43x14	Tension spring 1,6x12x43x14	
5	2030-646	Zylinder	Cylinder	
6	2038-348	Steckverschraubung	Plug-in screwing	

Kanalöffner / Channel opener

Zeichnung Variante / Drawing Variant A;D




Kanalöffner / Channel opener

Pos. Item	Ident-Nr. Ident. no.	Bezeichnung	Designation	Kommentar Remarks
1	2051-372	Lagerbock	Bearing block	
2	2050-770	Scharnier	Hinge	
3	2051-812 2050-956 100060793 100075158	Kanaldeckel hinten A;D Hub 400 Kanaldeckel hinten B;C Hub 400 Kanaldeckel hinten A;D Hub 600 Kanaldeckel hinten B;C Hub 600	Cover rear A;D stroke 400 Cover rear B;C stroke 400 Cover rear A;D stroke 600 Cover rear B;C stroke 600	
4	2055-060	Niederhalter komplett	Holding down device complete	
5	2050-662	Achsbolzen für Zylinderbefestigung	Bolt	
6	2055-058	Zylinder	Cylinder	
7	2056-579	Schwenkflansch	Flange	
8	2001-382	Gabelkopf	Fork head	DIN 439
9	2050-763	Kniehebellasche	Bracket	
10	2050-765	Drehgelenkbolzen	Bolt	
11	2035-200	Achsbolzen	Bolt	
12	2055-760	Achsbolzen	Bolt	
13	2050-764	Schließleiste	Locking strip	
14	2038-346	Steckverschraubung	Plug-in screwing	
15	2052-602	Buchse 25x12,2x16	Bush 25x12,2x16	
16	0024-635	Sicherungsring 10x1,0	Retaining ring 10x1,0	DIN 471
17	0026-638	Sicherungsring 12x1,0	Retaining ring 12x1,0	DIN 471
18	2052-599	Achsbolzen	Bolt	
19	2055-059	Zylinder	Cylinder	
20	2035-479	Schwenkflansch	Slewing flange	

Kanalöffner / Channel opener

Zeichnung Variante / Drawing Variant A;D




Kanalöffner / Channel opener

Pos. Item	Ident-Nr. Ident. no.	Bezeichnung	Designation	Kommentar Remarks
21	2012-991	Gelenkkopf	Joint head	
22	100071192	Leiste für Zylinder	Strip for cylinder	
23	0302-678	Zylinderschraube M8x30	Cheese head screw M8x30	ISO 4762-8-8
24	0292-869	Federring B 8	Spring washer B 8	DIN 127
25	2001-188	Vierkantmutter M8 - 16x16x8	Square nut M8 - 16x16x8	
26	0387-320	Zylinderschraube M8x25	Cheese head screw M8x25	ISO 4762-8-8
27	2000-360	Zylinderschraube M8x45	Cheese head screw M8x45	DIN 912
28	nicht vorhanden not existend			
29	0302-597	Zylinderschraube M8x16	Cheese head screw M8x16	DIN 912
30	0302-368	Zylinderschraube M6x10	Cheese head screw M6x10	DIN 912
	2055-054	Sicherungsbolzen	Bolt	
	2011-646	Kugelmutter	Ball chain	
	2011-647	Schließe 3.6 mm für Kugelmutter	Closer 3.6 mm for ball chain	
	2011-648	Ring 16 mm	Ring 16 mm	

Niederhalter / Holding-down device

2055-060



Niederhalter / Holding-down device


2055-060

Pos. Item	Ident-Nr. Ident. no.	Bezeichnung	Designation	Kommentar Remarks
1	2054-726	Niederhalterführung	Guidance for holding-down device	
2	2055-825	Niederhalter	Holding-down device	
3	2000-403	Scheibe A10,5	Washer A10,5	DIN 125
4	0292-362	Scheibe A8,4	Washer A8,4	DIN 125
5	0292-877	Federring B10	Spring washer B10	DIN 127
6	0292-869	Federring B8	Spring washer B8	DIN 7980
7	2055-759	Tellerfeder 8,2x20x1	Cup spring 8,2x20x1	DIN 2093
8	0666-998	Sechskantmutter M8	Hexagonal nut M8	DIN 985
9	2054-483	Klemmhebel	Clamping lever	
10	0302-716	Zylinderschraube M8x50	Cheese head screw M8x50	ISO 4762
11	4000-725	Zylinderschraube M10x50	Cheese head screw M10x50	ISO 4762

Lünette D26 / Steady rest D26

100082275 Variante/Variant A;D

100077069 Variante/Variant B;C



Lünette D26 / Steady rest D26

100082275 Variante/Variant A;D


100077069 Variante/Variant B;C

Pos. Item	Ident-Nr. Ident. no.	Bezeichnung	Designation	Kommentar Remarks
1	2058-235	Distanz f. Rolle	Distace for roller	
2	2065-355	Halter f. Rollen	Holder for roller	
3	2058-243	Rolle	Roller	
4	2038-348	Steckverschraubung	Plug-in screwing	
5	2065-358	Zylinder	Cylinder	
6	2031-007	Scheibe	Washer	DIN 25201
7	2001-999	Zylinderschraube M10x30	Cheese head screw M10x30	DIN 6912
8	100077703	Sterngriff	Star grip	

Lünette D38 / Steady rest D38

100077530 Variante/Variant A;D

100082276 Variante/Variant B;C



Lünette D38 / Steady rest D38


100077530 Variante/Variant A;D

100082276 Variante/Variant B;C

Pos. Item	Ident-Nr. Ident. no.	Bezeichnung	Designation	Kommentar Remarks
1	2058-235	Distanz f. Rolle	Distace for roller	
2	100077531	Führung	Guidance	
3	2058-243	Rolle	Roller	
4	2038-346	Steckverschraubung	Plug-in screwing	
5	100077703	Sterngriff	Star grip	
6	2055-066	Zylinder	Cylinder	
7	2031-007	Scheibe	Washer	DIN 25201
8	2001-999	Zylinderschraube M10x30	Cheese head screw M10x30	DIN 6912

Seitliche Materialauflage / Lateral material storage

Zeichnung Variante / Drawing Variant A;D




Seitliche Materialauflage / Lateral material storage

Pos. Item	Ident-Nr. Ident. no.	Bezeichnung	Designation	Kommentar Remarks
1	2054-875 2054-876	Auflagebock vormontiert mit Anschlag A;D Auflagebock vormontiert mit Anschlag B;C bestehend aus:	Bearing support premounted with stop A;D Bearing support premounted with stop B;C Consisting of:	
1.1	2050-881	Stößel an Vereinzelung	Tappet on separation	
1.2	2055-919	Anschlag der Vereinzelung	Stop of separation	
1.3	2055-067	Skala	Scale	
2	10050779	Hebel komplett	Lever complete	
3	2054-571	Hebel D25 komplett sv	Lever D25 complete, side reversed	
4	2053-377	Klemmhebel	Clamping lever	
5	2041-158	Kugelknopf	Ball lever	
6	2055-066	Zylinder	Cylinder	
7	2001-382	Gabelkopf	Fork head	
8	2056-579	Schwenkflansch	Slewing flange	
9	2038-346	Steckverschraubeung	Plug-in screwing	
		Zusätzlich bei Länge 6200	Additionally at length 6200	
	2068-971	Kupplung D40x20x100	Coupling D40x20x100	
	2027-596	Kupplung D25	Coupling D25	
	2060-336	Stützplatte	Support plate	

Reststückklappe / Remnant flap

Variante / Variant A;D: 100072011 (Zeichnung/Drawing)

Variante / Variant B;C: 100082121



Reststückklappe / Remnant flap

Variante / Variant A;D: 100072011


Variante / Variant B;C: 100082121

Pos. Item	Ident-Nr. Ident. no.	Bezeichnung	Designation	Kommentar Remarks
1	100070996	Rinne	Groove	
2	2052-935	Welle	Shaft	
3	100072032	Verstellklotz	Adjusting block	
4	100072033	Kegelsicherung	Taper lock	
5	100071214	Rändelschraube	Knurled thumb srew	
6	2051-796 2050-670	Schiebehülse A;D Schiebehülse B;C	Sliding sleeve A;D Sliding sleeve B;C	
7	2050-669	Mitnehmer	Carrier	
8	2050-673	Rastbolzen	Stop bolt	
9	2050-672	Kurvenrolle	Cam roller	
10	2056-577	Zylinder	Cylinder	
11	2001-382	Gabelkopf	Fork head	
12	2038-346	Steckverschraubung	Plug-in screwing	

Reststückklappe 800 / Remnant flap 800

Variante / Variant A;D: 100083017 (Zeichnung/Drawing)

Variante / Variant B;C: 100083049



Reststückklappe 800 / Remnant flap 800

Variante / Variant A;D: 100083017



Variante / Variant B;C: 100083049

Pos. Item	Ident-Nr. Ident. no.	Bezeichnung	Designation	Kommentar Remarks
1	100083013	Rinne	Groove	
2	2060-193	Welle	Shaft	
3	100072031	Schwenkklotz geteilt	Swivel block split	
4	100082933	Schwenkklotz geteilt 600/800	Swivel block split 600/800	
5	100072032	Verstellklotz	Adjusting block	
6	100072033	Kegelsicherung	Taper lock	
7	100071214	Rändelschraube	Knurled thumb screw	
8	2060-958	Winkel Zylinder A;D	Angle cylinder A;D	
	2060-957	Winkel Zylinder B;C	Angle cylinder B;C	
9	2060-959	Gabelkopf verlängert	Fork head extended	
10	2050-669	Mitnehmer	Carrier	
11	2051-796	Schiebehülse A;D	Sliding sleeve A;D	
	2050-670	Schiebehülse B;C	Sliding sleeve B;C	
12	2058-185	Zylinder	Cylinder	
13	2038-346	Steckverschraubung	Plug-in screwing	
14	2050-672	Kurvenrolle	Cam roller	
15	2050-673	Rastbolzen	Stop bolt	

Greifer / Gripper

Variante / Variant A;D: 2074-975

Variante / Variant B;C: 2074-493



Greifer / Gripper

Variante / Variant A;D: 2074-975


Variante / Variant B;C: 2074-493

Pos. Item	Ident-Nr. Ident. no.	Bezeichnung	Designation	Kommentar Remarks
1	2050-948	Grundplatte	Base plate	
2	2050-946	Kulissenplatte	Guide plate	
3	2054-253	Führungsleiste oben	Guide gib, top	
4	2050-947	Führungsleiste unten	Guide gib bottom	
5	2050-412	Halter für Greiferarm	Holder for gripper arm	
6	2051-480	Greiferarm unten	Gripper arm, bottom	
7	2051-479	Greiferarm oben	Gripper arm, top	
8	2050-415	Sicherungsring A28	Retaining ring A28	DIN 471
9	2000-510	Sicherungsring A25	Retaining ring A25	DIN 471
10	2027-118	Rillenkugellager 25x47x12	Grooved ball bearing 25x47x12	DIN 625
11	1324-063	Messer oben	Blade, top	
12	0304-050	Gewindestift M8x10	Set screw M8x10	DIN 916 - 45 H
13	2050-949	Führungsstange	Guide bar	
14	2037-505	Scheibe 12	Washer 12	DIN 25201
15	2043-639	Zylinderschraube M12x25	Cheese head screw M12x25	DIN 912 - 10.9
16	2050-416	Glycodur-Buchse 22x25x30	Glycodur bush 22x25x30	
17	2001-188	Vierkantmutter M8 - 16x16x8	Square nut M8 - 16x16x8	
18	0292-869	Federring B8	Spring washer B8	DIN 127
19	2000-016	Gabelkopf	Fork head	DIN 439
20	2004-949	Sechskantmutter M10x1,25	Hexagonal nut M10x1,25	DIN 934
21	0387-320	Zylinderschraube M8x25	Cheese head screw M8x25	ISO 4762 - 8-8
22	0305-979	Senkschraube M8x20	Countersunk screw M8x20	DIN 933
23	2038-346	Steckverschraubung	Plug-in screwing	

Greifer / Gripper

Variante / Variant A;D: 2074-975

Variante / Variant B;C: 2074-493



Greifer / Gripper


Variante / Variant A;D: 2074-975

Variante / Variant B;C: 2074-493

Pos. Item	Ident-Nr. Ident. no.	Bezeichnung	Designation	Kommentar Remarks
24	2000-364	Sechskantschraube M8x25	Hexagonal screw M8x25	DIN 933 8-8
25	0292-362	Scheibe A8,4 ST	Washer A8,4 ST DIN 125	DIN 125
26	2001-128	Zylinderschraube M8x55	Cheese head screw M8x55	ISO 4762
27	0302-694	Zylinderschraube M8x40	Cheese head screw M8x40	DIN 912 - 8-8
28	0302-740	Zylinderschraube M8x70	Cheese head screw M8x70	DIN 912 - 8-8
29	2052-391	Gewindestift M10x16	Set screw M10x16	DIN 914
30	1324-055	Messer, unten	Blade, bottom	
31	2074-494	Haltewinkel	Angle	
32	2058-131	Zylinder	Cylinder	

Reststückbehälter komplett / Remnant bin complete

100049340



Reststückbehälter komplett / Remnant bin complete


100049340

Pos. Item	Ident-Nr. Ident. no.	Bezeichnung	Designation	Kommentar Remarks
1	2050-732	Reststückbehälter	Remnant bin	
2	2050-733	Abtropfblech	Drip plate	
3	2051-669	Einlagenwerkzeug komplett	Insert tool complete	
4	100045693	Deckel	Cover	

Reststückbehälter komplett / Remnant bin complete

100049340

100049992 Länge / length 4200/6200 800 mm



Reststückbehälter komplett / Remnant bin complete

100049340

Pos. Item	Ident-Nr. Ident. no.	Bezeichnung	Designation	Kommentar Remarks
1	2050-732	Reststückbehälter	Remnant bin	
2	2050-733	Abtropfblech	Drip plate	
3	2051-669	Einlagenwerkzeug komplett	Insert tool complete	
4	100045693	Deckel	Cover	

Reststückbehälter 800 komplett / Remnant bin 800 complete

100049992 Länge / length 4200/6200


Pos. Item	Ident-Nr. Ident. no.	Bezeichnung	Designation	Kommentar Remarks
1	2060-373	Reststückbehälter	Remnant bin	
2	2050-734	Abtropfblech	Drip plate	
3	2051-669	Einlagenwerkzeug komplett	Insert tool complete	
4	10004996	Deckel	Cover	

Synchroneinrichtung / Synchronized device

100059040

100098408 Länge/length 2200 Hub/stroke 400

100098903 Länge/length 2200 Hub/stroke 600



Synchroneinrichtung / Synchronized device

100059040


100098408 Länge/length 2200 Hub/stroke 400

100098903 Länge/length 2200 Hub/stroke 600

Pos. Item	Ident-Nr. Ident. no.	Bezeichnung	Designation	Kommentar Remarks
1	2030-195	Synchronstange	Synchronized bar	
2	100060295 100098154 100098904	Zahnriemen Zahnriemen 2200 Hub 400 Zahnriemen 2200 Hub 600	Toothed belt Toothed belt 2200 stroke 400 Toothed belt 2200 stroke 600	
3	2051-605	Mitnehmer für Synchronstange	Carrier for synchronized bar	
4	2035-080	Spannplatte	Clamping plate	
5	100044200	Umlenkrad komplett	Deflection wheel complete	
6	2055-542	Zahnscheibe Z44	Toothed disk Z44	
7	2000-197	Magnetteil Gr. 10	Magnetic part	
8	2000-195	Rotor Gr. 10	Rotor	

Sensor Synchroneinrichtung / Sensor Synchronized device

200008719



Sensor Synchroneinrichtung / Sensor Synchronized device


200008719

Pos. Item	Ident-Nr. Ident. no.	Bezeichnung	Designation	Kommentar Remarks
1	2069-696	Zahnscheibe Z22	Toothed disk Z22	
2	2070-054	Zahnscheibe Z36	Toothed disk Z36	
3	2069-692	Zahnriemen	Toothed belt	

Abstützung Führungsmodul / Support guide module

Variante / Variant A;D: 100073316 (Zeichnung / Drawing)

Variante / Variant B;C: 100075129



Abstützung Führungsmodul / Support guide module



Variante / Variant A;D: 100073316

Variante / Variant B;C: 100075129

Pos. Item	Ident-Nr. Ident. no.	Bezeichnung	Designation	Kommentar Remarks
1	100066230	Führungsbuchse	Guide bush	
2	100074318	Stehbolzen	Bolt	
3	100073710	Rolle	Roller	
4	100007948	Rastbolzen	Stop bolt	

Adapterset / Adapter set

100061159



Adapterset / Adapter set

100061159

Pos. Item	Ident-Nr. Ident. no.	Bezeichnung	Designation	Kommentar Remarks
1	100091280	Miniraster	Mini-grid	
2	2044-374	Steckverschraubung	Plug-in-screwing	
3	2002-055	Schlauchschelle	Hose clip	
4	2001-674	Schlauchtülle R3/4"	Hose nozzle R3/4"	
5	100103525	Schlauch	Hose	

Umbausatz – Vorschubstange 1666 Hub 400 / Vorschubstange 1866 Hub 600


Retrofit kit – Pusher 1666 stroke 400 / Pusher 1866 stroke 600

Vorschubstange 1666 Hub 400 / Pusher 1666 stroke 400: Variante/Variant A;D 200008352 – 3200

Variante/Variant B;C 200008354 – 3200

Vorschubstange 1866 Hub 600 / Pusher 1866 stroke 600: Variante/Variant A;D 200008353 – 3200

Variante/Variant B;C 200008355 – 3200



Umbausatz – Vorschubstange 1666 Hub 400 / Vorschubstange 1866 Hub 600

Retrofit kit – Pusher 1666 stroke 400 / Pusher 1866 stroke 600


Länge/length 2200:	Vorschubstange 1666 Hub 400 / Pusher 1666 stroke 400:	Variante/Variant A;D: 200011111	Variante/Variant B;C: 200011112
	Vorschubstange 1866 Hub 600 / Pusher 1866 stroke 600:	Variante/Variant A;D: 200011113	Variante/Variant B;C: 200011114
Länge/length 3200:	Vorschubstange 1666 Hub 400 / Pusher 1666 stroke 400:	Variante/Variant A;D: 200008352	Variante/Variant B;C: 200008354
	Vorschubstange 1866 Hub 600 / Pusher 1866 stroke 600:	Variante/Variant A;D: 200008353	Variante/Variant B;C: 200008355
Länge/length 3800:	Vorschubstange 1666 Hub 400 / Pusher 1666 stroke 400:	Variante/Variant A;D: 200010417	Variante/Variant B;C: 200010418
	Vorschubstange 1866 Hub 600 / Pusher 1866 stroke 600:	Variante/Variant A;D: 200010481	Variante/Variant B;C: 200010482
Länge/length 4200:	Vorschubstange 1666 Hub 400 / Pusher 1666 stroke 400:	Variante/Variant A;D: 200008472	Variante/Variant B;C: 200008473
	Vorschubstange 1866 Hub 600 / Pusher 1866 stroke 600:	Variante/Variant A;D: 200010444	Variante/Variant B;C: 200010444

Pos. Item	Ident-Nr. Ident. no.	Bezeichnung	Designation	Kommentar Remarks
1	2054-385	Deckel mit Wanne	Top with basin	
2	2068-888 2068-886	Platte Vorderseite A;D Platte Vorderseite B;C	Plate front A;D Plate front B;C	
3	2054-380	Platte Rückseite	Plate rear	
4	2056-002	Abdeckblech Rückseite	Sheet rear	
5	2056-003	Abdeckblech Vorderseite	Sheet front	
6	2054-376	Halte Winkel 40x 60x80	Angle 40x60x80	
7	2054-382	Anschlag für Schlitten	Stop for carriage	
8	2054-615 2054-616	Kanaldeckel verlängert A;D Kanaldeckel verlängert B;C	Cover extended A;D Cover extended B;C	
9	2068-889	Stirnblech hinten	Sheet rear	
10	2074-376 2074-377	Stirnblech hinten A;D Stirnblech hinten B;C	Sheet rear A;D Sheet rear B;C	
11	2054-386	Halte Lasche	Bracket	
12	2055-995	Leiste 5x14x40	Gib 5x14x40	
13	2054-564	Nutenstein M8/3x - 8x16x150	Tenon block M8/3x - 8x16x150	
14	2044-508	Verschlussstopfen D40	Stopp D40	

Pos. Item	Ident-Nr. Ident. no.	Bezeichnung	Designation	Kommentar Remarks
15	100098976	Zahnriemen VST 1666 Hub 400 – 2200	Toothed belt pusher 1666 stroke 400 – 2200	
	200011117	Zahnriemen VST 1866 Hub 600 – 2200	Toothed belt pusher 1866 stroke 600 – 2200	
	100060659	Zahnriemen VST 1666 Hub 400 – 3200	Toothed belt pusher 1666 stroke 400 – 3200	
	100078162	Zahnriemen VST 1866 Hub 600 – 3200	Toothed belt pusher 1866 stroke 600 – 3200	
	200008475	Zahnriemen VST 1666 Hub 400 – 3800	Toothed belt pusher 1666 stroke 400 – 3800	
	100075650	Zahnriemen VST 1866 Hub 600 – 3800	Toothed belt pusher 1866 stroke 600 – 3800	
	200008471	Zahnriemen VST 1666 Hub 400 – 4200	Toothed belt pusher 1666 stroke 400 – 4200	
	200008474	Zahnriemen VST 1866 Hub 600 – 4200	Toothed belt pusher 1866 stroke 600 – 4200	
	200011877	Zahnriemen VST 1666 Hub 400 – 6200	Toothed belt pusher 1666 stroke 400 – 6200	
	200011882	Zahnriemen VST 1866 Hub 600 – 6200	Toothed belt pusher 1866 stroke 600 – 6200	

Umrüstsätze / Capacity adjustment sets

Abbildung / Drawing



***Hinweis:**

Die Materialführungen der Lünette (19) und das Führungsmodul (18) sind ebenfalls durchmesserabhängig. Diese sind nicht im Umrüstsatz enthalten und müssen separat bestellt werden.

***Note:**

The guide jaws (19) and the guide module (18) are also diameter-dependent. These are not included in the capacity adjustment set and must be ordered separately.

Umrüstsätze / Capacity adjustment sets

Pos.	Bezeichnung Designation
1	Vorschubstange Pusher
2	Hubplatte Lifting plate
3	Schieber Short pusher
4	Fahne Schieber Flag short pusher
5	Einlage hinten unten 1450 / 1650 Insert rear bottom 1450 / 1650
6	Einlage hinten oben 1400 Insert rear top 1400
7	Einlage unten (Reststückklappe) Insert bottom (remnant flap)
8	Einlage vorne unten 765 Insert front bottom 765
9	Einlage vorne unten 400 / 220 Insert front bottom 400 / 220
10	Einlage vorne oben 1160 Insert front top 1160

Pos.	Bezeichnung Designation
11	Einlage vorne oben 800 / 605 Insert front top 800 / 605
12	Einlage vorne unten 660 / 460 Insert front bottom 660 / 460
13	Einlage vorne oben 643 / 443 Insert front top 643 / 443
14	Einlage vorne unten 600 / 643 Insert front bottom 600 / 643
15	Einlage vorne unten 1000 Insert front bottom 1000
16	Einlage vorne oben 600 / 643 Insert front top 600 / 643
17	Einlage vorne oben 1000 Insert front top 1000
18	Führungsmodul / Guide module
19	Materialführung / Guide jaw

***Hinweis:**

Die Materialführungen der Lünette (19) und das Führungsmodul (18) sind ebenfalls durchmesserabhängig. Diese sind nicht im Umrüstsatz enthalten und müssen separat bestellt werden.

***Note:**

The guide jaws (19) and the guide module (18) are also diameter-dependent. These are not included in the capacity adjustment set and must be ordered separately.

Umrüstsätze 1466 Hub 400 / Capacity adjustment sets 1466 stroke 400

Umrüstsatz komplett Capacity adjustment set complete	2200	3200	3800	4200	6200
D07/1466 AD	200010927	200008218	200010388	200008452	200011830
D07/1466 BC	200010928	200008219	200010389	200008453	200011831
D10/1466	200010929	200008220	200010390	200008454	200011832
D12/1466	200010930	200008221	200010391	200008455	200011833
D13/1466	200010931	200008222	200010392	200008456	200011834
D15/1466	200010932	200008223	200010393	200008457	200011835
D16/1466	200010933	200008224	200010394	200008458	200011836
D18/1466	200010934	200008225	200010395	200008459	200011837
D20/1466	200010935	200008226	200010396	200008460	200011838
D22/1466	200010936	200008227	200010397	200008461	200011839
D23/1466	200010937	200008228	200010398	200008462	200011840
D25/1466	200010938	200008229	200010399	200008463	200011841
D26/1466	200010939	200008230	200010400	200008464	200011842
D28/1466	200010940	200008231	200010401	200008465	200011843
D30/1466	200010941	200008232	200010402	200008466	200011844
D32/1466	200010942	200008233	200010403	200008467	200011845
D34/1466	200010943	200008234	200010404	200008468	200011846
D36/1466	200010944	200008235	200010405	200008469	200011847
D38/1466	200010945	200008236	200010406	200008470	200011848

Umrüstsätze 1666 Hub 400 / Capacity adjustment sets 1666 stroke 400

Umrüstsatz komplett Capacity adjustment set complete	2200	3200	3800
D07/1666 AD	2000010946	200008549	100010388
D07/1666 BC	2000010947	200008550	100010389
D10/1666	2000010948	200008551	100010390
D12/1666	2000010949	200008552	100010391
D13/1666	2000010950	200008553	100010392
D15/1666	2000010951	200008554	100010393
D16/1666	2000010952	200008555	100010394
D18/1666	2000010953	200008556	100010395
D20/1666	2000010954	200008557	100010396
D22/1666	2000010955	200008558	100010397
D23/1666	2000010956	200008559	100010398
D25/1666	2000010957	200008560	100010399
D26/1666	2000010958	200008561	100010400
D28/1666	2000010959	200008562	100010401
D30/1666	2000010960	200008563	100010402
D32/1666	2000010961	200008564	100010403
D34/1666	2000010962	200008565	100010404
D36/1666	2000010963	200008566	100010405
D38/1666	2000010965	200008567	100010406

Umrüstsätze 1666 Hub 600 / Capacity adjustment sets 1666 stroke 600

Umrüstsatz komplett Capacity adjustment set complete	2200	3200	3800	4200	6200
D07/1666 AD	200011061	200007958	200010462	200010424	200011849
D07/1666 BC	200011062	200007959	200010463	200010425	200011850
D10/1666	200011063	200007960	200010464	200010426	200011851
D12/1666	200011064	200007961	200010465	200010427	200011852
D13/1666	200011065	200007962	200010466	200010428	200011853
D15/1666	200011066	200007963	200010467	200010429	200011854
D16/1666	200011067	200007964	200010468	200010430	200011855
D18/1666	200011068	200007965	200010469	200010431	200011856
D20/1666	200011069	200007957	200010470	200010432	200011857
D22/1666	200011070	200007966	200010471	200010433	200011858
D23/1666	200011071	200007967	200010472	200010434	200011859
D25/1666	200011073	200007968	200010473	200010435	200011860
D26/1666	200011074	200007969	200010474	200010436	200011861
D28/1666	200011076	200007970	200010475	200010437	200011862
D30/1666	200011078	200007971	200010476	200010438	200011863
D32/1666	200011079	200007972	200010477	200010439	200011864
D34/1666	200011081	200007973	200010478	200010440	200011865
D36/1666	200011086	200007974	200010479	200010441	200011866
D38/1666	200011091	200007975	200010480	200010442	200011867

Umrüstsätze 1866 Hub 600 / Capacity adjustment sets 1866 stroke 600

Umrüstsatz komplett Capacity adjustment set complete	2200	3200	3800	4200
D07/1866 AD	200011093	200008572	200010483	200010445
D07/1866 BC	200011094	200008573	200010484	200010446
D10/1866	200011095	200008574	200010485	200010447
D12/1866	200011096	200008575	200010486	200010448
D15/1866	200011097	200008576	200010487	200010449
D18/1866	200011098	200008577	200010488	200010450
D20/1866	200011099	200008578	200010489	200010451
D22/1866	200011100	200008579	200010490	200010452
D25/1866	200011101	200008580	200010491	200010453
D28/1866	200011102	200008581	200010492	200010454
D30/1866	200011103	200008582	200010493	200010455
D32/1866	200011104	200008583	200010494	200010456
D34/1866	200011105	200008584	200010495	200010457
D36/1866	200011106	200008585	200010496	200010458
D38/1866	200011107	200008586	200010497	200010459

Materialführungen / Material guide jaws

Lünette steady	Materialführung Guide jaw	Ident-Nr. Ident-No.	zu verarbeitender Materialdurchmesser Diameter of material to be machined
D26	D2,5	2065-394	1,5 mm – 2 mm
D26	D04	2065-395	2 mm – 3 mm
D26	D06	2065-396	3 mm – 5 mm
D26	D07	2065-397	5 mm – 6 mm
D26	D08	2065-398	6 mm – 7 mm
D26	D10	2065-399	7 mm – 9 mm
D26	D12	2065-400	9 mm – 11 mm
D26	D13	2064-401	11 mm -12 mm
D26	D14	2065-402	12 mm -13 mm
D26	D15	2065-403	13 mm -14 mm
D26	D17	2065-404	14 mm -16 mm
D26	D19	2065-405	16 mm -18 mm
D26	D20	2065-406	18 mm -19 mm
D26	D22	2065-407	19 mm – 21 mm
D26	D24	2065-408	21 mm – 23 mm
D26	D27	2065-409	23 mm – 26 mm


Lünette steady	Materialführung Guide jaw	Ident-Nr. Ident-No.	zu verarbeitender Materialdurchmesser Diameter of material to be machined
D38	D07	2021-764	3 - 6 mm
D38	D10	2021-765	6 - 9 mm
D38	D12	2053-000	9 - 11 mm
D38	D13	2053-195	11 - 12 mm
D38	D15	2021-766	12 - 14 mm
D38	D16	2027-704	14 - 15 mm
D38	D18	2044-040	15 - 17 mm
D38	D20	2021-767	17 - 19 mm
D38	D22	2027-705	19 - 21 mm
D38	D25	2021-768	21 - 24 mm
D38	D26	2053-196	24 - 25 mm
D38	D28	2030-119	25 - 27 mm
D38	D30	2021-769	27 - 29 mm
D38	D32	2023-714	29 - 31 mm
D38	D34	2024-758	31 - 33 mm
D38	D35	2021-770	33 - 34 mm
D38	D36	2024-970	34 - 35 mm
D38	D37	2053-911	35 - 36 mm
D38	D38	2060-512	36 - 37 mm

Führungsmodul / Guide module

	Lademagazinvariante Loading magazine variant	Hub / stroke 400		Hub / stroke 600	
	Führungsmodul Guide module	Hub / stroke 400		Hub / stroke 500	Hub / stroke 600
Ø		Ident Nr. Ident-No		Ident Nr. Ident-No	Ident Nr. Ident-No
D07		200008093		200007993	200007803
D10		200008094		200007994	200007804
D12		200008095		200007995	200007805
D13		200008096		200007996	200007806
D15		200008097		200007997	200007807
D16		200008098		200007998	200007808
D18		200008099		200007999	200007809
D20		200008100		200008000	200007810
D22		200008101		200008001	200007811
D23		200008102		200008002	200007812
D25		200008103		200008003	200007813
D26		200008104		200008004	200007814
D28		200008105		200008005	200007815
D30		200008106		200008006	200007816
D32		200008107		200008007	200007817
D34		200008108		200008008	200007818
D36		200008109		200008009	200007819
D38		100076440		200008010	100071540

Wartungseinheit / Maintenance unit

200005229



Wartungseinheit / Maintenance unit

200005229

Pos. Item	Ident-Nr. Ident. no.	Bezeichnung	Designation	Kommentar Remarks
1	2067-008	Steckverschraubung	Plug-in screwing	
2	2068-343	Steckverschraubung	Plug-in screwing	
3	2079-894	Filter-Regelventil	Filter-regulator unit	
4	200004160	Einschaltventil	On/Off valve	
5	2074-205	Schalldämpfer	Silencer	


Pneumatikplan / Pneumatic diagram


Betriebsmittelkennzeichnung / Equipment marking

Kennzeichnung Marking	Bezeichnung	Designation
AZ	Wartungseinheit	Maintenance unit
MM	Pneumatikzylinder, Pneumatikmotor	Pneumatic cylinder, pneumatic motor
BG	Näherungsschalter, Endschalter	Proximity switch, limit switch
PG	Anzeigeninstrument, Manometer	Indicator, manometer
BP	Druckschalter	Pressure switch
QM	Wegeventil, Schnellentlüftungsventil	Directional control valve, quick exhaust valve
GQ	Druckluftquelle, Kompressor	Pneumatic source, compressor
QN	Druckreduzierventil	Pressure reduction valve
GS	Druckluftöler	Pneumatik oiler
RP	Schalldämpfer	Silencer
HQ	Filter	Filter
RZ	Drossel-Rückschlagventil	One-way restrictor
KH	Signalverknüpfung	Signal connecting
SJ	Handbetätigtes Ventil	Manual vent

Seite 1 / Page 1

20007836






Pneumatikteile / Pneumatic parts

Pos. Item	Ident-Nr. Ident no	Bezeichnung/Typ	Designation/Type	
1	200005229	Wartungseinheit komplett bestehend aus:	Maintenance unit complete consisting of:	
1.1	200004160	Einschaltventil	Switch on valve	
1.2	2079-894	Filter-Regelventil	Filter-regulator valve	
1.3	2068-343	Steckverschraubung	Plug-in screwing	
1.4	2067-008	Steckverschraubung	Plug-in screwing	
1.5	2074-205	Schalldämpfer	Silencer	
2	100049628	Druckschalter komplett bestehend aus:	Pressure switch consisting of:	
2.1	2058-325	Druckschalter	Pressure switch	
2.2	2068-343	Steckverschraubung	Plug-in screwing	
3	100073627	Ventilinsel 7-fach	Valve terminal 7-fold	
3.1	100042337	Magnetventil 5/3	Solenoid valve 5/3	
3.2	2080-203	Magnetventil 5/2	Solenoid valve 5/2	
3.3	2080-255	Schilderträger	Label holder	
3.4	2079-425	Blindstopfen	Filler plug	
3.5	2080-293	Schalldämpfer	Silencer	
3.6	2038-348	Steckverschraubung	Plug-in screwing	
3.7	100008518	L-Verschraubung	L-screwing	
3.8	2057-797	Drosselrückschlagventil	One-way restrictor	
3.9	2080-257	Dichtscheibe	Sealind disk	
3.10	2057-830	Steckverschraubung	Plug-in screwing	
3.11	2057-833	Steckverschraubung	Plug-in screwing	
3.12	100053646	Steckverschraubung	Plug-in screwing	
3.13	2001-420	Schalldämpfer	Silencer	

Pneumatikteile / Pneumatic parts

Pos. Item	Ident-Nr. Ident no	Bezeichnung/Typ	Designation/Type	
4	100074799 100048698	Entlüftung komplett A;D Entlüftung komplett B;C bestehend aus:	Venting complete A;D Venting complete B;C consisting of:	
4.1	100074802 100047929	Halteblech für Absperrventil A;D Halteblech für Absperrventil B;C	Retaining plate for Shut-off valve A;D Retaining plate for Shut-off valve B;C	
4.2	100046626	Absperrventil	Shut-off valve	
4.3	2049-120	Steckverbindung	Plug-in connector	
4.4	2058-876	Steckhülse	Plug-in sleeve	
4.5	2057-799	Steckverbindung	Plug-in connector	
5	2055-058	Zylinder (Führungskanal)	Cylinder (Führungskanal)	-MM1
6	2055-059	Zylinder (Vorschubstange)	Cylinder (Pusher)	-MM8
7	2056-577	Zylinder (Reststückklappe 400 mm)	Cylinder (Remnant flap 400 mm)	-MM10
	2058-185	Zylinder (Reststückklappe 600/800/1100 mm)	Cylinder (Remnant flap 600/800/1100 mm)	-MM10
8	2058-131	Zylinder (Greifer)	Cylinder (Gripper)	-MM2
9	2055-066	Zylinder (Lünette)	Cylinder (Steady rest)	-MM7
		Zylinder (Vereinzelung)	Cylinder (Separation)	-MM5
10	2030-646	Zylinder (Anfahrsschalter)	Cylinder (Starting switch)	-MM9
11	2038-351	Steckverbindung	Plug-in connector	
12	2040-874	Druckregelventil	Pressure regulator	

Elektroteile / Electrical parts
Lademagazin / Loading magazine



Elektroteile / Electrical spare parts

Lademagazin / Loading magazine

Ident-Nr. Ident. no.	Bezeichnung	Designation	Kommentar Remarks
2018-648	Näherungsschalter	Proximity switch	-B1
2023-003	Näherungsschalter	Proximity switch	-B7
2035-221	Näherungsschalter	Proximity switch	-B5,-B6,-B13,-B14,-B17,-B22,-B23
2079-304	Näherungsschalter	Proximity switch	-B26
100049628	Druckschalter 0,5-8 bar	Pressure switch 0,5-8 bar	-B11
2042-872	Sensorleitung mit Stecker M12	Sensor lead with plug M12	für/for-B1
2042-579	Sensorleitung mit Stecker M12	Sensor lead with plug M12	für/for-B7
2042-582	Sensorleitung mit Stecker M12	Sensor lead with plug M12	für/for -B5,-B6,-B13,-B14,-B22,-B23
2063-956	Sensorleitung mit Stecker M12	Sensor lead with plug M12	für/for-B74
2063-957	Sensorleitung mit Stecker M12	Sensor lead with plug M12	für/for-B75
2076-151	Sensorleitung mit Stecker M12 8-polig	Sensor lead with plug M12 8-pol.	für/for-B79
2043-173	Verschlusskappe Port M12	Sealing cap Port M12	X6 Steckplatz/place X7 Steckplatz/place
200005144	Stecker mit Leitung für Druckschalter	Plug with lead for pressure switch	an/on -B11
200004100	Servomotor mit Geber	Servomotor with encoder	-M1 mit/with -B3
200006125	Servomotor mit Geber und Bremse	Servomotor with encoder and brake	-M1 mit/with -B3 (Option)
2070-052	Drehgeber (Option)	Encoder (option)	-B4
2041-038	Ölförderpumpe	Oil feed pump	-M2
1099-051	Magnetkupplung	Magnetic clutch	-Q6
2063-973	Aktor-Sensor-Box 4-fach mit 24 poligem Stecker	Aktor-Sensor-Box 4-fold with plug 24 pol.	X7
200003073	Anschlussleitung kpl. für Ventilblock 25pol.	Lead complete for valve block 25pol.	X9

Lademagazin / Loading magazine

Ident-Nr. Ident. No.	Bezeichnung	Designation	Kommentar Remarks
2042-920	Aktor-Sensor-Box mit 24 poligem Stecker	Aktor-Sensor-Box with plug 24 pol.	X6
2036-784	Funkenlöschglied	Protection relay	zu -Q6 / to -Q6
2063-952	Sicherheitsschalter T5C 236-02 Z-ST	Safety switch T5C 236-02 Z-ST	-B74,-B75
2063-953	Sicherheitsschalter T3C 236-02 Z-ST	Safety switch T3C 236-02 Z-ST	-B74,-B75
2068-440	Sicherheitsschalter AZ 16-03 zvk	Safety switch AZ 16-03 zvk	-B76
2051-354	Betätiger AZ 16-02 zvk / AZ 15/16-B1	Actuator AZ 16-02 zvk / AZ 15/16-B1	-B76
200004353*1 Schmersal	Sicherheitssensor RSS260-1	Safety sensor RSS260-1	-B79 (-B70 Option)
100060288*1 Schmersal	Betätiger RST 260-1	Actuator RST 260-1	für/for -B79
200009636*2 Sick	Sicherheitssensor STR1-SAXM0AC8S02	Safety sensor STR1-SAXM0AC8S02	(alternatives Bauteil/alternative component) -B79
200009637*2 Sick	Betätiger STR1-XAS	Actuator STR1-XAS	(alternatives Bauteil/alternative component) für/for -B79
2078-480	Y-Adapter 8polig	Y-adapter 8pin	-X79
2078-481	Abschlussstecker	Terminating plug	-X80
2078-482	Sensorleitung M12 auf M12 8p 1m	Sensor lead M12 to M12 8p 1m	-WD700
200001213	Sensorleitung M12 auf M12 8p 2m	Sensor lead M12 to M12 8p 2m	-WD790
200004101	Leistungskabel 5m	Power cable	für/for -B79
200004102	Geberkabel 5 m	Cable for encoder	between -T1 and -B3 zwischen -T1 und -B3
200004038	Profibusleitung	Profibus lead	-WG10 (Option)
200004853	Profinetleitung	Profinet lead	-WG10 (Option)


*Sicherheitssensor und Betätiger *1 oder *2 ausschließlich gemeinsam ersetzen, da die Funktion sonst nicht gewährleistet ist.

*Replace the safety sensor and actuator *1 or *2 exclusively together, otherwise the function is not guaranteed.

Elektroteile / Electrical spare parts

Schalttafel / Switch board

Abbildung beispielhaft – siehe Elektroschaltplan! / Drawing exemplary – see electrical circuit diagram!




Elektroteile / Electrical spare parts

Schalttafel / Switch board

Ident-Nr. Ident. no.	Bezeichnung	Designation	Kommentar Remarks
200004090	Kompaktumrichter HCS01.1E	Compact converter HCS01.1E	-T1
200004091	Kompaktumrichter HCS01.1E Multi Ethernet	Compact converter HCS01.1E Multi Ethernet	-T1 (Option)
200004092	Kompaktumrichter HCS01.1E Profibus	Compact converter HCS01.1E Profibus	-T1 (Option)
200000735	Programm-Modul micro SD-Karte	Program module micro SD-card	für/for -T1
200004094	Sercos Buskoppler Interface	Sercos Buskoppler Interface	-BO1
200004095	Eingangskarte 32E Interface	Input card 32E Interface	-DI1
200004097	Ausgangskarte 16A Interface	Output card 16A Interface	-DA1
200004098	Ausgangskarte 8A Interface	Output card 8A Interface	-DA2; -DA3
2063-649	Ethernet-Kabel Sercos III 1 m	Ethernet-cable Sercos III 1 m	zwischen -T1 und -BO1 between -T1 and -BO1
200005997 oder / or 200005995	Schütz 24V DC 3H 1Ö Schütz 24V DC 3H 1S	Contactor 24V DC 3H 1Ö Contactor 24V DC 3H 1S	-QA50,-QA21 auftragsbez./as per order -K22 auftragsbez./as per order -K22
2037-095 oder / or 2037-094	Schütz 24V DC 3H 1Ö DILEEM-01-G Schütz 24V DC 3H 1S	Contactor 24V DC 3H 1Ö DILEEM-01-G Contactor 24V DC 3H 1S	auftragsbez./ as per order -K23 auftragsbez./as per order -K23
2037-096	Hilfsschalterblock 22 DILEM	Auxiliary switch block 22 DILEM	auftragsbez. -K23 as per order -K23
2071-375* Pilz	Not-Aus Schaltgerät PNOZs4 C 24 VCD	Safety relay PNOZs4 C 24 VCD	-K20,-K70
200009625* Phoenix	Not-Aus Schaltgerät PSR-MC45	Safety relay PSR-MC45	(alternatives Bauteil/alternative component) -K20,-K70
2071-376	Sicherheitsrelais Erweiterungsgerät	Emergency-Stop extension device	-K201; K701
2049-124	Optokopplermodul 24V DC 2A	Opto-electronic coupler 24V DC 2A	-K41
2020-946	Relais 2WE 5A 40529024	Relay 2WE 5A 40529024	-K1,-K9,-K9.1,-K1.1,-K30, -K37

Elektroteile / Electrical spare parts
Schalttafel / Switch board

Abbildung beispielhaft – siehe Elektroschaltplan! / Drawing exemplary – see electrical circuit diagram!



Schalttafel / Switch board

Ident-Nr. Ident. no.	Bezeichnung	Designation	Kommentar Remarks
2025-516	Relaisfassung 95.95.3	Casing for relay 95.95.3	für Relais for relay
2025-517	Modul mit LED und Freilaufdiode 99.80.9.024.90	Module with LED and recovery diode 99.80.9.024.90	für Relais for relay
2004-401	Hilfsschütz220V 3TH 8262 OAMO	Auxiliary contactor 3TH 8262 OAMO	auftragsbez. -K91 as per order -K91
2004-403	RC-Entstörglied 3TX 6406 OG	RC-screening unit 3TX 6406 OG	auftragsbez. -K91 as per order -K91
200004802	Modul Kanalzuhaltung	Module channel locking	-K225
0943-304	Sicherungsautomat 2x4A	Automatic cut-out 2x4A	-F10
2076-869	Elektronische Sicherung 1,2,4,6A	Electronic fuse 1,2,4,6A	-F11
0942-480	Sicherungsautomat 6A	Automatic cut-out 6A	auftragsbez.-F4 as per order -F4
200006003	Motorschutzscharter 0,6-1A	Motor protection switch 0,6-1A	-F2 bei Betriebsspannung 400-460V -F2 for 400-460V machines
200006004	Motorschutzscharter 1-1,6A	Motor protection switch 1-1,6A	-F2 bei Betriebsspannung 200-230V -F2 for 200-230V machines
200006006	Motorschutzscharter 4-6,3A	Motor protection switch 4-6,3A	-F1
200006007	Hilfsscharter	Auxiliary switch	für/for -F1, -F2
200002455	Netzteil 24V 5A	Power supply 24V 5A	-T10
2001-368	Motorentstörglied RC 3/022-400 BU	Motor screening unit RC 3/022-400 BU	-FA50
200004037	Profibus Adapter	Profibus adapter	-X40 (Option)

Elektroteile / Electrical spare parts
Bedientableau / Control panel

Ident. Nr. Ident- no.	Bezeichnung	Designation	Kommentar Remarks
200004149	Bedientableau PH1 HGT835 mit Kabel 10 m	Control panel PH1 HGT835 with cable 10 m	-PH1
200004150	Bedientableau PH1 HGT835 mit Kabel 13,5 m	Control panel PH1 HGT835 with cable 13,5 m	-PH1

FMB
MASCHINENBAU

turbo RS 3-38 Serie 1

Blatt 1/1063

10431_003

Blatt	1
Folge	1.1

1										2										3										4										5										6										7										8																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																											

A

B


C

D


F


F


Ordering	Date	Name	Norm	DNS	Crop	Eros.	Eros.
1			2		3		4
						5	6
							7





	1	2	3	4	5	6	7	8	
A									A
B									B
C									C
D									D
E									E
F									F
				Datum	07.06.22	Schnittstelle			
				Bearb	Straub	interface			
				Gepr.	Straub	Interface			
	Aenderung	Datum	Name	Norm	DIN5	Urspr	Ers.f.	Ers.d.	
	1		2		3			4	
								5	
								6	
								7	
								8	






	Antriebsmotor					Geber		Geber Wegerfassung Spindelstock				Ölpumpe				
						Weg Lünette					0,37KW		200-230V		1,6A	
	driving motor					encoder		encoder distance headstock / steady				oil-pump				
	moteur d'entraînement					convertisseur		convertisseur				pompe à huile				
				Datum	01.06.22	main circuits motors Circuits principaux des moteurs				Hauptstromkreis Motoren		turbo RS 3-38 Serie 1				
			Bearb	D.Beck	Blatt 6/01							10431_003		Blatt 6		
			Gepr.	D.Beck										Folge 7		
	Aenderung	Datum	Name	Norm	DIN5	Urspr	Ers.f.	Ers.d.								


- * Steuerstromkreise sind geerdet.
Wird eine Erdungsverbindung entfernt,
ist eine Isolationsüberwachung
nach VDE einzubauen.
- * Control circuits are grounded.
When a ground connection is
removend, an insultation monitoring
has to be installed. (VDE)
- * Les circuits de commande sont
mis à la terre. Au cas d'une connexion
d'une mise à la terre, un surveillance
d'isolation doit être installé (VDE)



--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--



Datum		10.01.23	control		Steuerung		turbo RS 3-38 Serie 1			
Bearb		Straub	Commande		FMB		Blatt 8/00		10431_003	
Gepr.		Straub	Urspr		MASCHINENBAU				Blatt 8	
Aenderung		Datum	Name		Ers.f.				Folge 9	
Norm		DIN5								



Not - Halt

emergency stop

Freigabe Motor

Antriebssperre 1

Antriebssperre 2

release motor

drive barrier 1

drive barrier 2

Arrêt d'urgence

Libération moteur

Barrière d'entraînement 1 Barrière d'entraînement 2

Datum	10.01.23
-------	----------

Bearb	Straub
-------	--------

Geogr.	Straub
--------	--------

emergency stop

Arrêt d'urgence

FMB
MASCHINENBAU

Not-Halt

turbo RS 3-38 Serie 1

Blatt 9/00

10431_003

Blatt 9

Folge 10

Aenderung

	Datum
--	-------

Name

	Dep.
e	Norm

DIN5

Urspr

Ers.f.

Ers.d.

--	--

10

Folgt

Folge 10

1

2

3

4


5

6


7


8

8




1	2	3	4	5	6	7	8
---	---	---	---	---	---	---	---







	Reststückausfallklappe		Vorschubstange		Vorschubstange		Vorlauf		Rücklauf		Nachschieben		Material auf		
	eingeschwenkt		ausgeschwenkt		im Kanal						mit Gegenspindel		Seitlicher-Auflage		
	remnant flap swung in		pusher swung out		pusher in the channel		forward		backward		push with sub spindle		material on lateral storage		
	Volet résidus rentré fermé		Barre d'avance sortie		Bar.d'avance rentrée,dans le canal		Avance		Retour		Introduction con.broche				
				Datum	10.01.23	input-card KF11 IX202.0-7 Plaque d'entrée KF11 IX202.0-7				Eingangskarte KF11 IX202.0-7		turbo RS 3-38 Serie 1			
			Bearb	Straub											
			Gepr.	Straub											
	Aenderung	Datum	Name	Norm	DIN5	Urspr	Ers.f.	Ers.d.			Blatt 14/01	10431_003		Blatt 14	
														Folge 15	





9	10	11	12	13	14	15	16
IN	IN	IN	IN	IN	IN	IN	IN
IX203.0	IX203.1	IX203.2	IX203.3	IX203.4	IX203.5	IX203.6	IX203.7

Option									
Kurzdrehmodus		Schutztür		reset		Automatik ein		Vorschub Stopp	
		geschlossen				von Drehmaschine		Relais K225 aktiv	
								Führungskanal geschlossen	
								(Abfrage hinten)	
short mode		door closed		reset		automatic mode on from lathe		feed stop	
								Relay K225 active	
								feed channel closed	
mode court		porte de protection fermé		reset		Automatique on de la tour		Avancement stop	
								Relais K225 actif	
								Canal de guidage fermé	
			Datum	10.01.23	FMB MASCHINENBAU	Eingangskarte KF11 IX203.0-7		turbo RS 3-38 Serie 1	
			Bearb	Straub					
			Gepr.	Straub					
Aenderung	Datum	Name	Norm	DIN5	Urspr	Ers.f.	Ers.d.	Blatt 15/03	10431_003
1	2	3	4	5	6	7	8	Blatt 15	Folge 16










	1	2	3	4	5	6	7	8					
A									A				
B									B				
C									C				
D									D				
E	-KF10 /12.1 ○ 17 IN IX204.0 ○ 18 IN IX204.1 ○ 19 IN IX204.2 ○ 20 IN IX204.3 -KF11 /14.1 ○ 17 IN IX204.4 ○ 18 IN IX204.5 ○ 19 IN IX204.6 ○ 20 IN IX204.7								E				
F									F				
				Datum	01.06.22	FMB MASCHINENBAU Eingangskarte KF10/KF11 IX204.0-7		turbo RS 3-38 Serie 1					
				Bearb	D.Beck			input-card KF10/KF11 IX204.0-7					
				Gepr.	D.Beck	Plaque d entrée KF10/KF11 IX204.0-7							
Aenderung		Datum	Name	Norm	DIN5	Urspr	Ers.f.	Ers.d.	Blatt 21/00		10431_003	Blatt 21 Folge 22	
	1		2		3		4		5		6	7	8

	1	2	3	4	5	6	7	8													
A	-KF22 /19.1 <table><tr><td>QX204.0</td><td>QX204.1</td><td>QX204.2</td><td>QX204.3</td></tr><tr><td>OUT</td><td>OUT</td><td>OUT</td><td>OUT</td></tr><tr><td>9 ○</td><td>10 ○</td><td>11 ○</td><td>12 ○</td></tr></table>								QX204.0	QX204.1	QX204.2	QX204.3	OUT	OUT	OUT	OUT	9 ○	10 ○	11 ○	12 ○	A
QX204.0	QX204.1	QX204.2	QX204.3																		
OUT	OUT	OUT	OUT																		
9 ○	10 ○	11 ○	12 ○																		
B									B												
C									C												
D									D												
E									E												
F									F												
				Datum	01.06.22	input-card KF22 QX204.0-3 Plaque d'entrée KF22 QX204.0-3			Ausgangskarte KF22 QX204.0-3	turbo RS 3-38 Serie 1											
				Bearb	D.Beck																
				Gepr.	D.Beck																
	Aenderung	Datum	Name	Norm	DIN5	Urspr	Ers.f.	Ers.d.			Blatt 22/00	10431_003	Blatt 22 Folge 70								
	1		2		3		4	5		6		7	8								



				Datum	10.01.23	switch board Tableau de distribution				Schalttafel		turbo RS 3-38 Serie 1			
			Bearb	Straub											
			Gepr.	Straub											
	Aenderung	Datum	Name	Norm	DIN5	Urspr	Ers.f.	Ers.d.			Blatt 70/02	10431_003		Blatt 70	
														Folge	