

turbo RS 4-45 V

Operating instructions



Operating instructions

turbo RS 4-45 V, series 1

Confirmation number from: 2212752

Editorial deadline: 2023-11-14

FMB Maschinenbau Paul-Hohe-Straße 1 97906 Faulbach

Telephone: +49 9392 801 0

Fax:

E-mail: info@fmb-machinery.de Internet: www.fmb-machinery.de

Operating instructions

1, 1, en_US



Table of contents

1	Gen	ierai	. 0
	1.1	Operating instructions	. 5
	1.2	Information about the product	. 7
	1.3	Technical data	11
2	Safe	ety	15
	2.1	Safety measures	15
	2.2	Safety equipment	15
3	Trar	nsport	16
	3.1	Prepare for transportation	16
	3.2	Transporting the product	21
4	Ass	embly and start-up	. 25
	4.1	Prepare for assembly	25
	4.2	Aligning	26
	4.3	Electrical connection	27
	4.4	Assembly	. 28
	4.5	Adjustments	. 33
	4.6	Settings	34
	4.7	Pre-set parameters	35
5	Con	trol panel	38
	5.1	Control panel, general	38
6	Ope	eration	. 40
	6.1	Basic functions	40
	6.2	Overview of selections	41
	6.3	Edit and manage programs	43
	6.4	Processing settings	45
	6.5	Feed material bars	47
	6.6	Processing phase	48
7	Con	verting	54
	7.1	General conversion	54
	7.2	Guide channel	54
8	Mair	ntenance	64
	8.1	Maintenance actions	64
	8.2	Auxiliary equipment	69
9	Fau	lts	. 70
	9.1	Fault messages	70
	0.2	Fault table	71



10	Inde	×	77
	9.4	Technical problems	75
	9.3	Service	75



1 General

1.1 Operating instructions

Product versions and special equipment

The operating instructions cover several versions of the described product. You can see which version of the product you have in the field "Type" on the name plate. * "Name plate" on page 7.

The product versions differ with regards to the length of the loading magazine and therefore also with regards to the number of supports. In the chapters "Transport" and "Assembly" the respective product version is to be observed. Product versions over a certain length can be delivered in two pieces. Please find more precise information about the individual product versions from the respective dimension sheet. * "Other applicable documents" on page 5.

The diagrams may vary from the actual product. The principle described does, however, apply to all versions.

The operating instructions also describe special equipment, which may not be installed on your product. The descriptions of special equipment state that they are optionally installed.

Special equipment with a greater scope is described in corresponding supplemental instructions, which can also be found in the technical documentation folder. The supplemental instructions are a supplement to the operating instructions, and are to be observed in connection with it. First familiarize yourself with the operating instructions, before you use the supplemental instructions.

Other applicable documents

The operating instructions are supplemented by the following documents, which are also kept in the technical documentation folder:

- Circuit diagram
- Pneumatics plan
- Dimension sheet (specific to the product version)
- Adapter set/attachment diagram (optional)
- Supplemental instructions (optional)

Explanation of symbols

Warning Hazard

Warns of a hazard with a high risk level which, if not avoided, will cause death or severe injury.

▲ DANGER

Type and source of hazard

Consequences if the note is disregarded.

Actions necessary to avert the hazard.

Warning Hazard

Warns of a hazard with a medium risk level which, if not avoided, could cause death or severe injury.

⚠ WARNING

Type and source of hazard

Consequences if the note is disregarded.

Actions necessary to avert the hazard.



Warning Caution

Warns of a hazard with a low risk level which, if not avoided, could cause minor or moderate injury.



Type and source of hazard

Consequences if the note is disregarded.

Actions necessary to avert the hazard.

Note (material damage)

A note that misuse could cause material damage.

NOTICE

Type and source of hazard

Consequences if the note is disregarded.

Actions necessary to avert the hazard.

Useful information

Notes or additional information.



Useful information.

Instructions on use

These instructions require the user to take action.

Display text

Display text comprises terms or text which appear on the control panel of the product.

Example: Display text.

Menu pathway

The menu pathway shows the path for actions, where you have to navigate through more than one menu level.

Example: 'Start → Sub menu → Destination"

Cross-reference

Cross-references refer to further information about a topic.

Example: * "Explanation of symbols" on page 5.

Intended use

The loading magazine is intended for attachment to machine tools, and is only allowed to be operated if it has been installed on a machine tool in accordance with the specifications of these operating instructions. The loading magazine is exclusively intended for the supply of material bars to machine tools. These materials are round or have multiple edges. In individual cases, special profiles are allowed to be suppled, which have been agreed with FMB in advance.

Furthermore, the intended use of the loading magazine can be seen by observing the Technical Data chapter of these operating instructions A Chapter 1.3 "Technical data" on page 11.

The applicable accident prevention guidelines and other generallyrecognized technical safety regulations are to be observed.

Reasonably foreseeable misuse

- Non-observance of the requirements on the material bars. .
- Operation with asymmetric profile bars without consultation with FMB.
- Operation with special profiles without consultation with FMB.



- Operation with non-homogenous material bars (imbalance).
- Processing outside of the permitted area (diameter, length).
 - → "Technical data of the loading magazine" on page 11.
- Use of unintended fuel. .
- Operation without lubrication.
- Operation without a capacity adjustment set or with the wrong set

Operation without a clamping device or with the wrong clamping device.

- Transportation not done in accordance with the operating instructions. Chapter 3.2 "Transporting the product" on page 21.
- Operation outdoors.
- Manipulation of safety equipment.
- Performance of work without sufficient qualifications.

 "Qualifications of the personnel" on page 7.

Unauthorized alterations to the product are not permitted and exclude the liability of the manufacturer for any damage incurred as a result.

Qualifications of the personnel

The work described in these operating instructions is only allowed to be performed by personnel who have been qualified according to the table specified below.

Area of responsibility	Training by the man- ufacturer concerning assembly and start-up*	Product training**	Specific technical training***
Transport			X
Assembly / Start-up	X		
Operation		X	
Maintenance		X	X
Disposal			X

^{*}Extensive qualification in the assembly and start up of FMB products. Qualification is done by FMB.

1.2 Information about the product


Name plate

The name plate is attached to the loading magazine in position 1.

^{**}Personnel who have received training for the product, are familiar with the functions and have been made aware of the risks. The training can be done by FMB or by a person who has already received training.

^{***}Personnel who have received training in the respective area of responsibility, and have qualifications allowing them to perform the work correctly, to properly estimate risks and avoid hazards.






Types and lengthsYear of constructionMachine number


The declaration of conformity (CE or UKCA) shall be added, if issued, to the name plate of the loading magazine.

Overview



1	Control cabinet	2	Cover
3	Support	4	Oil tank
5	Remnant bin	6	Control panel
7	Steady		





8	Drive	9	Lateral material storage with separation device
10	Guide channel, rear	11	Material gripper
12	Guide channel, front		

Functional description

The loading magazine supplies material bars and pushes them through the spindle into the processing area of the machine tool. The loading magazine works at the speed of the machine tool and thereby allows the automatic loading of the machine tool.

The collet of the machine tool closes and processing begins. The guide channel filled with oil and the steady placed between the machine tool and the guide channel ensure the exact bar guide required for processing. After a workpiece has been completed, the collet of the machine tool opens. The pusher of the loading magazine moves the material bar into the cut-off position, the collet of the machine tool closes and the next workpiece is processed.


If the material bar has been used up and the last possible part has been made, the working process of the machine tool is stopped. The collet of the machine tool opens and the pusher is moved back. The material gripper closes and holds the remnant of the material bar in position. The remnant is taken out of the clamping sleeve and is ejected into the remnant bin. The working process begins again.

Drive

The pusher is driven by a servomotor with a toothed belt. A sensor on the servomotor detects the exact position of the pusher.




Layout of the components



1	End stop	2	Pusher with short pusher flag
3	Material gripper	4	Pusher
5	Clamping sleeve	6	Starting switch
7	Guide module	8	Lathe spindle
9	Lathe collet		

Positions and traverse paths



1	Pusher length	The dimension for the parameter Pusher length is measured from the rear edge of the pusher to the front edge of the bearing insert.
2	Traverse path First insert travel	The first insert is performed after the material bar is changed. The traverse path First insert travel is the path from the starting switch in the loading magazine to the cut-off position in the working area of the lathe.
3	Traverse path Travel interval on	With interval insert active, an intermittent feed takes place in the area of Travel interval on .



4	Position draw off	At position Position draw off the material gripper grabs the material bar.
5	Position rear limit	The maximum rear position the pusher is able to reach. The position Position rear limit is reached when the remnant is removed or the pusher swings out.
6	Position storage	The position at which the pusher picks up a new material bar. The pusher travels at high speed, just before the position Position storage it brakes, picks up the material bar and accelerates again.
7	Position Limit pos. short pusher front	The position to which the pusher moves the material bar, enabling the material gripper to grab the material bar.
8	Position open steady	During operation, the clamping sleeve must pass the steady. When the clamping sleeve is at the position Position open steady the steady opens to prevent damage.
9	Position close steady	During operation, the clamping sleeve must pass the steady. When the pusher has passed the open steady and reached the position Position close steady the steady closes.
10	Pos. reverse rotation return	When returning from the spindle of the lathe, the pusher moves from the position Pos. reverse rotation return at high speed.
11	Position front limit	The maximum front position the pusher is able to reach. The clamping sleeve is positioned just before the collet of the lathe. The value Position front limit and the value Part length 1 are used to calculate when the last part will be fed in.
12	Position press on	The clamping sleeve is pressed on to the material bar up to this position.
13	Length of guide module	The dimension for the parameter Length of guide module is measured from the rear edge to the front edge of the guide tube and depends on the stroke of the guide module.

1.3 Technical data

Technical data of the loading magazine

Characteristic	Unit	Value
Material flow in the guide channel	mm	4 - 45
Bar length	mm	2200 / 3200 / 3800 / 4200 / 6200
Maximum feed force	N	1025



Characteristic	Unit	Value
Insert speed	mm/s	520
Feed speed	mm/s	1000
Return speed	mm/s	2000
Maximum remnant length	mm	480
Weight ³ Length version 2200	kg	1050
Weight ³ Length version 3200	kg	1150
Weight ³ Length version 3800	kg	1250
Weight ³ Length version 4200	kg	1350
Weight ³ Length version 6200	kg	1650
Weight of transport pallet	kg	Depending on length variant approx. 250 - 500
Oil tank level	I	80
Supply of compressed air	bar	6 - 8
Compressed air consumed per loading process	1	approx. 27
Compressed air consumed per double stroke of the steady	1	approx. 0.5
Noise emission during the bar change	dB(A)	48 +/- 5
Operating voltage ^{1, 4}	V	200 / 400 / other types
Power requirement	KW	2
Nominal frequency ^{2, 5}	Hz	50 / 60
Control voltage	V	24

- 1) According to DIN EN 60204 (VDE 0113), the continuous operating voltage must be within 100% \pm 10% of the line voltage.
- 2) According to DIN EN 60204 (VDE 0113), the frequency must be between 0.99 and 1.01 of the nominal frequency.
- 3) Empty, without equipment and without transport pallets.
- 4) The operating voltage applicable for your product can be seen on the circuit diagram. *★ "Other applicable documents" on page 5.*



5) The product is rated for a nominal frequency of 50 Hz and 60 Hz.

Operating conditions

Characteristic	Unit	Value
Surrounding temperature	°C	+ 15 - + 40
Air humidity, non-condensing	%	30 - 75
Altitude about sea level	m	up to 1000


Storage conditions

Characteristic	Unit	Value
Surrounding temperature	°C	- 20 - + 65

The loading magazine is only allowed to be stored in dry rooms.

Dimensions of the loading magazine

*Dimension A: Material bar length; **Dimensions B and C: Depending on the pusher



Stroke	600	600
Pusher length	1900	2100
	B1	B2
	C1	C2

Table of dimensions

Loading maga- zine length	Dimensions in mm						
	Α	B1	B2	D	C1	C2	G***



Loading maga- zine length	Dimensions in mm						
2200	2210	3600	3800				
3200	3210	4600	4800				
3800	3810	5200	5400	821	1835	2035	920 - 1465
4200	4210	5600	5800				
6200	6210	7600	7800				

 $^{^{\}star\star\star}$ Aligned to spindle height. On loading magazines with a shifting device, this value increases by 30 mm.



2 Safety

2.1 Safety measures

Personal safety equipment

The operator of the product must provide the following safety equipment and ensure they are used.

- Safety shoes
- Ear protection
- Safety gloves
- Eye protection
- Skin protection

2.2 Safety equipment

Emergency stop device

The loading magazine has an emergency stop device compliant with DIN EN 60204 (VDE 0113). The emergency stop button is mounted on the control panel *★ "Press the emergency stop button"* on page 40.

When the emergency stop button is pressed, the power to the safety-relevant PLC outputs is shut off. The power supply to the drive motor is also shut off. The drive motor and hence the pusher cannot perform any more movements. The pressurization of the pneumatic valves for the "Open / close guide channel" function is maintained so that the guide channel remains shut. The pressurization of the remaining pneumatic valves is interrupted. They return to their original position. An error message appears on the control panel of the loading magazine.

The emergency stop signal is relayed to the machine tool and has to be processed there in accordance with DIN EN 23125.

If the emergency stop button of the machine tool is pressed, the emergency stop signal is relayed to the loading magazine and also triggers an emergency stop there.

Lock

The cover of the loading magazine and the lid of the steady are monitored by the lock. In open position, the lock prevents the loading magazine operating. If the lock reports an "open" position, there is no power at certain PLC outputs and the drive is shut down. The lock helps ensure the loading magazine operates safely.

Safety door of the machine tool

If the safety door of the machine tool is opened during operation, the drive of the loading magazine is shut down. It is not possible to move the pusher of the loading magazine if the safety door of the machine tool is open. A risk to people due to the pusher of the loading magazine being in the working area of the machine tool is therefore excluded.



3 Transport

3.1 Prepare for transportation

Preparing the loading magazine for transportation

▲ DANGER

Movable guide channel/guide module can unexpectedly move forward out of the loading magazine

During transport, the movable guide channel/guide module can move forward out of the loading magazine due to its inertia caused by jerky movements. Personal injury from impact can result.

- Do not loiter in the danger area.
- Install the transport lock for the guide channel/guide module before transport as described in the operating instructions.

⚠ WARNING

Falling attachments/components

Loose attachments or components being transported by the loading magazine can fall and cause personal injury due to crushing and impact.

 Secure loose attachments or components against slipping and falling before transport.




Once the loading magazine has been raised, the pins extending out of the floor must be detached at ground level or removed from the floor using suitable means.

- 1. Completely remove any material bars. *→ "Removing the material bar from the loading magazine" on page 51* or .
- 2. Remove the remnants from the remnant bin. .
- 3. Press the button.
- 4. SETUP Call .
- **5.** Move the pusher all the way back using the ___ button.
- **6.** Leave the loading magazine at a standstill for at least 8 hours to allow the oil to drain out.
- **7.** Empty the oil tank of the loading magazine. *→ "Empty the oil tank of the loading magazine" on page 68.*
- 8. Turn off the main switch of the lathe.
- **9.** Disconnect the power supply to the lathe (remove the connector).
- **10.** Remove all the electrical connections from the loading magazine to the control cabinet.
- 11. Remove the plug for the oil pump on the control cabinet.
- **12.** Dispose of the oil / cooling lubricant in accordance with the legal provisions.
- **13.** Unclip the connecting hoses for the oil feed and return.
- **14.** Secure detached oil hose connections to prevent the loss of residual oil.
 - i The oil tank must be transported separately.




- **15.** Depressurize the compressed air line to the loading magazine.
- **16.** Switch off the compressed air supply.
 - → The loading magazine is vented.
- 17. Fasten the control cabinet to the beam *★* "Removing the control cabinet from / attaching the control cabinet to the loading magazine" on page 32.
- 18. Assemble the transport lock for the guide channel/guide module. → "Assembling / disassembling the transport lock for the guide module" on page 19.
- 19. Assemble the transport lock for the remnant bin. .
- 20. ▶ Loosen the anchors on the floor.
 - ➡ The loading magazine is ready for transportation.

Transport beams



Two transport beams $\boxed{1}$ have to be attached to the loading magazine for transportation. The attachment points for the transport beams $\boxed{1}$ are on the underside of the loading magazine.



There are two threaded pins 2 and two attachment screws 3 on the underside of each transport beam. The threaded pins are used to position the transport beams and remain on the loading magazine even when the transport beams are removed.

Assembling the transport beams



Falling loading magazine

Personal injury due to squashing and impact by the falling loading magazine.

If the transport beams are attached improperly to the loading magazine, they might come loose or the screw connections might break.

 Observe the description about the assembly of transport beams in the operating instructions.



A DANGER

Falling transport beams

Personal injury due to squashing and impact by the falling transport beams.

If the raising of the loading magazine is not done by the transport beam, there is a danger that it might fall down if mounted improperly and hit people.


- Do not stay in the danger area.
- Only install transport beams for the purpose of crane transportation and then remove them directly.

⚠ CAUTION


Protruding transport beams

Personal injury because of impact due to protruding transport beams


- Remove the transport beams after the loading magazine has been transported.
- 1. Place the transport beams 1 on the threaded pins 2 and hold.



- 2. Place the nut with washer 3 on the threaded pin 4 and tighten.
- 3. Repeat the work step for the second threaded pin.
- **4.** Insert the screw with washer 5 and tighten.
- **5.** Repeat the work step for the second screw.




Removing the transport beams




- 1. Secure the transport beams to prevent falling.
- 2. Loosen the nut with washer 1 and remove.
- 3. Repeat the work step for the second nut.
- **4.** Loosen the screw with washer 2 and remove.
- **5.** Repeat the work step for the second screw.





- **6.** Remove the transport beam 3 in the direction indicated by the arrow.
- 7. Threaded pins 4 remain for repositioning the transport beams on the loading magazine.

Assembling / disassembling the transport lock for the guide module



Assembly:

- 1. Position the transport lock 1.
- 2. Insert and tighten the screws 2.

Disassembly:

____ Disassemble in reverse order.

Angle of inclination of the load attachment gear




Falling loading magazine

Personal injury due to crushing and impact by the falling loading magazine.

When lifting the loading magazine with the multi-chain load attachment gear, the specified maximum angle of the load attachment gear has to be observed. If this angle is exceeded, the attachments of the transport beams may break and the loading magazine could fall down.


 Observe the specified maximum angle of inclination of the load attachment gear.

When using the multi-chain load attachment gear, the load attachment gear chosen must not exceed the angle of inclination of $\mathbb A$ 40°. Greater angles of inclination generate transverse forces that are beyond the rating of the attachment of the transport beams.






Detaching the loading magazine from the transport pallet



- 1. Secure the loading magazine to prevent tipping over.
- Loosen the screws in the attachment holes of the support and remove.
- **3.** Loosen the rest of the supports from the transport pallet in the same way.



- **4.** Using a crane, raise the loading magazine ☐ from the transport pallet ☐ and set down securely # "Transporting the loading magazine using the crane" on page 21.
- 1. Detach the oil tank from the transport pallet.
- 2. Lift the oil tank off the transport pallet using a suitable hoist.

Fastening the loading magazine to the transport pallet




Fastening the loading magazine to the transport pallet serves only to prevent it from slipping or to raise the loading magazine and transport pallet over the transport beams of the loading magazine. For transportation, the loading magazine has to be additionally secured. Fastening it to the transport pallet is not sufficient.




The loading magazine must be fastened to the transport pallet using adequately dimensioned fasteners.

- Pay attention to the weight of the transport pallet in the technical data. *★ "Technical data of the loading magazine"* on page 11.
- 1. Place the oil tank on the transport pallet using a suitable hoist.
- 2. Secure the oil tank to prevent it from slipping.
- 1. Raise the loading magazine 1 to the transport pallet 2 using a crane. → "Transporting the loading magazine using the crane" on page 21.
- **2.** Secure the loading magazine to prevent tipping over.







- **3.** Drill through the attachment holes 3 in the transport pallet.
- Insert the screws and washers through the attachment holes of the support 4.
- **5.** Attach and tighten the washers and nuts from the other side.
- **6.** Fasten the rest of the supports to the transport pallet in the same way.

3.2 Transporting the product

Transporting the loading magazine using the crane

If the loading magazine is hoisted with the transport pallet, it must be ensured that the attachment screws of the pallet are adequately dimensioned to prevent the pallet coming loose from the loading magazine.

▲ DANGER

Falling loading magazine

Personal injury due to squashing and impact by the falling loading magazine.

- Do not stay in the danger area.
- Use hoisting equipment suitable for the weight of the loading magazine.
- Observe the weight of the loading magazine and, where applicable, the transport pallet in the technical data.
- Only hoist the loading magazine using a crane via the transport beams.
- Observe the description on hoisting the loading magazine in the operating instructions.

A DANGER

Falling transport pallets / Loose loading magazine

Personal injury due to squashing and impact as a result of a falling transport pallet.

If the loading magazine is secured insufficiently or incorrectly to the transport palette, this may come loose. The transport pallet may fall down. The loading magazine may be knocked over and fall down.

- Do not stay in the danger area.
- Observe the description about the correct attachment of the loading magazine to the transport pallet in the operating instructions.

▲ DANGER

Falling control cabinet

Personal injury due to squashing and impact by the falling control cabinet.

- Do not stay in the danger area.
- Observe the description on securing the control cabinet in the operating instructions.



▲ DANGER

Falling oil tank

Personal injury due to squashing and impact by the falling oil tank.

- Do not stay in the danger area.
- Secure the oil tank on the transport pallet against slipping.
- 1. Assembling the transport beams *→* "Assembling the transport beams" on page 17.
- **2.** Fasten suitable hoists to all four eyebolts 1 of the transport beam.
- 3. Hoist the loading magazine and set it down securely.
- **4.** Remove the hoists from the eyebolts 1 of the transport beams.

Transporting the loading magazine using the fork-lift truck

▲ DANGER

Falling loading magazine

Personal injury due to squashing and impact by the falling loading magazine.

- Do not stay in the danger area.
- Only hoist the loading magazine on a transport pallet using a fork-lift truck.
- Observe the description on the correct attachment of the loading magazine to the transport pallet in the operating instructions.
- Pay attention to the centre of gravity when hoisting with the fork-lift truck.
- Observe the weight of the loading magazine and, where applicable, the transport pallet in the technical data.

▲ DANGER

Falling transport pallets / Loose loading magazine

Personal injury due to squashing and impact as a result of a falling transport pallet.

If the loading magazine is secured insufficiently or incorrectly to the transport palette, this may come loose. The transport pallet may fall down. The loading magazine may be knocked over and fall down.

- Do not stay in the danger area.
- Observe the description about the correct attachment of the loading magazine to the transport pallet in the operating instructions.



▲ DANGER

Falling control cabinet

Personal injury due to squashing and impact by the falling control cabinet.

- Do not stay in the danger area.
- Observe the description on securing the control cabinet in the operating instructions.

▲ DANGER

Falling oil tank

Personal injury due to squashing and impact by the falling oil tank.

- Do not stay in the danger area.
- Secure the oil tank on the transport pallet against slipping.
- 1. Fasten the loading magazine to a transport pallet * "Fastening the loading magazine to the transport pallet" on page 20.
- 2. Calculate the center of gravity of the load.
- **3.** Place the forks of the fork-lift truck beneath the center of gravity of the load.
- **4.** Additionally secure the loading magazine to prevent it from tipping forward.
- **5.** Hoist the transport pallet with the loading magazine and set it down securely.
- Detach the loading magazine from the transport pallet

 ** "Detaching the loading magazine from the transport pallet"* on page 20.


Transport the loading magazine with means of transportation




When transporting the loading magazine with means of transportation such as a truck, it is necessary to attach the loading magazine to a transport pallet * "Fastening the loading magazine to the transport pallet" on page 20. The unit consisting of the transport pallet and the loading magazine must also be secured via the transport beams of the loading magazine to the floor of the means of transport, strapped diagonally. * "Attach the loading magazine to the means of transport" on page 24.



Attach the loading magazine to the means of transport





- 1. Attach the loading magazine to a transport pallet *→* "Fastening the loading magazine to the transport pallet" on page 20.
- 2. Attach suitable fasteners 1 to the end stop of the transport beams 2.
- 3. ▶ Raise the loading magazine and the transport pallet with a crane or fork-lift truck onto the means of transport → "Transporting the loading magazine using the crane" on page 21 or → "Transporting the loading magazine using the fork-lift truck" on page 22.
- **4.** Strap the loading magazine diagonally using suitable fasteners 1 to the floor of the means of transport 3.
- **5.** Attach the opposite side of the loading magazine in the same way.



4 Assembly and start-up

4.1 Prepare for assembly

Assembly requirements

NOTICE

Damage to the floor

The floor on which the product is placed, must be designed to bear the loads. Non observance can lead to material damage.

- Have the suitability of the floor checked by an expert.

NOTICE

Damage to wires in the floor

When selecting the place to set the product down, you must make sure that there are no wires in the floor in the area under the product. They could be damaged when securing the product.

Have the suitability of the installation location checked by an expert.

Delivery state

The loading magazine and all add-on parts and equipment are delivered together on a transport pallet. The entire consignment is covered with a protective film to prevent coarse contamination.

- The loading magazine is screwed to the transport pallet.
- The oil tank is located on the transport pallet and secured to prevent it from slipping.
- The add-on set for fastening the loading magazine to the floor is packed and stored in the remnant bin.
- The adapter set is packed and stored in the remnant bin.
- Depending on the equipment, further equipment parts such as the telescopic tube set, steady, lathe, capacity adjustment set or lacquered parts are also supplied. They are all packed on the carton and secured to prevent them from slipping on the transport pallet.

Unpacking the product

Check the delivery:

- 1. Remove the protective film.
- **2.** Remove the add-on parts and equipment from the transport pallet.
- **3.** Take the add-on parts and equipment out of the remnant bin.
- 4. Unpack the add-on parts and equipment.
- **5.** Check the delivery to make sure it is complete.

Detach the consignment from the transport pallet:

- 1. Detach the oil tank from the transport pallet.
- 2. Lift the oil tank off the transport pallet using a suitable hoist.
- Detach the loading magazine from the transport pallet.
 "Detaching the loading magazine from the transport pallet" on page 20.



4.2 Aligning

Calculating the distance from the loading magazine to the machine tool

Attachment to machine tools with moving headstock:

- 1. Set up the loading magazine on the machine tool. *→* "Setting up loading magazine" on page 26.
- **2.** Calculate the distance from the loading magazine to the machine tool using the order-specific adapter diagram.
- 3. Adjust the distance.

Setting up loading magazine

▲ DANGER

Falling loading magazine

Personal injury due to squashing and impact by the falling loading magazine.

The loading magazine has a high centre of gravity. When aligning the loading magazine there is a danger of it tipping over.

- Do not stay in the danger area.
- Observe the description on aligning and setting up the loading magazine in the operating instructions.

▲ DANGER


Moving the whole loading magazine during set-up

Personal injury due to squashing or impact due to moving the whole loading magazine.


When setting up and aligning the loading magazine, the whole loading magazine has to be moved. People may be struck by the loading magazine or become stuck between the loading magazine and the lathe.

Do not stay in the danger area.


For alignment, the loading magazine with the supports is placed on round material bars (diameter 18 mm - 22 mm).



- 2. Hoist the loading magazine using suitable equipment place it together with the supports 2 on the round material bars 1.
- **3.** Align the middle of the loading magazine roughly so that the side faces the lathe spindle.
- **4.** Calculate the distance between the loading magazine and the lathe. *→* "Calculating the distance from the loading magazine to the machine tool" on page 26.
- **5.** Move the loading magazine along the round material bars and create the calculated distance to the lathe.







- **6.** ▶ Position the foot plates 3 beneath the threaded pins 4.
- 7. Turn the threaded pins 4 clockwise until the round material bars 5 are free.
- 8. Tighten the 6 nuts.
- **9.** Remove the 5 round material bars.

4.3 Electrical connection

Electrical connection of the loading magazine and lathe

The electrical connection between the loading magazine and the lathe is shown in the order-specific electrical documents. The order-specific electrical documents are contained in the technical documentation of the product. The configuration of the plug and the operating voltage of the loading magazine are determined by the lathe. The configuration of the plug is done by FMB at the factory and is completed upon delivery. The contacts are configured according to the table below and have to be checked when starting up the loading magazine. If the contacts are not configured as described in the tables, please contact FMB.

- Contacts from the loading magazine to the lathe: *→ "Contacts from the loading magazine to the machine tool" on page 27*
- Contacts from the lathe to the loading magazine:

 "Contacts from the machine tool to the loading magazine" on page 28

Contacts from the loading magazine to the machine tool

Name	Explanation
-K30	Contact closed >> No fault reported by the loading magazine
	Contact open >> The loading magazine reports a fault
	In the event of a fault, the spindle of the tool machine must no longer turn
-K1	The material bar is pushed into the machine tool or Input release, Program - Start
	This signal is emitted, depending on the machine tool control system, as an impulse or permanent contact.
-K9	This signal indicates to the machine tool that the material bar has been processed.
	This signal is emitted, depending on the machine tool control system, as a normally closed or normally open contact.
-K91 (optional)	When working with two different part lengths, this signal is emitted when the bar end of the longer part length 1 is reached.
-K90	Contact closed >> The loading magazine is in automatic mode
-K44	This signal is emitted after the execution of the part length feed and continues until the moving signal (collet open) is removed.
	The signal is only emitted in the following cases: Operating mode Part length internal, Part length external and Collet open, fixed speed.



Name	Explanation
Loading magazine emergency stop	Floating contact of the loading magazine. This contact is to be included in the emergency-stop circuit of the machine tool.

Contacts from the machine tool to the loading magazine

Machine tool signal	Loading magazine action
Collet open	The feed equipment of the loading magazine is switched on.
End of cycle, start bar change	On machine tools with a program skip in the bar starting program, the contact must be queued in front of "collet open". Contact triggers a bar change on the loading magazine.
Machine tool ready for operation, enable automatic mode	The loading magazine can be switched to automatic mode (requires this contact to be active).
Loading magazine on (option)	Contact starts automatic mode of the loading magazine.
Safety door closed	The feed movement through the loading magazine is executed only if this contact is active.
Follow-up with sub- spindle (optional)	M-command from the machine tool.
	If this signal is emitted before the collet is opened (push command), the next follow-up is converted from Part length internal, Part length external, to Part follow-up with sub-spindle.
Emergency stop of the machine tool	Floating contact of the lathe. This contact is integrated into the emergency-stop circuit of the loading magazine.

4.4 Assembly

Establish the power supply to the loading magazine

Live components of the control cabinet

Personal injury by electrical shock due to contact with live components of the control cabinet.

This work is only allowed to be performed by a qualified electrician.

Turn off the machine tool before starting work on the main switch.

Damaged wires or plugs

Personal injury by electric shock due to damaged wires or plug-in connections.

The main power supply of the loading magazine is connected to the loading magazine and attached to the front of the loading magazine.

Perform a visual check of wires and plug-in connections for damage before inserting them into the control cabinet.



- 1. Turn off the machine tool before starting work on the main switch.
- 2. Check the electrical connection of the loading magazine and lathe. → "Electrical connection of the loading magazine and lathe" on page 27
- **3.** Insert the main power supply cable of the loading magazine into the control cabinet of the lathe.
- **4.** Check the input voltage of the loading magazine.
- **5.** Insert the connecting pipe for the compressed air supply to the loading magazine into the maintenance unit 1.

Aligning the loading magazine

▲ DANGER

Falling loading magazine

Personal injury due to squashing and impact by the falling loading magazine.

The loading magazine has a high centre of gravity. When aligning the loading magazine there is a danger of it tipping over.

- Do not stay in the danger area.
- Observe the description on aligning and setting up the loading magazine in the operating instructions.

▲ DANGER

Moving pusher without protective equipment

Personal injury due to squashing and impact because of work on an unsecured pusher.

When aligning the loading magazine, it is necessary for technical reasons to move the pusher without the intended protective equipment. The danger area is not covered during this process. The moving pusher may catch extremities or people.

- Do not stay in the danger area.

⚠ CAUTION

Sharp knives of the material gripper


Cuts due to the sharp knives of the material gripper.

When working in the vicinity of the material gripper, there is a risk of cuts in the event of inattentiveness.


- Wear safety gloves.
- The centering hole on the pusher of the loading magazine must align with the lathe spindle. Set and check the alignment with an optical alignment aid. Please contact FMB if you have any questions. * "Service contact details" on page 75.

Correcting the height (roughly):






1. Loosen the clamping screws 4.




- **2.** Loosen the lock nuts 5 of the threaded spindles 6.
- **3.** Correct the height of the loading magazine with the threaded spindles 6.
- **4.** Tighten the lock nuts 5 of the threaded spindles 6.
- **5.** Tighten the clamping screws 4.



Correcting the position:

- 1. Loosen the lock nuts 7 of the threaded pins 8.
- 2. Correct the position of the loading magazine by adjusting the threaded pins 8.
- 3. Tighten the lock nuts 7 of the threaded pins 8.



Correcting the lateral position:

- 1. Position the lever (e.g. crowbar) at the leverage points 9 and correct the side position.
- **2.** Remove the optical alignment aids again.

Attaching the loading magazine to the floor



The number of attachment points to be used depends on the condition of the floor and the equipment of the loading magazine.


Consult FMB if you are unsure.



To attach the loading magazine to the floor, appropriately designed drop-in anchors or adhesive anchors must be used. Consult FMB if you are unsure.

1. Align the loading magazine *→ "Aligning the loading magazine" on page 29.*





- 2. Drill the floor holes through the attachment points 1.
- **3.** Fix attachment aids to the floor hole.
- **4.** Screw the nuts to the attachment aid and tighten.

Attachment to machine tool

▲ DANGER

Moving components of the loading magazine and the machine tool

Personal injury due to crushing, impact or entanglement by movements of the loading magazine and the machine tool.

When working on the unsecured interface (connection between loading magazine and machine tool released), extremities may become trapped or entangled by the moving components of the loading magazine or machine tool.

 Turn off the machine tool at the main switch before starting work.

⚠ CAUTION

Falling add-on parts

Personal injury due to squashing and impact by the falling add-on parts.

When setting up the loading magazine, various add-on parts have to be mounted at the interface between the loading magazine and the machine tool. They might fall down and hit body extremities.

Raise and secure add-on parts with suitable hoisting equipment.

The attachment of the loading magazine to the machine tool is order-specific and dependent on the individual design of the interface between the loading magazine and the machine tool. The loading magazine must be positioned directly on the machine tool so that there is no unsecured transition area between the loading magazine and the machine tool. If this is not possible, the transition area must be secured with an order-specific adapter set. Refer to the adapter set/attachment diagram for the precise procedure.

★ "Other applicable documents" on page 5.

If you have any questions about how the loading magazine is attached to the machine tool, please contact FMB. * "Service contact details" on page 75.




Removing the control cabinet from / attaching the control cabinet to the loading magazine




Falling control cabinet

Personal injury due to squashing and impact by the falling control cabinet.


- Observe the description on removing and fastening the control cabinet from the loading magazine in the operating instructions
- 1. Support the control cabinet 1 using suitable hoisting equipment 2.



2. Loosen the screws 3.



- 3. Shift the control cabinet in the direction indicated by the arrow and unhinge.
- **4.** Lower the control cabinet and place it on the floor.
- **5.** Attach the control cabinet to the loading magazine in reverse order.



Setting up and connecting the oil tank




Damaged wires or plugs


Personal injury by electric shock due to damaged wires or plug-in connections.

- Perform a visual check of wires and plug-in connections for damage before inserting them into the control cabinet.
- 1. Turn off the machine tool before starting work on the main switch.






2. Place the oil tank 1 below the loading magazine using suitable hoisting equipment.



3. Connect pump outlet 2 and 3 with oil feed and 5 with oil feed hose.



- **4.** Guide the oil return hose into the oil return opening 6.
- **5.** Connect the remaining end of the oil return hose to the oil return 7.
- **6.** Secure the oil return hose to the oil return 6 using a hose clip.
- Insert the plug of the oil pump into the control cabinet (the socket is located outside the control cabinet) of the loading magazine.
- 8. Fill the oil tank. .

4.5 Adjustments

Positional values to be set

During start-up, positional values have to be set once for the parameter settings. This concerns certain positions, which can only be calculated from the perspective of the whole system (the loading magazine installed on a lathe).

The following positional values have to be set:

- First insert travel
- Position front limit

Determining value for First insert travel

- 1. Load a short material bar (approx. 1 m).
- 2. Press the button.
- 3. SETUP Open .
- Move the end of the material bar on the lathe side to the starting switch using the button.
- **5.** Check and note the current position on the control panel.



- **6.** On lathes with a moving headstock: Move the end of the material bar on the lathe side through the collet of the lathe until just before the guide sleeve of the lathe using the button.
 - **1** The position "just before the guide sleeve" has to be clarified, if necessary with FMB or with the lathe manufacturer.
- 7. On lathes with a fixed headstock: Move the end of the material bar on the lathe side through the collet of the lathe up to the cut-off position using the button.
- **8.** Check and note the current position on the control panel.
- **9.** Deduct the first position from the second position.
- 10. If The result is the value for the First insert travel.
- **11.** ▶ Press the **■** button.
- 12. ► 'SETTINGS → Service settings → Position"
- **13.** ▶ Tap the First insert travel field.
 - → An input window opens.
- 14. Enter value for First insert travel .
 - → The value for First insert travel is determined.

Determining value for Position front limit

- **1.** Only for lathes with a moving headstock: Move the headstock of the spindle towards the guide sleeve to the end position.
- 2. Close the collet of the lathe.
- 3. Press the button.
- 4. SETUP Open .
- **5.** Move the pusher with the clamping sleeve towards the lathe using the button until the clamping sleeve of the loading magazine is queued on the collet of the lathe.
- **6.** ▶ Press the button.
- 7. ► 'SETTINGS → Service settings → Position"
- 8. Tap the Position front limit field.
 - → An input window opens.
- **9.** Enter the recorded value, minus the safety distance of 5 mm for Position front limit .
 - → The value for Position front limit is determined.

4.6 Settings

Distanceview

Distanceview is a display on the control panel, which is active after a pre-set time and is ended by pressing the touchscreen. On the Distanceview display, only the information relevant for production is shown on an enlarged display. This makes it possible to see the current statuses of the loading magazine, even from a distance.



Set the Distanceview



The display Distanceview is active, if the touchscreen is not pressed within the pre-set time. The time is set in seconds. If the time has been set to "0", the function is deactivated.

- 1. Press the button.
- 2. ► 'SETTINGS → System settings"
- 3. Click on the field TIME DISTANCEVIEW.
 - → An input field opens.
- **4.** Enter the value for the activation of the display.
 - Distanceview has been set and is active after the expiry of the entered time.

Set the date and time

- 1. Press the button.
- 2. ► 'SETTINGS → System settings"
- 3. Click on the field SET DATE.
 - → An input field opens.
- 4. Lenter the current date.
- Click on the field SET TIME.
 - → An input field opens.
- 6. ▶ Enter the current time.

Changing language settings

- 1. Press the button.
- 2. 'SETTINGS → System settings"
- 3. Click on the respective language.

Set the unit of measure

- 1. Press the button.
- 2.

 'SETTINGS → System settings"
- Click on the respective unit of measure in the field UNIT OF MEASURE.
 - → The status display on the button turns green. The unit of measure has been set.

4.7 Pre-set parameters

Enter Speed First insert low



The value Speed First insert low describes the speed at which the pusher moves to the Position front limit position.





This value is pre-set by the FMB. If necessary, the value can be adjusted.

- 1. Press the button.
- 2. ► 'SETTINGS → Service settings → Speed"
- 3. Click on the field Speed First insert low.
 - → An input field opens.
- **4.** Enter the value for Speed First insert low.

Enter the Speed Return from spindle



The value Speed Return from spindle describes the slower of the two speeds of the pusher when retracting. This is used if the pusher is in the area of the machine tool spindle.



This value is pre-set by the FMB. If necessary, the value can be adjusted.

- 1. Press the button.
- 2. ► 'SETTINGS → Service settings → Speed"
- 3. Click on the field Speed Return from spindle.
 - → An input field opens.
- **4.** Fanter the value for Speed Return from spindle.

Enter the Pos. reverse rotation return



At the Pos. reverse rotation return position the speed of the pusher when returning out of the machine tool spindle is switched from Speed Return from spindle to the higher Speed Return high.



This value is pre-set by the FMB. If necessary, the value can be adjusted.

- 1. Press the button.
- 2. ► 'SETTINGS → Basic settings → Parameter"
- 3. Click on the field Pos. reverse rotation return.
 - An input field opens.
- **4.** Enter the value for Pos. reverse rotation return.

Enter the Speed Return high



The value Speed Return high describes the faster of the two speeds of the pusher when retracting. This is used if the pusher is no longer in the area of the machine tool spindle.



This value is pre-set by the FMB. If necessary, the value can be adjusted.

- 1. Press the button.
- 2. ► 'SETTINGS → Service settings → Speed"



- 3. Click on the field Speed Return high.
 - → An input field opens.
- **4.** Enter the value for Speed Return high.



5 Control panel

5.1 Control panel, general

Layout

The control panel has a touchscreen, which is operated by touching it with a finger.

The upper, darker area of the screen provides information about the current statuses of the loading magazine and is visible in every menu. On the lower part of the screen the different menus are shown.



1	Display of the current material bar length
2	Number of possible parts
3	Display of the current position
4	Fault message display
5	Visualization of the current material bar length
6	Visualization of the current material bar length (enlarged image)
7	Display of the current status
8	Display of the loaded program
9	Product status (automatic mode)

Navigation

The contents of the control panel are split into several main menus. In the main menus you can reach the corresponding content page directly or via the sub-menus.

The way to reach the respective action in the control panel is described via a menu pathway in the guidelines of these operating instructions. The menu pathway shows the way via the menus to the content page which the action is on.



Example: 'Main menu → Sub menu 1 → Sub menu 2"

If you selected the last menu, you are directly on the content page on which the action occurs. The guidelines then indicate the field which should be worked on, or the button which should be pressed.

Example: Field Click on the example field.

Some pages contain more content that can be shown on one page of the control panel. In this case the described field or button may be on one of the following pages. To reach any following pages, you have to scroll through the content page. The fact that content may be located on following pages is not considered in the operating instructions.

Scroll through content pages: *★* "Scroll through content page" on page 39.

Scroll	through	content	page
--------	---------	---------	------

Access the following page

Access the following pages with <a>_.

Access the previous page

____ Access the previous page with ____.

Explanation of symbols



In the main menus PRODUCTION and SETUP there is a help page, which provides explanations of the symbols used.

Explanation of symbols Main menu PRODUCTION

- 1. Press the button.
- 2. Press PRODUCTION.
- 3. Press the 2 button.

Explanation of symbols Main menu SETUP

- 1. Press the button.
- 2. Press SETUP.
- 3. Press the putton.



6 Operation

6.1 Basic functions

Press the emergency stop button



The emergency stop button is located on the control panel. Pressing the emergency-stop button switches the outputs of the PLC output card off. The drive of the loading magazine is shut down. An error message appears on the display of the control panel.



Press the emergency stop button 1.

→ The loading magazine stops.

Make the loading magazine ready for operation after the emergency stop



- 1. Unlock the emergency stop button 1.
- **2.** Where necessary, cancel the emergency stop on the machine tool.
 - → The loading magazine is ready for operation

Switch on the loading magazine

- Turn on the main switch of the machine tool.
 - → The loading magazine is ready for operation.

Switch off the loading magazine



During active production, the production can be stopped after the end of the machine tool's cycle, and the whole system can be switched off. When the system is switched on again, the processing is continued from the same place.

- Turn off the main switch of the machine tool.
 - → The loading magazine is switched off.



Parts counter

The parts counter counts the number of parts produced. If a target value is reached, the parts counter stops the production. Product can only be restarted if the actual value has been reset. The target value of the parts counter can be adjusted * "Set the parts counter" on page 41.

Set the parts counter



Once the target value has been reached, the parts counter stops production.



Production can only be restarted, if the actual value of the parts counter has been reset → "Reset the actual value of the parts counter" on page 41.



Entering Parts counter Desired = "0" deactivates the parts counter.

- 1. Press the button.
- 2. ► 'SETTINGS → Basic settings → Parts counter"
- 3. Click on the field Parts counter Desired.
 - → An input field opens.
- **4.** Enter the value for the target number of units.
 - → The parts counter is activated with the entered target quantity.

Reset the actual value of the parts counter

- 1. Press the button.
- 2. ► 'SETTINGS → Basic settings → Parts counter"
- 3. Click on the field Reset parts counter.
 - → The parts counter is reset.

6.2 Overview of selections

Selections

Selections are available for the functions and components of the loading magazine with several respective selection options. They can be selected if required to adjust the operation of the loading magazine.



Part follow-up

Selection	Selection option	Description
Part follow-up		
	Collet open, fixed speed	Push to the stop.
	Part length internal	Push without stop to the specified position.
	Part length external (optional)	As Part length internal. Feed values are, however, provided by the lathe.
	Part length internal+w/o tension	Push without stop to the specified position. Once the push command has been removed, the system is depressurized.
	Part length external+w/o tension (optional)	As Part length internal. Feed values are, however, provided by the lathe. Once the push command has been removed, the system is depressurized.

Interval insert



The interval insert improves the insertion of multi-sided material in the collet.

Selection	Selection option	Description
Interval insert	without return	Intermittent feed of short strokes.
	with return	Intermittent feed of short forward and backward strokes.

Mode sliding-fixed headstock



This selection is available only if the machine tool can be operated in both modes (Long turn and Short turn).

Selection	Selection option	Description
Mode sliding-fixed head- stock		
	Long turn	The parameters "First insert sliding head- stock turning" and "Position front end posi- tion sliding headstock turning" are used.
	Short turn	The parameters "First insert fixed headstock turning" and "Position front end position fixed headstock turning" are used.



Draw on bar

Selection	Selection option	Description
Draw on bar	without first insert	The material bar is loaded and pressed.
	with first insert	The material bar is loaded and pressed. Then the pusher moves to the position end First insert.

Loading magazine



This function is available as an option.

Selection	Selection option	Description
Loading magazine	On	Normal work flow with the loading magazine.
	Off (chucker mode)	The loading magazine is switched off (collet mode).

6.3 Edit and manage programs

Program

Processing parameters are saved in the programs, which are valid for particular processing. During production, the program parameters of the loaded program are consulted.

For the creation of programs, a particular selection of program parameters is available, which can be set in the program editor. They are described under "Edit and manage programs".

 → Chapter 6.3 "Edit and manage programs" on page 43.

In addition to the program parameters, general processing settings can be made which are not, however, saved in the programs. They are described under "Processing settings".

→ Chapter 6.4 "Processing settings" on page 45.

Creating a new program

- 1. Press the button.
- 2. \ 'PROGRAM → NEW"
 - PROGRAM EDITOR opens.
- 3. Enter the program parameters.
- 4. Scroll to page 2 using the button.
- **5.** Press the button.
- **6.** Give the program a name.
- 7. Press the NEW button.
 - → A new program is created.



Editing a program

- **1.** ▶ Press the button.
- 2. Select PROGRAM.
- 3. Click on the program to be edited in the list.
 - → The selected program is marked blue.
- 4. Press Edit.
- **5.** Lenter the program parameters.
- **6.** ▶ Press the 🔳 button.
- 7. Press the Overwrite button.
 - → The changes are saved.

Load program



To use a program in automatic mode, it must be loaded.

- 1. Press the button.
- 2. Select PROGRAM.
- 3. Click on the corresponding program in the list.
 - → The selected program is marked blue.
- 4. Press Open and load.
 - → The selected program is loaded and is used in automatic mode.

Enter the profile of the material bar

- 1. Open the program in the program editor. *→ "Creating a new program" on page 43* or *→ "Editing a program" on page 44*.
- 2. Click on the field Profile.
 - → A list of profiles opens.
- 3. Click on the profile to be processed.
- **4.** Save changes with the button.

Entering the material to be processed

- 1. Open the program in the program editor. *→ "Creating a new program" on page 43* or *→ "Editing a program" on page 44*.
- 2. Click on the field Material.
 - An input field opens.
- 3. Finter the material to be processed.
- **4.** Save changes with the button.



Enter the diameter of the material bar to be processed

- 1. Open the program in the program editor. *→ "Creating a new program" on page 43* or *→ "Editing a program" on page 44.*
- 2. Click on the field Diameter.
 - → An input field opens.
- 3. Lenter the diameter to be processed.
- **4.** Save changes with the button.

Enter Feed force for first insert



Feed force for first insert is the force with which the pusher moves a new material bar into the working area of the lathe.



This value is pre-set by the FMB. If necessary, the value can be adjusted.

- 1. Open the program in the program editor. → "Creating a new program" on page 43 or → "Editing a program" on page 44.
- 2. Click on the field Feed force for first insert.
 - → An input field opens.
- 3. Enter Feed force for first insert.
- **4.** Save changes with the button.

Enter Extension first insert



This function allows the extension of the First insert travel. The entered value is added to the First insert travel path.



This value is set to "0" (off) by FMB. If necessary, the value can be adjusted.

- Open the program in the program editor. → "Creating a new program" on page 43 or → "Editing a program" on page 44.
- 2. Click on the field Extension first insert.
 - → An input field opens.
- 3. Enter Extension first insert.
- **4.** Save changes with the button.

6.4 Processing settings

Enter the selection option

- 1. Press the button.
- 2. ► 'SETTINGS → Basic settings → Selection option"
- 3. Click on the field with the corresponding selection.
 - → A selection window opens.



- **4.** Click on the selection option.
 - → The chosen selection option is shown in the field.

Enter Speed First insert



Speed First insert is the speed with which the pusher moves a new material bar into the working area of the lathe.



This value is pre-set by the FMB. If necessary, the value can be adjusted.

- 1. Press the button.
- 2. SETTINGS → Service settings → SPEED"
- 3. Click on the field Speed First insert.
 - → An input field opens.
- **4.** Lenter the value for Speed First insert.

Correct. value after auto / door start Enter



This function compensates for minor position changes to the pusher, which may occur if the system is relieved of tension.

When the material bar is clamped by the lathe collet, there may be a slight distortion, which is caused by the feed force of the pusher. If the system is switched from automatic to manual operation, or the working area of the lathe is opened, the drive of the loading magazine switches off. The pressure on the pusher reduces and the distortion disappears. This causes a slight change in position of the pusher, which can then be corrected by the entered value.



This value is set to "0" (off) by FMB. If necessary, the value can be adjusted.

- 1. Press the button.
- 2. ► 'SETTINGS → Basic settings → Parameter"
- 3. Tap the Correct. value after auto / door start field.
 - → An input field opens.
- **4.** Enter the value for Correct. value after auto / door start .

Enter the Max. bar return



If the material bar is clamped by the lathe collet, the pusher may be pressed back. This function reports a fault if the pusher is pressed back by more than the set value.



This value is set to "0" (off) by FMB. If necessary, the value can be adjusted.

- 1. Press the button.
- 2. ► 'SETTINGS → Basic settings → Parameter"



- 3. Click on the field Max. bar return.
 - → An input field opens.
- **4.** Enter the value for Max. bar return.

Max. remnant length Enter



This function limits the length of the remnant to the entered value. If this value is exceeded, an error message is output.



This value is set to "0" (off) by FMB. If necessary, the value can be adjusted.

- 1. Press the button.
- 2. 'SETTINGS → Service settings → Position"
- 3. Tap the Max. remnant length field.
 - → An input field opens.
- 4. Enter value for "Max. remnant length".

6.5 Feed material bars

Interval insert

The interval insert improves the insertion of multi-sided material into the lathe collet. During the first insert, the pusher performed intervals of short forward and backward strokes. The interval insert can be adjusted * "Set the Interval insert" on page 47.

Set the Interval insert



The value Travel interval on determines the length of the intermittent movement.



The intermittent movement is set for the time of the forward and backward stroke.

Length of the intermittent movement:

- 1. Press the button.
- 2. ► 'SETTINGS → Service settings → Position"
- 3. Click on the field Travel interval on.
 - → An input field opens.
- 4. Enter the value for Travel interval on.

Set the speed:

- 1. Press the button.
- 2. ► 'SETTINGS → Basic settings → Selection option"
- 3. Click on the field Time on.
 - → A selection window opens.
- 4. Enter the value for Time on.
- 5. Click on the field Time off.
 - → A selection window opens.



6. Enter the value for Time off.

Set the interval insert selection:

- 1. Press the button.
- 2. ► 'SETTINGS → Basic settings → Selection option"
- 3. Click on the field Interval insert.
 - → A selection window opens.
- 4. Click on the selection option.
 - → The chosen selection option is shown in the field.

Switching Interval insert on/off

- 2. Click on the field Interval insert.
 - → A selection window opens.
- 3. Select a corresponding value.
 - → The selection is shown in the field.
- **4.** Scroll to the next page using the __ button.
- 5. Save changes.

6.6 Processing phase

Reloading during automatic mode

During production in automatic mode, material bars can be reloaded on the loading magazine even when the machine tool is actively processing. The cover of the loading magazine can be opened for this reason.

A signal light is installed on the loading magazine. This indicates the time at which the cover of the loading magazine can be opened during production to reload material bars without interrupting the production process.

If the cover is opened during the material bar change, the loading magazine and machine tool come to a standstill.

Signal light signal	Reloading in automatic mode	Description
Yellow, constant	Reloading possible.	
Yellow, slow flashing.	Reloading possible.	Last material bar in the guide channel. The lateral material storage is empty.
Yellow, fast flashing.	Reloading possible.	Material bar change will occur soon. The cover must be closed.
Yellow, off.	Reloading not possible.	Material bar change active.



Production



During production the automatic mode is active. The loading magazine works at the same speed as the lathe. The program flow is completed taking into account the set values.

Automatic mode can be started in two stages of the program flow. This requires the following conditions:

- Step 1: A remnant is in the clamping sleeve.
- Step 17: A material bar is drawn onto the clamping device and is located in the lathe, at the cut-off position.

If the requirements for automatic mode have not been met, they can be established by the following procedure:

Remove remnant, eject it and draw on the new material bar .

Start/stop production

- Observe the prerequisites for automatic mode → "Production" on page 49.
- 2. Press the button.
- 3. Access PRODUCTION.
- 4. If there is a remnant in the clamping sleeve: press the S1 button.

If a material bar is drawn onto the clamping device and is located in the cut-off position in the lathe, press the S17 button

5. Start/stop production with the button.

Work flow for production (automatic mode)

Step	Description	Position
Step 1 Return	The pusher moves with the remnant from the lathe spindle into the area of the material gripper.	From the position: Pos. reverse rotation return at high speed
		End: Position draw off
Step 2 Close gripper blades	The material gripper closes and grabs the remnant.	-
Step 3 Draw off remnant	The pusher moves back again. The remnant is removed from the pusher.	End: Position rear limit
Step 4 Open gripper blades / guide channel	The guide channel opens. The material gripper opens. The remnant falls on the remnant flap.	-
Step 5 Open remnant flap	The remnant flap opens. The remnant falls into the remnant bin.	-
Step 6 Close gripper blades / remnant flap	The remnant flap closes. The material gripper closes.	



Step	Description	Position
Step 7 Swing pusher out	The pusher swings out of the guide channel. The separation device moves down. A material bar rolls from the lateral material storage onto the separation device.	-
Step 8 Separate material	The separation device moves up. The material bar falls into the open guide channel.	-
Step 9 Close guide channel, short pusher forward	The guide channel closes. The short pusher moves the material bars forward.	End: Limit pos. short pusher front
Step 10 Short pusher return	The material bar remains in position. The short pusher moves back.	End: Position rear limit
Step 11 Swing pusher in	The pusher swings into the guide channel. The material gripper closes and grabs the material bar.	-
Step 12 Press upon	The pusher moves forward. The material bar is pressed onto the pusher.	End: Position draw off
Step 13 Open gripper blades	The material gripper opens.	-
Step 14 First insert	The pusher moves the material bar into the working area of the lathe.	End: First insert travel
Step 15 Start lathe	The loading magazine reports "End of bar change – program start" on the lathe. The collet of the lathe closes. The processing begins.	-
Step 16 Material cut-off	The processed part is cut off. The collet of the lathe opens.	-
Step 17 Part production	The pusher moves the material bar until the end of the material bar is reached.	End: Position front limit - Part length 1
Step 18 Insert last part	The pusher moves the material bar for the last time.	
Step 19 Machine last part	The lathe operates the last part.	-
Step 20 Stop lathe / start bar change	A transfer time switch into step 1 is activated	-

Approaching Position rear limit



The "Position rear limit" position is reached when the pusher stops by itself while moving back and a value in the region of "0.00" (tolerance - 2.00 mm to + 1.50 mm) is displayed in the FEED POSITION field on the control panel.

1. Press the button.

2. Access SETUP.



3. Move the pusher back using the or button until the pusher stops. button until the

Removing the material bar from the loading magazine



This action is suitable for material bars, which cannot be removed from the remnant bin due to their length. When the action is performed, the material bar is removed from the clamping sleeve and placed in the guide channel. The material bar can then be removed from the guide channel.

⚠ WARNING

High weight of the material bar

Physical overloading when raising the material bar by a high weight.

- Observe the weight of the material bar.
- Use suitable hoisting equipment.

⚠ CAUTION Sharp knives of the material gripper

Cuts due to the sharp knives of the material gripper.

When working in the vicinity of the material gripper, there is a risk of cuts in the event of inattentiveness.

- Wear safety gloves.
- 1. Press the button.
- 2. SETUP Call .
- **3.** ▶ Press the **=** button.
 - → The status display on the button turns green during the action. Once the action has been completed, the status display on the button is switched off. The material bar is removed from the clamping device and lies in the guide channel.
- Push the material bar out of the range of the material gripper using the button.
- **5.** Press the button to move the bar to position Position rear limit .
- **6.** Swing out the pusher using the button.
- 7. Open the guide channel with the button.
- **8.** Press the emergency stop button. *→* "Press the emergency stop button" on page 40.
- **9.** Switch off the compressed air supply.
- **10.** Where necessary, obtain release from the lathe to open the cover.
- **11.** ▶ Open the cover.
- 12. If the material bar reaches into the working area of the lathe: pull the material bar by hand towards the loading magazine, until the material bar is fully on the loading magazine.
- **13.** Remove the material bar from the loading magazine via the lateral material storage.



- **14.** ▶ Close the cover.
- **15.** ▶ Switch on the compressed air supply.
- Unlock the emergency stop button. → "Make the loading magazine ready for operation after the emergency stop" on page 40
- 17. Swing in the pusher using the button.
- 18. Close the guide channel using the __ button.
- 19. Acknowledge the error message using the button.

Switching Interval insert on/off

- 1. Press the button.
- 2. Access PRODUCTION.

Switch on:

- 1. Press the numbutton.
 - → The status display on the button turns green. The interval insert is switched on.

Switch off:

- 1. Press the must button.
 - The status display on the button is off. The interval insert is switched off.

Switching the brake function on/off



The brake function holds the pusher in position while the machine tool is processing and prevents the pusher being pushed back.

- 1. Press the button.
- 2. PRODUCTION Call .

Switch on:

- Press the button.
 - → The status display on the button turns green. The brake function is switched on.

Switch off:

- Press the button.
 - → The status display on the button is off. The brake function is switched off.

Ejecting the remnant

- 1. Press the button.
- 2. SETUP Call .
- 1. Press and hold the button.
 - → The status display on the button turns green. The remnant flap is opened. The remnant drops into the remnant bin.



2. Release the multiple button.

been swung in.

→ The status display on the button is off. The remnant flap is closed.

Swinging the pusher out/in

1. Press the button.
2. SETUP Call .
Swing out:
Press the button.
The status display on the button turns green. The pusher has been swung out.
Swing in:
Press the button.
→ The status display on the button is off. The pusher has



7 Converting

7.1 General conversion

Capacity adjustment set

The loading magazine can process material bars of different diameters. Certain components of the loading magazine can be adjusted to the material bar diameter to be processed in order to improve material bar guidance. These components are consolidated in a capacity adjustment set and can be exchanged if needed.

If you have any questions about selecting the right capacity adjustment set, please contact FMB. *★* "Service contact details" on page 75.

The capacity adjustment set includes:

- A pusher with a short pusher and flag
- Inserts of the guide channel
- Lifting plates
- Flap limiter

The guide jaws of the steady and the telescopic tube/guide tube/guide module can also be adapted to the material diameter to be processed. However, these are not part of the capacity adjustment set.

Depending on the extension version and the type of lathe, further adjustments may be necessary when converting to other diameters. For information about this, see the attachment-specific adapter set/attachment diagram. **Other applicable documents" on page 5.

Move to the conversion position

- 1. Press the button.
- 2. Access SETUP.
- Press the substitution.
 - → The status display on the button turns green. The conversion position is moved to (duration approx. 10s).

7.2 Guide channel

Adjusting the guide channel diameter

Adjusting the diameter sets the guide channel diameter to the entered value.

Adjusting the guide channel diameter

- 1. Press the button.
- 2. DIAMETER press.
- 3. Tap the Channel diameter field.
 - An input field opens.
- 4. Enter the value.



- 5. Press the Set press.
 - → The guide channel diameter is set to the entered value.

Pusher

The pusher is driven by the drive motor and moves the material bar into the working area of the lathe. The diameter of the pusher depends on the diameter of the material to be processed and must be changed when processing different material thicknesses.

Depending on the spindle diameter of the lathe, it may be necessary for the spindle diameter to also be adjusted. In the event of questions about this please contact FMB. * "Service contact details" on page 75

Changing the pusher

MARNING

Falling material bar

Personal injury due to squashing and impact as a result of a falling material bar.

Material bars which are located on the lateral material storage, may fall down during conversion work.

 Before conversion work, remove the material bars from the lateral material storage.

⚠ WARNING

Heavy weight of the pusher

Physical overloading when raising the pusher due to heavy weight.

- Observe the weight of the pusher.
- Use suitable hoisting equipment.

⚠ CAUTION

Sharp knives of the material gripper

Cuts due to the sharp knives of the material gripper.


When working in the vicinity of the material gripper, there is a risk of cuts in the event of inattentiveness.


- Wear safety gloves.


Removal:

- 1. Dismantle the clamping device. .
- 2. Press the button.
- 3. SETUP Press .
- **4.** Approach the conversion position by pressing the □ button. *★ "Move to the conversion position" on page 54.*
- 5. Press the emergency stop button. *▶ "Press the emergency stop button" on page 40.*
- 6. Switch off the compressed air supply.
- **7.** Where necessary, obtain release from the lathe to open the cover.
- 8. Den the cover.
- **9.** Set the holding-down device in the area of the pusher to the uppermost position.










- Push the pusher 1 in the direction indicated by the arrow until the pusher is pushed out of the lifting plate 2.
- Lower the pusher in the direction indicated by the arrow and push until the pusher is pushed out of the lifting plate 4.
- **13.** ▶ Remove the pusher.



Installation:

- 1. Install the pusher in reverse order.
- **2.** Ensure that the pusher is seated correctly (against the stop) in plate 1.
- 3. Close the cover.
- 4. Switch on the compressed air supply.
- Unlock the emergency stop button. → "Make the loading magazine ready for operation after the emergency stop" on page 40
- **6.** Swing in the pusher using the **button**.
- 7. Close the guide channel using the button.
- 8. Acknowledge the error message using the button.

Changing the insert of the top rear guide channel



Falling material bar

Personal injury due to squashing and impact as a result of a falling material bar.

Material bars which are located on the lateral material storage, may fall down during conversion work.

 Before conversion work, remove the material bars from the lateral material storage.




Sharp knives of the material gripper

Cuts due to the sharp knives of the material gripper.

When working in the vicinity of the material gripper, there is a risk of cuts in the event of inattentiveness.

- Wear safety gloves.





The top rear guide channel insert 1 is located in the area between the drive motor 2 and the material gripper 3

To change the top rear guide channel insert, the pusher must be removed. * "Changing the pusher" on page 55.

- 1. Press the button.
- 2. SETUP Press .
- **4.** Press the emergency stop button. *→* "Press the emergency stop button" on page 40.
- **5.** Switch off the compressed air supply.
- **6.** Where necessary, obtain release from the lathe to open the cover.
- 7. Den the cover.
- **8.** Take hold of the insert 1.
- **9.** Press the insert lock 2 and release.
 - → The insert is now detached.



- **10.** Turn the insert in the direction indicated by the arrow and remove it.
- **11.** ▶ Place the new insert in the top rear guide channel.




- **12.** ▶ Pull the insert lock 2 until it engages.
 - → The insert is secured.
- **13.** ▶ Install the pusher. *→* "Changing the pusher" on page 55.





Changing the lifting plates



- 1. Remove the "top rear insert". → "Changing the insert of the top rear guide channel" on page 56.
- **2.** Remove the lifting plate 1 in the direction indicated by the arrow.
- 3. Install the new lifting plates in the reverse order.
- 4. Install the "top rear insert". → "Changing the insert of the top rear guide channel" on page 56.

Changing the bottom rear insert of the guide channel



Falling material bar

Personal injury due to squashing and impact as a result of a falling material bar.

Material bars which are located on the lateral material storage, may fall down during conversion work.

 Before conversion work, remove the material bars from the lateral material storage.

⚠ CAUTION


Sharp knives of the material gripper

Cuts due to the sharp knives of the material gripper.

When working in the vicinity of the material gripper, there is a risk of cuts in the event of inattentiveness.


- Wear safety gloves.

The bottom rear guide channel insert 1 is located in the area between the drive motor 2 and the remnant bin 3.





- 1. Press the button.
- 2. SETUP Press .
- 3. Approach the conversion position by pressing the □ button. *★ "Move to the conversion position" on page 54.*
- **4.** Press the emergency stop button. *→* "Press the emergency stop button" on page 40.
- **5.** Switch off the compressed air supply.
- **6.** Where necessary, obtain release from the lathe to open the cover.
- 7. Den the cover.











- **8.** Press the insert locks 1 and release.
 - → The insert is now detached.
- 9. Turn the insert [2] in the direction indicated by the arrow and remove it.
- 10. Place the new insert into the top rear guide channel.
- **11.** ▶ Pull the insert locks 1 until they engage.
 - → The insert is secured.
- **12.** ▶ Close the cover.
- **13.** ▶ Switch on the compressed air supply.
- **14.** ▶ Unlock the emergency stop button. *→ "Make the loading* magazine ready for operation after the emergency stop" on page 40
- 15. Swing in the pusher using the toutton.
- **16.** Close the guide channel using the toutton.
- **17.** ▶ Acknowledge the error message using the □ button.

Changing the top front insert of the guide channel



Falling material bar

Personal injury due to squashing and impact as a result of a falling material bar.

Material bars which are located on the lateral material storage, may fall down during conversion work.

Before conversion work, remove the material bars from the lateral material storage.

⚠ CAUTION


Sharp knives of the material gripper

Cuts due to the sharp knives of the material gripper.

When working in the vicinity of the material gripper, there is a risk of cuts in the event of inattentiveness.

Wear safety gloves.





The top front guide channel insert 1 is located in the area between the material gripper 2 and the steady 3. The insert consists of several parts. The change is described using the example of one part of the insert, but has to be done for all the parts.

- 1. Press the button.
- 2. SETUP press.
- **3.** Approach the conversion position by pressing the □ button. *★ "Move to the conversion position" on page 54.*
- **4.** Press the emergency stop button. *→* "Press the emergency stop button" on page 40.
- 5. Switch off the compressed air supply.
- **6.** Where necessary, obtain release from the lathe to open the cover.
- 7. Den the cover.
- 8. | Hold the insert 1.
- 9. Press the insert lock 2 and release.
 - → The insert is now detached.
- 10. Turn the insert 1 in the direction indicated by the arrow and remove it.
- **11.** ▶ Place the new insert into the upper front guide channel.
- **12.** ▶ Pull the insert lock 2 until it engages.
 - → The insert is secured.
- 13. Close the cover.
- 14. Switch on the compressed air supply.
- **16.** Swing in the pusher using the **to** button.
- 17. Close the guide channel using the toutton.
- **18.** ▶ Acknowledge the error message using the □ button.






1

2

The flap limiter 1 is located below the "bottom front insert".





- 1. Remove the "bottom front insert". → "Changing the insert of the bottom front guide channel" on page 61.
- **2.** Pull off the flap limiter 1 in the direction indicated by the arrow.
- 3. Install the new flap limiter in reverse order.
- **4.** Install the "bottom front insert". *→* "Changing the insert of the bottom front guide channel" on page 61.

Changing the insert of the bottom front guide channel



Falling material bar

Personal injury due to squashing and impact as a result of a falling material bar.

Material bars which are located on the lateral material storage, may fall down during conversion work.

 Before conversion work, remove the material bars from the lateral material storage.

⚠ CAUTION


Sharp knives of the material gripper

Cuts due to the sharp knives of the material gripper.

When working in the vicinity of the material gripper, there is a risk of cuts in the event of inattentiveness.


Wear safety gloves.

The bottom front guide channel insert 1 is located in the area between the remnant bin 2 and the steady 3. The insert consists of several parts. The change is described using the example of one part of the insert, but has to be done for all the parts.



- 1. Press the button.
- 2. SETUP press.
- 4. Press the emergency stop button. *▶* "Press the emergency stop button" on page 40.
- 5. Switch off the compressed air supply.
- **6.** Where necessary, obtain release from the lathe to open the cover.
- 7. Den the cover.







- 8. Press the insert lock 1 and release.
 - → The insert is now detached.
- **9.** Turn the insert 2 in the direction indicated by the arrow and remove it.
- **10.** Place the new insert into the upper front guide channel.
- 11. Pull the insert lock 1 until it engages.
 - → The insert is secured.
- **12.** ▶ Close the cover.
- 13. Switch on the compressed air supply.
- **15.** Swing in the pusher using the **to** button.
- **16.** Close the guide channel using the button.
- 17. Acknowledge the error message using the button.


Changing the guide module

- **1.** ▶ Press the **■** button.
- 2. SETUP Press .
- 4. Press the emergency stop button. *▶ "Press the emergency stop button" on page 40.*
- 5. Switch off the compressed air supply.
- **6.** Where necessary, obtain release from the lathe to open the cover.
- 7. Den the cover.
- 8. Pull the index pin 1 and rotate through 30°.
 - → The index pin is in the open position
- **9.** Pull the guide module 2 out of the adapter set 3 in the direction indicated by the arrow.









- **10.** ▶ Pull the index pin 4 and rotate through 30°.
 - → The index pin is in the open position
- 11. Remove the guide sleeve 5 in the direction indicated by the arrow.
- **12.** Remove the guide module 6 in the direction indicated by the arrow.
- Attach the guide module in reverse order. It must be ensured that the locking points for the index pins are in the correct position so that the index pins lock.
- 14. Close the cover.
- **15.** Switch on the compressed air supply.
- Unlock the emergency stop button. → "Make the loading magazine ready for operation after the emergency stop" on page 40
- 17. Swing in the pusher using the sutton.
- **18.** Close the guide channel using the **t** button.
- **19.** Acknowledge the error message using the **button**.



8 Maintenance

8.1 Maintenance actions

Maintenance plan

Chap.	Task to perform	Every 6 months	Every 36 months	Page
	Check the drive belt	X		64
	Check the belts of the diameter setting	Χ		65
	Lubricate the worm gear of the diameter setting	X		66
	Replace the relay insert in the control cabinet		X	67

Check the drive belt

▲ DANGER

Moving components of the loading magazine and the tool machine with the cover open

Personal injury due to squashing, impact or striking by movements of the loading magazine and the machine tool with the cover open.

During maintenance work on the loading magazine, there may be unexpected movements of the components of the loading magazine and the machine tool.

 Turn off the machine tool at the main switch, before performing maintenance work. Observe the sequence of the working steps according to the descriptions listed below.

⚠ CAUTION

Sharp knives of the material gripper

Cuts due to the sharp knives of the material gripper.

When working in the vicinity of the material gripper, there is a risk of cuts in the event of inattentiveness.

Wear safety gloves.



Condition of the drive belt:

If the drive belt has cracks or is missing teeth, it must be replaced. Contact FMB. → "Service contact details" on page 75.

- 1. Press the emergency stop button. → "Press the emergency stop button" on page 40.
- 2. Switch off the supply of compressed air.
- **3.** Where necessary, obtain release from the lathe to open the cover.
- 4. Den the cover.
- **5.** Turn off the machine tool at the main switch.



- **6.** Check the condition: Check the drive belt visually for missing teeth.
- 7. Close the cover.
- **8.** Turn on the machine tool at the main switch.
- 9. Switch on the compressed air supply.
- 11. Acknowledge the error message by pressing the button.

Check the belts of the diameter setting



Moving components of the loading magazine and the tool machine with the cover open

Personal injury due to squashing, impact or striking by movements of the loading magazine and the machine tool with the cover open.

During maintenance work on the loading magazine, there may be unexpected movements of the components of the loading magazine and the machine tool.

 Turn off the machine tool at the main switch, before performing maintenance work. Observe the sequence of the working steps according to the descriptions listed below.

⚠ WARNING

Moving components of the loading magazine without a safety cover

Personal injury due to squashing and impact due to freely-accessible, driven components of the loading magazine.

With maintenance work on the loading magazine, it may be necessary for technical reasons to remove screwed-on safety covers. Screwed in safety covers are not electrically locked. That means that the loading magazine is not automatically shut down when these safety covers are removed, and driven components may still move.

- Before removing safety covers, press the emergency stop button.
- After the end of the maintenance work, reattach the safety covers directly.
- Maintenance work is only to be performed if the person holds the respective qualification described in these operating instructions.




Condition of the diameter setting belt:


If the diameter setting belt has cracks or is missing teeth, the diameter setting belt must be replaced. Contact FMB. → "Service contact details" on page 75.

- **1.** Turn off the machine tool at the main switch.
- 2. Press the emergency stop button. *→ "Press the emergency stop button" on page 40.*





- 3. Loosen the screws of the back wall 1 and remove.
- **4.** Remove the back wall 1.



- **5.** Check the condition: Check the belt 2 visually for cracks and missing teeth.
- **6.** ▶ Put the back wall 1 into position.
- 7. Insert the screws of the back wall and tighten.
- 8. Turn on the machine tool at the main switch.
- 9. Unlock the emergency stop button. → "Make the loading magazine ready for operation after the emergency stop" on page 40

Lubricate the worm gear of the diameter setting

▲ DANGER

Moving components of the loading magazine and the tool machine with the cover open

Personal injury due to squashing, impact or striking by movements of the loading magazine and the machine tool with the cover open.

During maintenance work on the loading magazine, there may be unexpected movements of the components of the loading magazine and the machine tool.

 Turn off the machine tool at the main switch, before performing maintenance work. Observe the sequence of the working steps according to the descriptions listed below.

⚠ WARNING

Moving components of the loading magazine without a safety cover

Personal injury due to squashing and impact due to freely-accessible, driven components of the loading magazine.

With maintenance work on the loading magazine, it may be necessary for technical reasons to remove screwed-on safety covers. Screwed in safety covers are not electrically locked. That means that the loading magazine is not automatically shut down when these safety covers are removed, and driven components may still move.


- Before removing safety covers, press the emergency stop button.
- After the end of the maintenance work, reattach the safety covers directly.
- Maintenance work is only to be performed if the person holds the respective qualification described in these operating instructions.






The number of worm gears depends on the length of the loading magazine. All worm gears must always be lubricated during maintenance.

- 1. Turn off the machine tool at the main switch.
- 2. Loosen the screws of the back wall 1 and remove.





- 3. Lubricate the worm gear 2.
- 4. Lubricate the worm gear 3.
- **5.** Put the back wall 1 into position.
- 6. ▶ Insert the screws of the back wall ☐ and tighten.
- 7. Turn on the machine tool at the main switch.
- 8. Unlock the emergency stop button. *★ "Make the loading magazine ready for operation after the emergency stop" on page 40*

Replace the relay insert in the control cabinet



Live components of the control cabinet

Personal injury by electrical shock due to contact with live components of the control cabinet.

This work is only allowed to be performed by a qualified electrician.

 Turn off the machine tool before starting work on the main switch.



The relay insert for changing signals with the lathe must be replaced regularly. In the event of uncertainty, please contact FMB.

- → "Service contact details" on page 75.
- 1. Turn off the machine tool before starting work on the main switch.
- **2.** Disconnect the relay insert in the control cabinet of the loading magazine.
- **3.** Insert the new relay insert in the control cabinet of the loading magazine.



Empty the oil tank of the loading magazine

▲ DANGER

Moving components of the loading magazine and the tool machine with the cover open

Personal injury due to squashing, impact or striking by movements of the loading magazine and the machine tool with the cover open.

During maintenance work on the loading magazine, there may be unexpected movements of the components of the loading magazine and the machine tool.

 Turn off the machine tool at the main switch, before performing maintenance work. Observe the sequence of the working steps according to the descriptions listed below.

⚠ WARNING

Leaking fuel

Personal injuries due to slipping on leaking fuel.

Leaking fuel causes a slipping hazard in the working area.

- Remove leaking fuel immediately.
- Observe the description in the operating instructions about filling / emptying the oil tank.
- Only fill fuel in the intended containers.



Observe the oil tank level. → "Technical data of the loading magazine" on page 11.



Before the next operation of the loading magazine, the oil tank of the loading magazine must be refilled. .




To empty the oil tank, a suitable pump has to be used.

- 1. Press the emergency stop button. *→ "Press the emergency stop button" on page 40.*
- 2. Switch off the compressed air supply.
- 3. Turn off the machine tool at the main switch.
- **4.** Prepare a suitable container with sufficient capacity to collect the oil.



- **6.** Remove the oil feed hose on the oil feed 1.
- **7.** Guide the end of the removed oil feed hose into the container provided.
- **8.** Pump the whole contents of the oil tank into the container provided, using a suitable pump.
- 9. Insert the oil feed hose onto the oil feed 1.
- **10.** ▶ Tighten the hose clip on the oil feed 1.
- 11. Turn on the machine tool at the main switch.
- **12.** ▶ Switch on the compressed air supply.






14. Acknowledge the error message by pressing the witton.

8.2 Auxiliary equipment

Shifting the loading magazine



This function is available as an option.

The shifting device 1 is located between the support and the beam of the loading magazine. The procedure is described using the example of a support. To shift the loading magazine, the shifting device must be activated on each support.



The screws 2 must be used in alternating positions depending on the shifting positions. Several drill holes are intended for this.

- 1. ▶ Press the emergency stop button. ★ "Press the emergency stop button" on page 40.
- 2. Switch off the compressed air supply.
- **3.** ▶ Loosen the screws 2 and remove.
- 4. Pull and hold the locking pin 3.
- **5.** Shift the loading magazine up to the stop.
- **6.** ▶ Release the locking pin 3.
- 7. Insert and tighten the screws 2.
- 8. Switch on the compressed air supply.
- 9. Unlock the emergency stop button. *→ "Make the loading magazine ready for operation after the emergency stop" on page 40*
- 10. Acknowledge the error message using the putton.



Performing a reference run



If the drive of the loading magazine is moved manually in switchedoff condition, it causes the position of the PLC control unit to be lost. In this case, a reference run must be performed.

- 1. Press the button.
- 3. Press the button.
- **4.** Press the Reference run button.
 - → The status display on the button flashes yellow. The reference run is performed. The status display on the button turns green. The reference run is ended.



9 Faults

9.1 Fault messages

Display the current fault message

The current fault message is shown in the upper area of the control panel.

Delete the current fault message

Press the LR button.

Display of pending fault messages in the fault list

- 1. Press the button.
- 2. ► 'DIAGNOSIS → Fault list"

Delete fault messages in the fault list

- 1. Press the button.
- 2. ► 'DIAGNOSIS → Fault list"

Delete an error message:

- 1. Click on error message.
- **2.** Delete the error message with the button.

Delete all error message:

- 1. Click on error message.
- 2. Delete the error message with the button.

Access the fault history

- 1. Press the button.
- 2. *DIAGNOSIS* → Fault list"
- **3.** Press the button.

Display the position of the current fault on the loading magazine

- 1. Press the button.
- 2. July 'DIAGNOSIS → Fault list"
- 3. Press the strongshille button.



9.2 Fault table

Fault message and possible cause

Fault message of the loading magazine	Possible cause	Switch / position
Axis 1 fault, code: xx	The servo drive issues a fault message.	
Starting switch -B7 not in home position -KK5/B7	The starting switch is not back in its home position. Air flow disrupted Solenoid valve -KK5 not working	Starting switch not in the home position. Switch -B7 not actuated.
Starting switch -B7 not in the home position -KK9/B7	The starting switch is not back in its home position. Air flow disrupted Solenoid valve -KK9 not working	Starting switch not in the home position. Switch -B7 not actuated.
Press upon not correct; Pos. material draw-off not reached	The clamping sleeve was not pressed, or not pressed completely, onto the material bar. Feed force for press upon too low. Incorrect clamping sleeve. New clamping sleeve.	Position Position draw off has been reached.
Storage empty! No new bar reloaded -B80	There is no material bar in the lateral material storage.	Switch -B80 not actuated.
Diameter setting of channel -M3	The monitoring time has expired. The diameter setting was not performed. The desired value of the channel diameter setting does not agree with the actual value.	
Diameter setting of separation M4/B8	The monitoring time has expired. The diameter setting was not performed. The desired value of the separation diameter setting does not agree with the actual value.	
Motor speed controller not ready for operation -TA1/K3	Fault on the drive motor speed controller.	
Guide channel not closed; Check guide channel -KK01/B6/B26/B28	The guide channel is not closed. Solenoid valve -KK01 not working. Air flow disrupted.	Switch -B6 or -B26 not actuated.
Opening – closing of guide channel not correct -KK1/ KK01/B5/B6/B26/B28	Guide channel not opened or closed correctly. Solenoid valve -KK1 or -KK01 not working. Air flow disrupted.	Switch -B5, -B6, or -B26 not actuated.
No stop in the lathe	Caution selection First insert To stop set! The material bar was not stopped by an end stop in the working area of the lathe.	



Fault message of the loading magazine	Possible cause	Switch / position
No return of remnant -B13	Remnant remains in the lathe. The material gripper did not grab any remnant when removing the remnant.	Switch -B13 was actuated.
	■ The lathe collet does not open correctly.	
	The remnant fell out of the clamping sleeve when returning. The material gripper did not grab any remnant when removing the remnant.	
	Clamping sleeve pressure too low.	
No new bar in guide channel -B13	The material gripper does not grab any material bars when drawing on No material bar was loaded from the lateral	Switch -B13 was actuated.
	material storage.	
No air pressure! -B11 Check air pressure min. 5 bar	The compressed air is too low, or is lacking, on the maintenance unit.	Switch -B11 not actuated.
	Air supply disturbed	
Magazine not in start position; Start position step 1,15,17 or 19	The loading magazine is not in one of the possible starting positions: step 1, step 15, step 17 or step 19.	
Material on the lateral storage -B80	Material bars are located in the lateral material storage.	Switch -B80 actuated.
Material bar loaded in test run	Test mode active. In test mode, there must be no material bars on the lateral material storage.	
Max fill level of the loading magazine lubricant container reached	The maximum fill level of the lubricant container was reached.	
Motor protection -F1 tripped! -M1/F1 Check -M1, switch -F1 on	The drive motor of the loading magazine was overloaded.	Motor protection switch -F1 was triggered.
Motor protection -F2 tripped! -M2/F2 Check -M2, switch -F2 on	The motor of the oil pump was blocked or overloaded.	Motor protection switch - F2 was triggered.
Motor overload switch F3 triggered! check -M3/F3 -M3, activate F3	Drive motor of the pilgrim step separation was overloaded.	Motor protection switch -F3 was triggered.
Neg.software end position was overrun. Release with manual forward function	The negative software stop was overrun.	
Emergency Stop lathe	The emergency stop button of the lathe was actuated.	
Emergency Stop loading magazine -S69	The emergency stop button on the loading magazine was actuated.	



Fault message of the loading magazine	Possible cause	Switch / position
Pilgrim step separation not in position / not empty -B83/B81/B82	 The pilgrim step separation is not in position. Pilgrim step separation was lowered without authorization. Pilgrim step separation was raised without authorization. The pilgrim step separation cycle was interrupted. 	
Pos.software end position was overrun. Release with manual return function	The positive software stop was overrun.	
Profibus/Profinet - No live signal from the lathe	The connection of Profibus / Profinet to the machine tool is defective.	
Relay tumbler -K225	Malfunction of the channel lock module. Relay -K225 not working.	
Remnant jammed in clamping sleeve -B13	The remnant was not correctly extracted from the clamping sleeve and is still in the gripping area. The material gripper closes to check the remnant ejection and then grabs the available remnant. The clamping sleeve pressure is not right. The blades of the material gripper are worn. The pressure of the material gripper is too low. The remnant did not fall correctly into the remnant bin and is still in the gripping area. The material gripper closes to check the remnant ejection and then grabs the remaining remnant. The remnant flap is oily. The remnant remains stuck on the remnant flap.	Switch -B13 was not actuated.
Remant flap not closed -KK010/B17	The remnant flap does not close. Solenoid valve -KK010 does not switch. Air flow disrupted.	Switch -B17 not actuated.
Remnant to long	The "Maximum remnant length" function is active. The length of the remnant exceeds the entered value.	
Pushing signal not ok; Check signal from lathe	The signal "collet open" is transferred by the lathe in an unstable way to the loading magazine (the signal bounces). Defective connection Relay worn (on the lathe side)	



Fault message of the loading magazine	Possible cause	Switch / position
Sensor of the pilgrim step separation support contaminated -B83	 The light reflection for the stable detection of a material bar is not sufficient. Sensor head (light guide) of switch -B83 is damaged or dirty. 	
Signal sliding-fixed head- stock lathe mode does not match shifting device -B71/B76	The external signal of the machine tool (long or short turning mode) does not agree with the position of the shifting device.	
Collet in the lathe closed	Caution selectionDraw on bar with first insert set! The collet of the lathe is not open. First insert cannot be performed. The collet position signal is not available in manual mode.	
Collet closed too long	Collet monitoring time expired.	
Collet opened too long	Collet monitoring time expired.	
Bar has been pushed back	Caution Max. bar return active. The material bar was moved back past the set value when closing the collet. Lathe clamping system not OK.	
Part follow-up too short	Caution Min. part length follow-up active. The entered value was not reached when pushing the material bar. Feed force too low. The collet signal is unstable.	
Part follow-up too long	Caution Max. part length follow-up active. The entered value was exceeded when pushing the material bar. End stop in the lathe overrun.	
Cover not closed -B76/B77/B78/B79/K20/K2 1	The cover (guide channel cladding) or the lid of the steady is not closed.	Switch -B71, -B76, -B77, -B78, or -B79 not actuated.
Shifting device -B71/B76	The shifting device is in a non-permitted position.	Switch -B71 and -B76 not actuated.
Pusher not swung in correctly -KK08/B23	Pusher incorrectly swung in. Solenoid valve -KK08 does not switch. Air flow disrupted.	Switch -B23 does not switch.



Fault message of the loading magazine	Possible cause	Switch / position
Pusher out of position	Caution Part length internal or Part length external active.	
	The pusher was moved during processing.	
	 Vibrations to the material bar. Lathe clamping system not OK. Brake not switched on. Braking force too low. 	
Z-axis collision	The entered value for rotary encoder B4 was not met.	
Monitoring time motor expired	The moving signal is constantly on. The motor pushes against resistance. Problem with the lathe work flow.	
The monitoring time of motor -M3 pilgrim step separation has expired -B81	The motor did not end the single cycle after approx. 10 seconds.	Switch -B81 does not switch.
Monitoring time bar change expired; Fault at bar change	The bar change was unable to be performed correctly. Monitoring time expired.	

9.3 Service

Service contact details

Service telephone no.	+49 9392 801 801
Telephone no. of the headquarters	+49 9392 801 0
Fax	+49 9392 801 220
Email	info@fmb-machinery.de

9.4 Technical problems

Behavior of the loading magazine in the event of a power failure

In the event of a power failure, the operation of the loading magazine is interrupted. The pressurisation of the pneumatic valves is interrupted. All parameters are saved and are available again once the power supply is reestablished.





10 Index

A	Delivery state
Aligning	Detaching the loading magazine
the loading magazine	from the transport pallet
Assembling	Diameter of the material bar
the transport beams	Entering
Attaching the control cabinet	Dimensions
to the loading magazine	Loading magazine
Attaching the loading magazine	Set the
to the floor	Drive
С	Drive belt
	Checking
Capacity adjustment set	
CE marking	E
Changing	Electrical connection of the loading magazine and
the guide module	lathe
the lifting plates	Emergency stop
the limiter flap	Emergency stop device
the lubricant	Make the loading magazine ready for operation
the pusher	after the emergency stop 4
Changing the lifting plates	Press the emergency stop button 40
Connection of the loading magazine and the lathe	Emptying
Electrical connection	the oil tank 6
Connection of the loading magazine and the machine	Explanation of symbols
tool	F
Contacts from the loading magazine to the	Fortonia allo de la Romana de la
machine tool	Fastening the loading magazine
Contacts from the machine tool to the loading	to the transport pallet
magazine28	fault message
Contacts from the loading magazine to the machine	Access the fault history
tool	Display of pending fault messages
Contacts from the machine tool to the loading	Display the position of the current fault on the
magazine	loading magazine
Control panel	Fault message
Explanation of symbols	show the current fault message
Layout	Feed the material bar
Navigation	Feed the multiple-sided material 4
Converting Change the insert of the bottom front guide	Feed the multiple-sided material
channel	bar
Changing the bottom rear insert of the guide	Front end position
channel	Setting the positional value
Changing the lifting plates	Functional description
Changing the limiter flap 60	G
Changing the top front insert of the guide channel	
	Guide channel
Cover	adjusting diameter
Safety switch	
Cover of the loading magazine	adjusting
Lock	Changing bottom rear insert
opening	Changing the bottom front insert 6
D	Changing the top front insert
	Changing the top rear insert
Date	gg
Set the	



1	Profile
Interval insert	Enter the profile of the material bar
1	Program Oraching a pow program
L	Creating a new program
Language	Editing44
change	R
Language settings	Reference run
change	Performing a run 69
Lathe	Reloading during automatic mode 48
Safety door	Removing
Angle of inclination	the transport beams
Loading magazine	Removing the material bar
attach to means of transport	from the loading magazine
Calculating the distance to the machine tool 26	Return speed shift
Dimensions	S
Functional description	Cofety
Overview of components8	Safety Personal safety equipment
switching off	Safety equipment
switching on	selection
transport with means of transportation 23	Overview
M	Selection options
Maintananaa nlan	Set the
Maintenance plan	Selections
Entering the material to be processed 44	Enter the selection option 45
Max. bar return	Setting up
Setting	the control cabinet
Max. remnant length	the loading magazine
Setting	Shifting
Menus	the loading magazine
Navigation	Special equipment
N	Speed
	First insert
Name plate	First insert low
Navigation	Return from spindle
Control panel	Return high
Menus	Steady
0	Lid
Oil tank	Storage conditions
connecting32	Switching brake function
setting up	on/off
Operating conditions	T
Overview	Technical data
Components	Loading magazine
P	Time
Packaging	Set the
Parts counter	Transport
Personal safety equipment	Angle of inclination of the load attachment gear. 19
Pos. reverse rotation return	Transport lock
Entering	Transporting
Power failure	loading magazine by means of transportation. 23
Behavior of the loading magazine	Preparing the loading magazine for transportation
Product versions	the loading magazine using the crane
	the loading magazine using the fork-lift truck 22
	-



Fransporting the loading magazine	
using the crane	21
using the fork-lift truck	22
J	
Jnit of measure	
change	35

⋖			turbo RSV Interface EDGE Standard	Btr.Spn.: 3x200V~ 50/60Hz	Z
	Blatt- Nr.:	Inhalt	contents		
<u> </u>	1/1063 2/1063 3/1063 4/1063 5/1063 7/1063 8/1063	Zeichnungs Aufstellung Kennzeichnung der Betriebsmittel Schnittstelle Edge Standard Schnittstelle Edge Standard Erdung Hauptstromkreis Servoantrieb -M1 Steuerspannung	index of plans marking of the electrical equipment interface edge standard interface edge standard grounding main circuits Servodrive motors -M1 main circuits Oilpump -M2 control voltage		<u>m</u>
O	9/1063 10/1063 12/1063 13/1063 15/1063 16/1063	SPS-Steuerung, Bedieneinheit Refferenzschalter, Messschalter Not-Halt Sicherheit Überwachung Abdeckung Lademagazin Überwachung Abdeckung Lünette Überwachung Abdeckung Lünette Überwachung Führungskanal Lademagazin	PLC-control, control panel refference-switch, measuring-switch emergency stop, safety check covering loading magazine check covering steady check covering steady check guide channel loading magazine check guide channel loading magazine		O
Ω	18/1063 19/1063 20/1063 22/1063 23/1063 24/1063 25/1063	e KF10 MX400.0 e KF10 MX401.0 e KF11 MX403.0 e KF11 MX403.0 te KF20 MX600. te KF20/K21 MX te KF20/K21 MX	input-card KF10 MX400.0-7 input-card KF10 MX400.0-7 input-card KF11 MX402.0-7 input-card KF11 MX403.0-7 input-card KF10/KF11 MX404.0-7 output-card KF20/21 MX601.0-7 output-card KF21 MX601.0-7		Ω
Ш	26/1063 27/1063 29/1063 30/1063 31/1063 32/1063 33/1063	(F22 MX (F23/KF; (F23 MX (F23 MX) Iangskar J / Weg ellung nschlus; turbo	output-card KF22 MX603.0-7 input-card KF22/KF23 MX604.0-3 output-card KF23 MX605.0-7 analog in/output-card A24-2,AQ1-2 synchr. clutch / encoder distance motor diametter setting -M3/M4 switch cabinet Interface device arrangement RS 4-45 device arrangement RS 4-45		Ш
LL	35/1063 36/1063 70/1063 Aenderung	Geräteanordnung turbo 4–52 V Schalttafel Bearb D.Beck Gepr. D.Beck Orspr Ers.f.	device arrangement 4-52 V switch board Zeichnungs MASCHINENBAU Ers.d. Aufstellung Blatt 1/1063	1111_003 Folge 2	<u>L</u>

 ∞

